



## **ProLiant DL380**

Maintenance and Service Guide

Fourth Edition (June 2000)  
Part Number 136363-004  
Spare Part Number 159127-001  
Compaq Computer Corporation

## Notice

© 2000 Compaq Computer Corporation

Compaq, ProLiant, SmartStart, and the Compaq logo Registered U.S. Patent and Trademark Office.

Compaq Authorized Reseller is a trademark and/or service mark of Compaq Information Technologies Group, L.P.

Other product names mentioned herein may be trademarks and/or registered trademarks of their respective owners.

Compaq Computer Corporation shall not be liable for technical or editorial errors or omissions contained herein. The information in this document is subject to change without notice.

**The information in this publication is subject to change without notice and is provided "AS IS" WITHOUT WARRANTY OF ANY KIND. THE ENTIRE RISK ARISING OUT OF THE USE OF THIS INFORMATION REMAINS WITH RECIPIENT. IN NO EVENT SHALL PUNITIVE OR OTHER DAMAGES WHATSOEVER (INCLUDING WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION OR LOSS OF BUSINESS INFORMATION), EVEN IF COMPAQ HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. THE FOREGOING SHALL APPLY REGARDLESS OF THE NEGLIGENCE OR OTHER FAULT OF EITHER PARTY AND REGARDLESS OF WHETHER SUCH LIABILITY SOUNDS IN CONTRACT, NEGLIGENCE, TORT, OR ANY OTHER THEORY OF LEGAL LIABILITY, AND NOTWITHSTANDING ANY FAILURE OF ESSENTIAL PURPOSE OF ANY LIMITED REMEDY.**

**The limited warranties for Compaq products are exclusively set forth in the documentation accompanying such products. Nothing herein should be construed as constituting a further or additional warranty.**

Compaq ProLiant DL380 Maintenance and Service Guide  
Fourth Edition (June 2000)  
Part Number 136363-004  
Spare Part Number 159127-001

# Contents

## About This Guide

|                                       |      |
|---------------------------------------|------|
| Symbols in Text.....                  | vii  |
| Compaq Technician Notes .....         | viii |
| Where to Go for Additional Help ..... | ix   |
| Telephone Numbers .....               | ix   |

## Chapter 1

### Illustrated Parts Catalog

|  |     |
|--|-----|
| Mechanical Parts Exploded View.....      | 1-2 |
| Mechanical Spare Parts List .....        | 1-3 |
| System Components Exploded View .....    | 1-4 |
| System Components Spare Parts List ..... | 1-5 |

## Chapter 2

### Removal and Replacement Procedures

|  |      |
|--|------|
| Electrostatic Discharge Information.....             | 2-2  |
| Symbols on Equipment.....                            | 2-3  |
| Preparation Procedures.....                          | 2-4  |
| Powering Down the Server.....                        | 2-4  |
| Rack Warnings .....                                  | 2-6  |
| Server Warnings and Precautions.....                 | 2-6  |
| Server Cover.....                                    | 2-7  |
| Power On/Standby Switch with Status Indicators ..... | 2-8  |
| Rack-Mount Bezel.....                                | 2-9  |
| Diskette Drive.....                                  | 2-10 |
| Power Supply Fan and Bracket .....                   | 2-12 |
| Power Supply Blank.....                              | 2-13 |
| Hot-Plug Power Supply.....                           | 2-14 |
| Hot-Plug Power Supply Backplane Board .....          | 2-15 |
| Mass Storage Devices.....                            | 2-16 |
| External Storage Devices .....                       | 2-16 |
| ProLiant DL380 Drives.....                           | 2-17 |
| Drive Locations .....                                | 2-17 |
| Hard Drive Blank .....                               | 2-18 |
| SCSI Hot-Plug Hard Drive.....                        | 2-19 |
| Hot-Plug Drive Cage.....                             | 2-20 |
| SCSI Backplane Board.....                            | 2-21 |
| Low-Profile IDE CD-ROM Drive.....                    | 2-22 |
| Removable Media Blank .....                          | 2-23 |
| Optional 2x1-Inch Media Device Drive Cage .....      | 2-24 |

## Removal and Replacement Procedures

*continued*

|   |      |
|---|------|
| Cable Routing Diagrams .....              | 2-25 |
| PCI Expansion Board .....                 | 2-27 |
| Riser Board and Brace .....               | 2-28 |
| Memory .....                              | 2-29 |
| SDRAM DIMM .....                          | 2-31 |
| Processor and Processor Power Module..... | 2-32 |
| Processor .....                           | 2-33 |
| Processor Power Module .....              | 2-34 |
| CPU Fan .....                             | 2-35 |
| Integrated Smart Array Controller.....    | 2-36 |
| System Board .....                        | 2-38 |
| System Board Battery.....                 | 2-39 |

## Chapter 3

### Diagnostics and Troubleshooting

|   |      |
|---|------|
| Diagnostic Tools Utility Overview.....                        | 3-2  |
| Default Configuration.....                                    | 3-4  |
| Default Configuration Messages .....                          | 3-4  |
| Inspect Utility.....  | 3-4  |
| Utilities Access.....   | 3-5  |
| Running Compaq Utilities.....                                 | 3-5  |
| Power-On Self-Test (POST).....                                | 3-7  |
| POST Error Messages .....                                     | 3-7  |
| Diagnostics Software.....                                     | 3-23 |
| Steps for Diagnostics.....                                    | 3-23 |
| 100 – 199, Primary Processor Test Error Codes .....           | 3-24 |
| 200 – 299, Memory Test Error Codes .....                      | 3-25 |
| 300 – 399, Keyboard Test Error Codes .....                    | 3-26 |
| 400 – 499, Parallel Printer Test Error Codes.....             | 3-26 |
| 500 – 599, Graphics Display Unit Test Error Codes .....       | 3-27 |
| 600 – 699, Diskette Drive Test Error Codes .....              | 3-28 |
| 1100 – 1199, Serial Test Error Codes .....                    | 3-29 |
| 1200 – 1299, Modem Communications Test Error Codes .....      | 3-29 |
| 6000 – 6099, Compaq NIC Boards Test Error Codes .....         | 3-30 |
| 6500 – 6599, SCSI Hard Drive Test Error Codes .....           | 3-31 |
| 6600 – 6699, SCSI/IDE CD-ROM Drive Test Error Codes.....      | 3-32 |
| 6700 – 6799, SCSI Tape Drive Test Error Codes .....           | 3-32 |
| 8600 – 8699, Pointing Device Interface Test Error Codes ..... | 3-33 |
| Array Diagnostic Utility (ADU).....                           | 3-33 |
| Starting ADU.....   | 3-33 |
| Integrated Management Log.....                                | 3-44 |
| Multiple Ways of Viewing the Log.....                         | 3-44 |
| Event List .....  | 3-46 |
| Event Messages .....  | 3-47 |
| Rapid Error Recovery.....                                     | 3-49 |
| Automatic Server Recovery-2 .....                             | 3-49 |
| ASR-2 Integrated Management Log Messages .....                | 3-61 |
| Storage Fault Recovery Tracking .....                         | 3-64 |
| Storage Automatic Reconstruction.....                         | 3-64 |
| Network Interface Fault Recovery Tracking .....               | 3-64 |
| Memory Fault Recovery Tracking .....                          | 3-64 |
| Remote Service Features .....                                 | 3-65 |

**Diagnostics and Troubleshooting***continued*

|   |      |
|---|------|
| ROMPaq Error Recovery Options.....                    | 3-65 |
| ROMPaq Disaster Recovery .....                        | 3-66 |
| Compaq Insight Manager .....                          | 3-67 |
| Features of Compaq Insight Management.....            | 3-67 |
| Compaq Insight Management Software Architecture ..... | 3-68 |

**Chapter 4****Connectors, Switches, and Status Indicators**

|   |      |
|---|------|
| Connectors.....                                 | 4-1  |
| Rear Panel Components .....                     | 4-2  |
| Riser Board Expansion Slots .....               | 4-3  |
| System Board Components .....                   | 4-4  |
| Switches .....                                  | 4-5  |
| System Configuration Switchbank (SW2).....      | 4-5  |
| LED Indicators .....                            | 4-6  |
| Power Switch LED Indicators .....               | 4-7  |
| Hot-Plug Power Supply LED Indicators .....      | 4-8  |
| RJ-45 LED Indicators.....                       | 4-9  |
| System Board LED Indicators.....                | 4-10 |
| SCSI Hard Drive LED Indicators.....             | 4-11 |
| Low-Profile IDE CD-ROM Drive LED Indicator..... | 4-12 |
| 1.44-MB Diskette Drive LED Indicator .....      | 4-13 |
| Riser Board LED Indicator.....                  | 4-14 |

**Chapter 5****Specifications**

|   |      |
|---|------|
| System Unit .....   | 5-2  |
| Hot-Plug Power Supply.....  | 5-3  |
| Memory .....  | 5-4  |
| 1.44-MB Diskette Drive .....  | 5-4  |
| Low-Profile IDE CD-ROM Drive .....                                      | 5-5  |
| Wide Ultra2 SCSI Hot-Plug Hard Drive .....                              | 5-6  |
| Integrated Smart Array Controller.....                                  | 5-7  |
| NC3163 Embedded 10/100 Fast Ethernet NIC Controller (Wake On LAN) ..... | 5-8  |
| Smart Array 221 Controller.....   | 5-9  |
| Smart Array 3200 Controller.....  | 5-10 |
| Smart Array 4200 Controller.....  | 5-11 |
| NC3131 Fast Ethernet NIC 64 PCI Dual Base 10/100.....                   | 5-12 |
| Optional 2x1-Inch Hot-Plug Drive Cage.....                              | 5-13 |

**Index**



# About This Guide

This maintenance and service guide is a troubleshooting guide that can be used for reference when servicing Compaq ProLiant DL380 Servers.

---

**IMPORTANT:** The installation of options and the servicing of this product shall be performed by individuals who are knowledgeable of the procedures, precautions, and hazards associated with equipment containing hazardous energy circuits.

---

## Symbols in Text

These symbols may be found in the text of this guide. They have the following meanings.



**WARNING:** Text set off in this manner indicates that failure to follow directions in the warning could result in bodily harm or loss of life.

---



**CAUTION:** Text set off in this manner indicates that failure to follow directions could result in damage to equipment or loss of information.

---

**IMPORTANT:** Text set off in this manner presents clarifying information or specific instructions.

---

**NOTE:** Text set off in this manner presents commentary, sidelights, or interesting points of information.

## Compaq Technician Notes



**WARNING:** Only authorized technicians trained by Compaq should attempt to repair this equipment. All troubleshooting and repair procedures are detailed to allow only subassembly/module level repair. Because of the complexity of the individual boards and subassemblies, no one should attempt to make repairs at the component level or to make modifications to any printed wiring board. Improper repairs can create a safety hazard.

---



**WARNING:** To reduce the risk of electric shock or damage to the equipment:

- If the system has multiple power supplies, disconnect power from the system by unplugging all power cords from the power supplies.
  - Do not disable the power cord grounding plug. The grounding plug is an important safety feature.
  - Plug the power cord into a grounded (earthed) electrical outlet that is easily accessible at all times.
- 



**CAUTION:** To properly ventilate your system, you must provide at least 12 inches (30.5 cm) of clearance at the front and back of the computer.

---



**CAUTION:** The computer is designed to be electrically grounded. To ensure proper operation, plug the AC power cord into a properly grounded AC outlet only.

---

**IMPORTANT:** Any indications of component replacement or printed wiring board modifications may void any warranty.

---



## Where to Go for Additional Help

In addition to this guide, the following information sources are available:

- User documentation
- On line information at the Compaq website  
<http://www.compaq.com/support/servers/index.html>
- *Compaq Service Quick Reference Guide*
- Service training guides
- Compaq service advisories and bulletins
- Compaq QuickFind
- Compaq Insight Manager
- Compaq download facility: Call using computer modem 1-281-518-1418

## Telephone Numbers

For the name of your nearest Compaq authorized reseller:

- In the United States, call 1-800-345-1518.
- In Canada, call 1-800-263-5868.

For Compaq technical support:

- In the United States and Canada, 1-800-386-2172.
- For Compaq technical support phone numbers outside the United States and Canada, visit the Compaq website:

<http://www.compaq.com>

# *Chapter 1*

## **Illustrated Parts Catalog**

This chapter provides the illustrated parts breakdown and a spare parts list for the Compaq *ProLiant*<sup>™</sup> DL380 Servers. See Table 1-1 and Table 1-2 for the names of referenced spare parts.

# Mechanical Parts Exploded View




Figure 1-1. Mechanical parts exploded view

## Mechanical Spare Parts List

**Table 1-1**  
**Mechanical Spare Parts List**

| <b>Item</b>    | <b>Description</b>                        | <b>Spare Part Number</b> |
|----------------|---|--------------------------|
| <b>Chassis</b> |   |                          |
| 1              | Chassis                                   | 212943-001               |
| 2              | Server cover                              | 327313-001               |
| 3              | Rack-mount bezel                          | 218257-001               |
| 4              | SCSI drive cage                           | 159137-001               |
| 5              | Optional 2x1-inch media device drive cage | 144087-001               |
| 6              | Hard drive blank                          | 122759-001               |
| 7              | Removable media blank                     | Part of kit 159542-001   |

# System Components Exploded View




Figure 1-2. System components exploded view

## System Components Spare Parts List

**Table 1-2**  
**System Components Spare Parts List**

| <b>Item</b>                 | <b>Description</b>                                    | <b>Spare Part Number</b> |
|-----------------------------|---|--------------------------|
| <b>System Components</b>    |   |                          |
| 8                           | CPU fan   |                          |
|                             | a) 92 mm, 74 CFM                                      | 159203-001               |
|                             | b) 92 mm, 110 CFM                                     | 216472-001               |
| 9                           | Power supply fan                                      | 173907-001               |
| 10                          | Power On/Standby switch with cable and LED indicators | 144086-001               |
| 11                          | Processors  |                          |
|                             | a) Pentium III 667-MHz with heatsink                  | 166109-001               |
|                             | b) Pentium III 733-MHz with heatsink *                | 166108-001               |
|                             | c) Pentium III 800-MHz with heatsink *                | 187781-001               |
|                             | d) Pentium III 866-MHz with heatsink *                | 187782-001               |
|                             | e) Pentium III 933-MHz with heatsink *                | 196628-001               |
|                             | f) Pentium III 1-GHz with heatsink *                  | 221536-001               |
| 12                          | Hot-plug power supply, 275 W                          | 159125-001               |
| <b>Boards</b>               |   |                          |
| 13                          | Riser board and brace                                 | 159128-001               |
| 14                          | Hot-plug power supply backplane board                 | 333112-001               |
| 15                          | SCSI drive cage backplane board                       | 387090-001               |
| 16                          | System board  | 157824-001               |
| 17                          | Integrated Smart Array Controller                     | 158855-001               |
| 18                          | 128-MB Registered 133-MHz SDRAM DIMM                  | 159226-001               |
| 19                          | Processor power module                                | 157825-001               |
| <b>Mass Storage Devices</b> |   |                          |
| 20                          | 24X low-profile IDE CD-ROM drive                      | 323332-001               |
| 21                          | 1.44-MB diskette drive                                | 179161-001               |
| 22                          | 18-GB Wide Ultra2 hard drive                          | 143920-001               |

\* Not shown

*continued*

**Table 1-2**  
**System Components Spare Parts List** *continued*

| Item           | Description                                   | Spare Part Number      |
|----------------|---|------------------------|
| <b>Options</b> |   |                        |
| 23             | Signal cable kit *                            | 159129-001             |
|                | CD data shredded cable assembly               |                        |
|                | SCSI 2-device shredded cable assembly         |                        |
|                | SCSI 1-device shredded cable assembly         |                        |
| 24             | Power cable kit *                             | 327919-001             |
|                | 14-pin power cable assembly                   |                        |
|                | Main 20-pin power cable assembly              |                        |
|                | Hard drive/CD power cable assembly            |                        |
| 25             | Plastics kit *                                | 327319-001             |
|                | Option board retainer                         |                        |
|                | Blank option board bracket                    |                        |
|                | Power supply fan guard                        |                        |
|                | Power supply fan cover                        |                        |
| 26             | Thermal upgrade kit*                          | 216472-001             |
| 27             | CD tray assembly *                            | Part of kit 159542-001 |
| 28             | Return kit *                                  | 327322-001             |
| 29             | Country kit *                                 | 159124-001             |
| 30             | Mounting kit for rack model *                 | 327310-001             |
| 31             | Carton and buns, international *              | 327322-002             |
| 32             | Maintenance and service guide *               | 159127-001             |
| 33             | Battery, 3-V lithium *                        | 179322-001             |
| 34             | Baffle *                                      | 163327-001             |
| 35             | Expansion slot 1 optional installation tool * | 216394-001             |

\* Not shown

*continued*

**Table 1-2**  
**System Components Spare Parts List** *continued*

| Item               | Description  | Spare Part Number |
|--------------------|--|-------------------|
| <b>Memory</b>      |  |                   |
| 36                 | 64-MB registered 133-MHz SDRAM DIMM *                    | 159225-001        |
| 37                 | 256-MB registered 133-MHz SDRAM DIMM *                   | 159304-001        |
| 38                 | 512-MB registered 133-MHz SDRAM DIMM *                   | 159227-001        |
| 39                 | 1-GB registered 133-MHz SDRAM DIMM *                     | 163902-001        |
| <b>Controllers</b> |  |                   |
| 40                 | NC3163 Embedded 10/100 Fast Ethernet NIC (Wake On LAN) * | N/A               |
| 41                 | Smart Array 221 controller *                             | 400546-001        |
| 42                 | Smart Array 3200 controller *                            | 340855-001        |
| 43                 | Smart Array 4200 controller *                            | 401859-001        |
| 44                 | NC3131 Fast Ethernet NIC 64 PCI Dual Base 10/100 *       | 338482-001        |
| * Not shown        |  |                   |



## *Chapter* **2**

# **Removal and Replacement Procedures**

This chapter provides subassembly/module-level removal and replacement procedures for Compaq ProLiant DL380 Servers. After completing all necessary removal and replacement procedures, run the Diagnostics program to verify that all components operate properly.

The following tools are recommended:

- Torx T-15 screwdriver
- Torx T-7 screwdriver
- From the SmartStart and Support Software CD:
  - System Configuration Utility software
  - Array Diagnostics Utility (ADU)
  - Diagnostics software

## Electrostatic Discharge Information

A discharge of static electricity can damage static-sensitive devices or microcircuitry. Proper packaging and grounding techniques are necessary precautions to prevent damage. To prevent electrostatic damage, observe the following precautions:

- Transport products in static-safe containers such as conductive tubes, bags, or boxes.
- Keep electrostatic-sensitive parts in their containers until they arrive at static-free stations.
- Cover workstations with approved static-dissipating material. Use a wrist strap connected to the work surface and properly grounded tools and equipment.
- Keep the work area free of nonconductive materials such as ordinary plastic assembly aids and foam packing.
- Always be properly grounded when touching a static-sensitive component or assembly.
- Avoid touching pins, leads, or circuitry.
- Always place drives PCB assembly-side down.
- Use conductive field service tools.

## Symbols on Equipment



25 kg  
55 lb

Any product or assembly marked with these symbols indicates that the component exceeds the recommended weight for one individual to handle safely.

**WARNING:** To reduce the risk of personal injury or damage to the equipment, observe local occupational health and safety requirements and guidelines for manual material handling.



Any surface or area of the equipment marked with these symbols indicates the presence of a hot surface or hot component.

**WARNING:** To reduce the risk of injury from a hot component, allow the surface to cool before touching it.




To reduce the risk of injury from electric shock hazards, do not open this enclosure.

**WARNING:** Any surface or area of the equipment marked with these symbols indicates the presence of electric shock hazards. The enclosed area contains no operator serviceable parts.




Any RJ-45 receptacle marked with these symbols indicates a Network Interface Connection.

**WARNING:** To reduce the risk of electric shock, fire, or damage to the equipment, do not plug telephone or telecommunications connectors into this receptacle.



Power supplies or systems marked with these symbols indicate the equipment is supplied by multiple sources of power.

**WARNING:** To reduce the risk of electric shock or damage to the equipment, disconnect power from the server by unplugging all power cords from the electrical outlet or the server.



This label or equivalent is located on the surface of your CD-ROM drive. This label indicates that the product is classified as a Class 1 Laser Product.

## Preparation Procedures

Before beginning to remove any serviceable parts, determine whether the part is hot-pluggable or non-hot-pluggable.

### Hot-Pluggable Device

Hot-pluggable devices in the ProLiant DL380 Server include SCSI hard drives and power supplies.

---

**IMPORTANT:** It is not necessary to turn off the server to replace hot-plug devices such as power supplies, fans, or hard drives when they are not in active use.


---

### Non-Hot-Pluggable Device

If the part is non-hot-pluggable, the server must be powered down. Non-hot-pluggable parts include the processors, all boards, DIMMs, fans, and drive cages.

## Powering Down the Server

System power in ProLiant DL380 Servers does not completely shut off with the front panel Power On/Standby switch. The switch toggles between On and Standby, rather than On and Off. The standby position removes power from most electronics and the drives, but portions of the hot-plug power supply and some internal circuitry remain active. To completely remove all power from the system, you must disconnect all power cords from the server.



**WARNING:** To reduce the risk of injury from electric shock, remove all power cords to completely disconnect power from the system.

---



**WARNING:** To reduce the risk of personal injury or damage to the equipment, ensure that only one component is extended at a time. A rack may become unstable if more than one component is extended for any reason.

---



**WARNING:** Because the rack allows you to stack computer components in a vertical rather than a horizontal plane, you must take precautions to provide for rack stability and safety to protect both personnel and property. Heed all cautions and warnings throughout the installation instructions that came with the server.

---



**WARNING:** To reduce the risk of personal injury or damage to the equipment: If the server is removed from the rack for device accessibility, remove the server from the rack and place it on a sturdy table or workbench. Refer to the *ProLiant DL380 Server Setup and Installation Guide* for further information on working with racks.

---



**CAUTION:** The system power in the server does not completely shut off from the front Power On/Standby switch. Moving the switch from On to Standby leaves some portions of the hot-plug power supply and some internal circuitry active. Disconnect all power cords from the server to remove all power from the system.

---



**CAUTION:** Electrostatic discharge can damage electronic components. Be sure you are properly grounded before beginning any installation procedure. For more information, see “Electrostatic Discharge Information” earlier in this chapter.

---

1. Press the Power On/Standby switch to Standby. This places the server in standby mode, thereby disabling the main hot-plug power supply output and providing auxiliary power to the server. Standby does not completely disable or remove power from the system.
2. Verify that the system LED indicator on the front panel, near the Power On/Standby switch, is amber and that the fan noise has stopped.
3. Disconnect the AC power cord from the AC outlet, then from the server.
4. Disconnect all external peripheral devices from the server.
5. For stability and safety, properly positioning the server is critical.

## Rack Warnings



25 kg  
55 lb

**WARNING:** To reduce the risk of personal injury or damage to the equipment:

- Observe local Occupational Safety requirements and guidelines for heavy equipment handling.
- Obtain adequate assistance to lift and stabilize the product during installation or removal.
- Remove all pluggable power supplies and modules to reduce the weight of the product.
- At least two people are needed to safely unload the rack from the pallet. An empty 42U rack weighs 115 kg (253 lb), is over 2.1 meters (7 ft) tall, and may become unstable when being moved on its casters. Do not stand in front of the rack as it rolls down the ramp from the pallet; handle it from the sides. Stabilize the server by keeping the unit on the rails.



25 kg  
55 lb

**WARNING:** To reduce the risk of personal injury or damage to the equipment:

- Always load the heaviest item first and load the rack from the bottom up. This makes the rack “bottom-heavy” and helps prevent the rack from becoming unstable.
- The bottom stabilizers on the equipment must be fully extended. Be sure that the equipment is properly supported/braced when installing options and cards.
- Be sure that the rack is adequately stabilized before extending a component outside the rack. Extend only one component at a time. A rack may become unstable if more than one component is extended.



**WARNING:** To reduce the risk of personal injury, fire, or damage to the equipment, do not overload the AC supply branch circuit that provides power to the rack.

## Server Warnings and Precautions



**WARNING:** To reduce the risk of personal injury from hot surfaces, allow the internal system components to cool before touching them.



**CAUTION:** Protect the server from power fluctuations and temporary interruptions with a regulating uninterruptible power supply (UPS). This device protects the hardware from damage caused by power surges and voltage spikes and keeps the system in operation during a power failure.



**CAUTION:** The ProLiant DL380 Server must always be operated with system unit covers on. Proper cooling will not be achieved if the system unit covers are removed.

## Server Cover

To remove the server cover:

1. Complete the preparation procedures. See “Powering Down the Server” earlier in this chapter.
2. Loosen the three captive thumbscrews on the rack-mount bezel ❶.
3. Use the grip slot to slide the cover toward the rear of the unit approximately 2.5 cm (1-inch); then lift off the server cover ❷.




Figure 2-1. Removing the server cover

Reverse steps 1 through 3 to replace the server cover.

## Power On/Standby Switch with Status Indicators

To remove the Power On/Standby switch with status indicators:

1. Perform the preparation procedures. See “Powering Down the Server” earlier in this chapter.
2. Remove the server cover. See “Server Cover” earlier in this chapter.
3. Disconnect the power switch cable from the system board ❶.
4. Press in on the two tabs on the top and bottom of the switch ❷.
5. Push the switch through the bezel as shown ❸.




Figure 2-2. Removing the Power On/Standby switch with status indicators

Reverse steps 1 through 5 to replace the Power On/Standby switch with status indicators.



## Rack-Mount Bezel



**WARNING:** Before removing the rack-mount bezel, be sure the computer is powered down and the power cord is disconnected from the electrical outlet.

To remove the rack-mount bezel:

1. Complete the preparation procedures. See “Powering Down the Server” earlier in this chapter.
2. Remove the Power On/Standby switch assembly from the bezel. See “Power On/Standby Switch with Status Indicators” earlier in this chapter.
3. Remove the nine screws from the front of the bezel ❶.
4. Remove the rack-mount bezel ❷.




Figure 2-3. Removing the rack-mount bezel

Reverse steps 1 through 4 to replace the rack-mount bezel.

## Diskette Drive



**CAUTION:** When removing or installing the diskette drive, be careful not to damage its front eject button.

To remove the diskette drive:

1. Complete the preparation procedures. See “Powering Down the Server” earlier in this chapter.
2. Remove the server cover. See “Server Cover” earlier in this chapter.
3. Disconnect the power and data cables from the diskette drive (if installed).
4. Remove the Power On/Standby switch. See “Power On/Standby Switch with Status Indicators” earlier in this chapter.
5. Remove one T-15 screw ❶ from the diskette drive.
6. Slide the diskette drive back, then away from the front bezel until it stops ❷.

**NOTE:** Ensure that the diskette eject lever clears the bezel when removing the diskette drive. Slide the diskette drive straight back from the front of the unit.




Figure 2-4. Removing the screw and sliding the diskette drive

**NOTE:** The cables from the Power On/Standby switch have been removed from the drawing for clarity.

7. Rotate the rear of the diskette drive toward the outer edge of the chassis ③.
8. Lift the diskette drive straight up to remove it ④.




Figure 2-5. Removing the diskette drive

**NOTE:** The cables from the Power On/Standby switch have been removed from the drawing for clarity.

Reverse steps 1 through 8 to replace the diskette drive.

## Power Supply Fan and Bracket

To remove the power supply fan and bracket:

1. Complete the preparation procedures. See “Powering Down the Server” earlier in this chapter.
2. Remove the server cover. See “Server Cover” earlier in this chapter.
3. Unplug the fan from the system board.
4. Remove the three screws from the power supply fan bracket ❶.
5. Move the fan assembly forward. Pull up to remove the fan assembly from the power supply ❷.




Figure 2-6. Removing the power supply fan and bracket

Reverse steps 1 through 5 to replace the power supply fan and bracket.

## Power Supply Blank

To remove a power supply blank:

1. Push in the tabs on the power supply blank ❶.
2. Pull the tab out until it is horizontal ❷.
3. Pull the power supply blank out the back of the chassis ❸.

---

**IMPORTANT:** A ProLiant DL380 Server ships standard with a single power supply module. The primary module must populate the outer bay. A power supply blank may populate the inner bay. The blank can be removed and a second power supply can be installed for redundant power supply capability.

---




Figure 2-7. Removing the power supply blank

Reverse steps 1 through 3 to replace a power supply blank.

## Hot-Plug Power Supply



**WARNING:** To reduce the risk of electric shock, do not disassemble the power supply or attempt to repair it. It should be replaced only with the specified spare part.

---

To remove a hot-plug power supply:

1. Unplug the AC power cord.
2. Push in the port-colored lever on the power supply blank ❶.
3. Pull the lever out until it is horizontal ❷.
4. Pull the power supply out the back of the chassis ❸.

---

**IMPORTANT:** A ProLiant DL380 Server ships standard with a single power supply module. The primary module must populate the outer bay. A power supply blank may populate the inner bay. The blank can be removed and a second hot-plug power supply installed for redundant power supply capability.

---




Figure 2-8. Removing a power supply

Reverse steps 1 through 4 to replace a power supply.

## Hot-Plug Power Supply Backplane Board

To remove a hot-plug power supply backplane board:

1. Complete the preparation procedures. See “Powering Down the Server” earlier in this chapter.
2. Remove the server cover. See “Server Cover” earlier in this chapter.
3. Remove the power supply fan and bracket. See “Power Supply Fan and Bracket” earlier in this chapter.
4. Disconnect all cables from the backplane board.
5. Tilt the backplane forward.
6. Pull up to remove the backplane board ❶.




Figure 2-9. Removing a power supply backplane board

To replace a power supply backplane board, slide it into the three slots on the back of the power supply, then reverse steps 1 through 4.

## Mass Storage Devices

ProLiant DL380 Servers can house up to eight mass storage devices, including:

- Up to four 1-inch, hot-plug hard drives
- Preinstalled, low-profile, IDE CD-ROM drive
- Preinstalled 3.5-inch, 1.44-MB diskette drive in the vertical position
- Two half-height 5.25-inch removable media drives
- Optional hard drive cage that supports two 1-inch SCSI hot-plug hard drives

## External Storage Devices

You can connect optional mass storage devices to the ProLiant DL380 by using the external SCSI port on the back of the unit.

**NOTE:** All servers ship standard with SCSI ports connected to appropriate cables. In order to use the external SCSI connector, the internal cable located in port 1 must be removed.



## ProLiant DL380 Drives

This section describes the drive cage positions, and removal and replacement procedures for parts of the ProLiant DL380 Server.



**CAUTION:** The ProLiant DL380 Server does not support the IDE or EIDE hard drives.

### Drive Locations




Figure 2-10. Drive options

**Table 2-1**  
**Drive Options**

| Item | Media Positions | Configuration  |
|------|-----------------|--|
| ❶    | 0, 1, 2, 3      | Hot-plug drive cage accommodating four 1-inch height SCSI hot-plug hard drives |
| ❷    | A, B            | Two 5.25-inch wide x half-height drives  |
| ❸    | 4, 5            | Optional drive cage that supports two 1-inch media devices                     |
| ❹    |                 | Low-profile IDE CD-ROM drive   |
| ❺    |                 | Diskette drive   |

## Hard Drive Blank

To remove a hard drive blank:

1. Push the tab to unlock the hard drive blank ❶.
2. Continue to press on the tab and slide the hard drive blank out of the drive cage ❷.

---

**IMPORTANT:** A hard drive blank must be installed in an unused drive slot. Failure to install a hard drive blank could result in thermal failures.

---




Figure 2-11. Removing a hard drive blank

To replace a hard drive blank, slide the blank into the cage until it clicks into place.

## SCSI Hot-Plug Hard Drive

To remove a SCSI hot-plug hard drive:

1. Push in the tab to unlock the lever on the hard drive ❶.
2. Rotate the lever outward, as shown ❷.
3. Pull the hard drive out of the bay ❸.




Figure 2-12. Removing a hard drive

To replace the hard drive, slide the drive into the cage until it clicks into place, then close the lever.

## Hot-Plug Drive Cage

To remove the hot-plug drive cage:

1. Complete the preparation procedures. See “Powering Down the Server” earlier in this chapter.
2. Remove the drives from the drive cage. See “SCSI Hot-Plug Hard Drive” earlier in this chapter.
3. Disconnect the SCSI and power cables from the SCSI backplane board.
4. Remove the three Torx T-15 screws securing the drive cage to the chassis **1**.
5. Pull the drive cage back, then up to remove it from the server **2**.




Figure 2-13. Removing a hot-plug drive cage

Reverse steps 1 through 5 to replace the hot-plug drive cage.

## SCSI Backplane Board

To remove the SCSI backplane board:

1. Complete the preparation procedures. See “Powering Down the Server” earlier in this chapter.
2. Disconnect the SCSI and power cables from the SCSI backplane board.
3. Remove the drives from the drive cage. See “SCSI Hot-Plug Hard Drive” earlier in this chapter.
4. Remove the hot-plug drive cage. See “Hot-Plug Drive Cage” earlier in this chapter.
5. Loosen the thumbscrew securing the backplane board to the drive cage ❶.
6. Remove the backplane board from the drive cage ❷.




Figure 2-14. Removing a backplane board

**NOTE:** When replacing the SCSI backplane board, slide the backplane board down into the hooks on the back of the power supply.

Reverse steps 1 through 6 to replace the SCSI backplane board.

## Low-Profile IDE CD-ROM Drive

To remove the low-profile IDE CD-ROM drive:

1. Complete the preparation procedures. See “Powering Down the Server” earlier in this chapter.
2. Remove the server cover. See “Server Cover” earlier in this chapter.
3. Remove the diskette drive. See “Diskette Drive” earlier in this chapter.
4. Disconnect the CD-ROM cable from the CD-ROM drive ❶.
5. Remove the retaining screw securing the CD-ROM drive to the chassis ❷.
6. Pull the CD-ROM drive from the drive cage ❸.




Figure 2-15. Removing the low-profile IDE CD-ROM drive

Reverse steps 1 through 6 to replace the low-profile IDE CD-ROM drive.

## Removable Media Blank

Devices that can be installed in the removable media drive include an additional CD-ROM drive, a SCSI hard drive cage, and SLR, DAT, or DLT tape drives.

To remove a removable media blank:

1. Complete the preparation procedures. See “Powering Down the Server” earlier in this chapter.
2. Remove the server cover. See “Server Cover” earlier in this chapter.
3. Remove the diskette drive. See “Diskette Drive” earlier in this chapter.
4. Remove the T-15 Torx screw securing the removable media blank to the chassis ❶.
5. Slide the removable media blank out of the server ❷.




Figure 2-16. Removing the removable media blank

Reverse steps 1 through 5 to replace the removable media blank.

## Optional 2x1-Inch Media Device Drive Cage

To remove the 2x1-inch media device drive cage:

1. Complete the preparation procedures. See “Powering Down the Server” earlier in this chapter.
2. Remove the server cover. See “Server Cover” earlier in this chapter.
3. Remove the diskette drive. See “Diskette Drive” earlier in this chapter.
4. Disconnect the power, SCSI, and signal cables.
5. Remove the T-15 screw from the side of the 2x1-inch drive cage ❶.
6. Slide the 2x1-inch drive cage out of the chassis ❷.




Figure 2-17. Removing an optional 2x1-inch media device drive cage

Reverse steps 1 through 6 to replace the optional 2x1-inch media device drive cage.



## Cable Routing Diagrams



**CAUTION:** When routing cables, always ensure that the cables are not in a position where they will be pinched or crimped.

### Diskette Drive Signal Cable




Figure 2-18. Diskette drive signal cable routing

### Low-Profile CD-ROM Drive Signal Cable




Figure 2-19. Low-profile CD-ROM drive signal cable routing

### Hot-Plug Hard Drive Cage Cables




Figure 2-20. Hot-plug hard drive cage cable routing

### Optional 2x1 Media Device Drive Cage Cables




Figure 2-21. Media device drive cage cable routing

## PCI Expansion Board

To remove a PCI expansion board:

1. Perform the preparation procedures. See “Powering Down the Server” earlier in this chapter.
2. Remove the server cover. See “Server Cover” earlier in this chapter.
3. Swing out the expansion board latch securing the expansion board to the riser board ❶.
4. Pull the expansion board from the chassis ❷.




Figure 2-22. Removing a PCI expansion board

**NOTE:** If the PCI expansion board is not going to be replaced, then replace the expansion slot cover to prevent damage to the expansion board slot.

**NOTE:** Expansion boards may differ from the board shown above.

Reverse steps 1 through 4 to replace a PCI expansion board.

## Riser Board and Brace

To remove the riser board and brace:

1. Complete the preparation procedures. See “Powering Down the Server” earlier in this chapter.
2. Remove the server cover. See “Server Cover” earlier in this chapter.
3. Remove all expansion boards, if any. See “PCI Expansion Board ” earlier in this chapter.
4. Loosen the two captive screws securing the riser board and brace ❶.
5. Lift the riser board and brace out of the unit ❷.




Figure 2-23. Removing the riser board and brace

**NOTE:** When replacing the riser board, ensure that the riser board is properly seated in the riser board slot before tightening the screws.

Reverse steps 1 through 5 to replace the riser board and brace.

## Memory

The following guidelines may be helpful when installing additional memory:

- The server ships standard with 128-MB Synchronous DRAM (SDRAM) Dual Inline Memory Module (DIMM) installed in DIMM slot 1.
- SDRAMs must be 133-MHz, registered, 3.3 volt, 72-bit wide, with Error Correction Code (ECC). No other DIMMs are compatible with server.
- Install SDRAM DIMM modules one at a time in the sequential order starting with DIMM slot 1.
- Install DIMMs of the same speed. Do not install DIMM modules supporting different speeds.
- Use only 64-, 128-, 256-, 512-MB, or, when available, 1-GB SDRAM DIMMs. Any combination of these SDRAM DIMMs can be used.
- Install DIMMs only in one direction. Be sure to match the notch on the module with the tab on the DIMM slot. Before seating the DIMM in the slot, ensure that the module key is fully inserted.
- Memory can be expanded to a maximum of 4-GB of memory.
- Use only Compaq SDRAM DIMMs. DIMMs from other sources may affect data integrity.

ProLiant DL380 Servers ship standard with one Synchronous DRAM (SDRAM) Dual Inline Memory Module (DIMM) installed in DIMM slot 1. Figure 2-24 and Table 2-2 show the location of the DIMM slots on the system board.




Figure 2-24. SDRAM DIMM slot locations

**Table 2-2**  
**SDRAM DIMM Slot Locations**

| Item | Description                                       |
|------|---|
| ①    | DIMM slot 1 (populated with standard 128-MB DIMM) |
| ②    | DIMM slot 2                                       |
| ③    | DIMM slot 3                                       |
| ④    | DIMM slot 4                                       |

## SDRAM DIMM



**CAUTION:** Electrostatic discharge can damage electronic components. Be sure you are properly grounded before beginning any installation procedure. Refer to “Electrostatic Discharge Information” earlier in this chapter.

To remove an SDRAM DIMM:

1. Complete the preparation procedures. See “Powering Down the Server” earlier in this chapter.
2. Remove the server cover. See “Server Cover” earlier in this chapter.
3. Press both SDRAM DIMM slot latches outward **1**.
4. Lift out the SDRAM DIMM **2**.

**IMPORTANT:** A memory module can be installed only one way. Be sure to match the key slots on the module with the tabs on the memory slot. Push the module down into the slot, ensuring that the module is fully inserted and properly seated.




Figure 2-25. Removing an SDRAM DIMM

Reverse steps 1 through 4 to replace an SDRAM DIMM.

## Processor and Processor Power Module

ProLiant DL380 Servers can support up to two processors. When two processors are used, they operate in an associated mode. Figure 2-26 and Table 2-3 show the location of the processor(s) and Processor Power Module(s) on the system board.




Figure 2-26. Processor and Processor Power Module locations

**Table 2-3**  
**Processor and Processor Power Module Locations**

| Item | Description                               |
|------|---|
| ①    | Processor Power Module slot 1 (populated) |
| ②    | Processor slot 1 (populated)              |
| ③    | Processor Power Module slot 2             |
| ④    | Processor slot 2                          |

**Note:** Individual heat sinks may vary from the heat sink shown above.



## Processor



**CAUTION:** Electrostatic discharge can damage electronic components. Be sure you are properly grounded before beginning any installation procedure. Refer to “Electrostatic Discharge Information” earlier in this chapter.

To remove a processor:

1. Complete the preparation procedures. See “Powering Down the Server” earlier in this chapter.
2. Remove the server cover. See “Server Cover” earlier in this chapter.
3. Push out the tabs on the processor retaining posts ❶.
4. While pulling the latches outward, lift out the processor ❷.




Figure 2-27. Removing the processor

To replace the processor, push in on the tabs located at each side of the processor until they click twice. Then reverse steps 1 through 4. Use the System Configuration Utility to reconfigure your system if you are replacing a faulty processor. See Chapter 3, “Diagnostics and Troubleshooting,” for more information.

**IMPORTANT:** The processor is keyed to ensure correct alignment. Align the pattern of pins in the processor with the pattern of holes in the slot. The pins and holes will not line up if the processor is misaligned.

## Processor Power Module



**WARNING:** To reduce the risk of personal injury from hot surfaces, allow the internal system components to cool before touching them.

Every processor comes with a Processor Power Module (DC-to-DC converter) that provides power for the processor.

To remove a Processor Power Module (PPM):

1. Complete the preparation procedures. See “Powering Down the Server” earlier in this chapter.
2. Remove the server cover. See “Server Cover” earlier in this chapter.
3. Press the latches on the slot outward until the latches snap open ❶.
4. Pull the module out of the slot ❷.




Figure 2-28. Removing a Processor Power Module

Reverse steps 1 through 4 to install a Processor Power Module. The module is keyed to ensure correct alignment. Use the System Configuration Utility to reconfigure the server. See Chapter 3, “Diagnostics and Troubleshooting,” for more information.

## CPU Fan

To remove the CPU fan:

1. Complete the preparation procedures. See “Powering Down the Server” earlier in this chapter.
2. Remove the server cover. See “Server Cover” earlier in this chapter.
3. Remove the processor(s) from the processor retaining posts. See “Processor” earlier in this chapter.
4. Remove the two processor retaining posts closest to the CPU fan.
5. Remove the four screws **1** securing the fan assembly to the chassis.
6. Unplug the CPU fan assembly from the system board **2**.
7. Remove the CPU fan from the back of the chassis **3**.




Figure 2-29. Removing the CPU fan

Reverse steps 1 through 7 to replace the CPU fan.

## Integrated Smart Array Controller

The Integrated Smart Array Controller supports the following features:

- 16-MB total memory, 8-MB read-ahead cache
- 32-bit PCI bus master interface
- RAID 0, 0+1, 1, and 5 disk fault tolerance
- Support for up to four internal SCSI hot-plug hard drives
- Support for up to six internal SCSI hot-plug hard drives with optional 2x1-inch drive cage
- Migration from any RAID level to any RAID level
- Migration from any stripe size to any stripe size
- Online capacity expansion
- Online spares

**NOTE:** See the Integrated Smart Array Controller documentation for a more detailed description of the Integrated Smart Array Controller.



**WARNING:** To reduce the risk of personal injury from hot surfaces, allow the internal system components to cool before touching.

To remove the Integrated Smart Array Controller:

1. Complete the preparation procedures. See “Powering Down the Server” earlier in this chapter.
2. Remove the server cover. See “Server Cover” earlier in this chapter.
3. Pull the latches outward ❶.
4. When the Integrated Smart Array Controller rises to a 45-degree angle, pull the controller out of the slot ❷.




Figure 2-30. Removing the Integrated Smart Array Controller from the system board

**NOTE:** For instructions on installing the Integrated Smart Array Controller, refer to Chapter 4 of the *ProLiant DL380 Set-Up and Installation Guide*, or the instructions provided in the Integrated Smart Array Controller option kit.

## System Board

To remove the system board:

1. Complete the preparation procedures. See “Powering Down the Server” earlier in this chapter.
2. Remove the server cover. See “Server Cover” earlier in this chapter.
3. Remove all expansion boards. See “PCI Expansion Board” earlier in this chapter.
4. Remove the riser board and brace. See “Riser Board and Brace” earlier in this chapter.
5. Disconnect all internal and external cables, including all power supply cables. See “Cable Routing Diagrams” earlier in this chapter.
6. Remove any SDRAM DIMMs. See “Memory” earlier in this chapter.
7. Remove the processor(s). See “Processor” earlier in this chapter.
8. Remove the Processor Power Module(s). See “Processor Power Module” earlier in this chapter.
9. Remove the CPU fan. See “CPU Fan” earlier in this chapter.
10. Remove the Integrated Smart Array Controller. See “Integrated Smart Array Controller” earlier in this chapter.
11. Remove the one thumbscrew securing the system board to the chassis ❶.
12. Slide the system board toward the front of the chassis 1.5 cm (.5 inch). Then, lift the system board up off of the five alignment keys.
13. Remove the system board from the chassis ❷.




Figure 2-31. Removing the system board

Reverse steps 1 through 13 to replace the system board.

## System Board Battery

If the server no longer automatically displays the correct date and time, you may need to replace the battery that provides power to the real-time clock. Under normal use, battery life is 5 to 10 years.




**WARNING:** This server contains either an internal lithium manganese dioxide, or a vanadium pentoxide battery. There is risk of fire and burns if the battery pack is not handled properly. To reduce the risk of personal injury:

- Do not attempt to recharge the battery.
  - Do not expose to temperatures higher than 60°C.
  - Do not disassemble, crush, puncture, short external contacts, or dispose of in fire or water.
  - Replace only with the spare designated for this product.
- 



**CAUTION:** Loss of BIOS settings will occur if the lithium battery is removed. BIOS settings must be reconfigured whenever the battery is replaced.

---



**CAUTION:** Batteries, battery packs, and accumulators should not be disposed of together with general household waste. In order to forward them to recycling or proper disposal, please use the public collection system or return them to, your authorized Partners, or their agents.

---

**IMPORTANT:** Run the System Utility to configure the system after replacing the battery. See Chapter 3, “Diagnostics and Troubleshooting,” for more information.

---

To replace the system board battery:

1. Complete the preparation procedures. See “Powering Down the Server” earlier in this chapter.
2. Remove the server cover. See “Server Cover” earlier in this chapter.
3. Locate the battery on the system board ❶. Pull the battery sideways to remove it from the system board.
4. Install the new battery.
5. Run the System Configuration Utility to reconfigure the system. See Chapter 3, “Diagnostics and Troubleshooting,” for more information about reconfiguring the system.




Figure 2-32. Removing a system board battery



# *Chapter* **3**

## **Diagnostics and Troubleshooting**

This chapter describes software and firmware diagnostic tools available for all Compaq server products. The sections in this chapter are:

- Diagnostic Tools Utility Overview
- Default Configuration
- Utilities Access
- Power-On Self-Test (POST)
- Diagnostics Software
- Array Diagnostic Utility (ADU)
- Integrated Management Log
- Rapid Error Recovery
- Remote Service Features
- ROMPaq Error Recovery Options
- Compaq Insight Manager

## Diagnostic Tools Utility Overview

These utilities were developed to assist in diagnosing problems, testing the hardware, and monitoring and managing Compaq server hardware.

**Table 3-1**  
**Diagnostic Tools**

| Tool                       | What it is  | How to run it   |
|----------------------------|---|---|
| Compaq Diagnostics Program | Utility to assist testing and/or verifying operation of Compaq hardware. If problems are found, Compaq Diagnostics isolates failure(s) down to replaceable parts, whenever possible.  | Diagnostics and utilities are located on Compaq system partition on hard drive and must be accessed when a system configuration error is detected during Power-On Self-Test (POST). Compaq Diagnostics software is also available on the Compaq SmartStart and Support Software CD. A diagnostics diskette can be created from SmartStart and Support Software CD, and Diagnostics run from diskette. |
| Compaq Inspect Utility     | The Inspect utility provides a report detailing system information.   | The Inspect utility can be run from either the main menu of the System Configuration Utility or the Compaq Diagnostics Program.   |
| Compaq Insight Manager     | A client/server application used to remotely manage Compaq hardware in a network environment. Reports hardware fault conditions (both failure and prefailure) and collects data for reporting and graphing.   | For more information, refer to the Compaq Management CD and the <i>Compaq Insight Manager User Guide</i> .<br><br>More information on viewing and printing the event list can be found in the Compaq Insight Manager section of this chapter.   |
| Compaq Survey Utility      | An online information gathering agent that runs on servers, gathering critical hardware and software information from various sources. A utility for servers running Windows NT or NetWare.<br><br>If a significant change occurs between data-gathering intervals, previous information is marked, and the <i>survey text file</i> is overwritten to reflect the latest configuration and changes since last configuration. This allows a historical record of change events for server hardware and software. | Install Survey from SmartStart, Compaq Integration Maintenance Utility, or from Compaq Management CD.   |

*continued*

**Table 3-1**  
**Diagnostic Tools** *continued*

| Tool                                    | What it is   | How to run it  |
|---|--|--|
| Array Diagnostics Utility (ADU)         | <p>A Windows-based tool designed to run on all Compaq systems that support Compaq array controllers. Two main functions of ADU are to collect all possible information about the array controllers in the system, and generate a list of detected problems.</p> <p>This tool is available for all Compaq servers covered by this guide.</p>  | Use the information provided in Array Diagnostics Utility (ADU) later in this chapter.   |
| Drive Array Advanced Diagnostics (DAAD) | <p>The predecessor to ADU, DAAD is a DOS-based tool for Compaq servers with Smart Array Controllers. DAAD collects information about the array controllers in the system and offers a list of detected problems.</p>   | <p>For a list of Compaq servers still supported by this tool, visit the Compaq website:</p> <p><a href="http://www.compaq.com">http://www.compaq.com</a></p>   |
| Integrated Management Log               | <p>A log of system events, such as system failures or nonfatal error conditions. View events in the Integrated Management Log:</p> <ul style="list-style-type: none"> <li>■ On the Integrated Management Display</li> <li>■ From within Compaq Insight Manager</li> <li>■ From within Compaq Survey Utility</li> </ul>   | <p>The Integrated Management Log requires Compaq operating system-dependent drivers. Refer to Compaq Support Software CD for instructions on installing the appropriate drivers.</p>   |
| System Configuration Utility            | <p>Utility to easily configure the hardware installed in or connected to the server. Specifically, it can:</p> <ul style="list-style-type: none"> <li>■ Resolve resource conflicts in areas such as memory, port addresses, and interrupts (IRQs)</li> <li>■ Configure PCI boards automatically</li> <li>■ Provide switch and jumper settings</li> <li>■ Manage installation of memory, processor upgrades, and mass storage devices such as hard drives, tape drives, and diskette drives</li> <li>■ Store configuration information in nonvolatile memory</li> <li>■ Assist in installation of an operating system</li> <li>■ Assist in running diagnostic tools such as TEST and INSPECT</li> </ul> | <p>If the server has bootable CD-ROM drive, run Compaq System Configuration Utility directly from Support Software CD supplied with SMART Controller Option Kit, or SmartStart and Support Software CD supplied with server. Use the CD supplied for latest version supporting SMART Controller.</p> <p>If the server does not have a bootable CD-ROM drive, create diskettes with latest version of the System Configuration Utility from Support Software CD, or SmartStart and Support Software CD.</p> |

## Default Configuration

When the system is first turned on, the system ROM detects the unconfigured state of the hardware and provides default configuration settings for most devices. By providing this initialization, the system can run Diagnostics and other software applications before running the normal SmartStart and System Configuration programs.

## Default Configuration Messages

---

**IMPORTANT:** If you chose to format and partition the boot drive before running SmartStart and the System Configuration programs, this may prohibit creating a Compaq system partition and the off-line remote management features that it provides.

---

If you insert a System Configuration, Diagnostics, or SmartStart and Support Software CD into the CD-ROM drive prior to powering on the Server, the system ROM boots to that utility. If the system ROM does not detect one of those CDs, you will be prompted for the intended operating system. The system reboots if any operating system-dependent configurations have changed with the new operating system selection. If the selected operating system-dependent configurations are the same as the current configurations, the system starts normally. If you enter a wrong choice, on subsequent restarts you may change the operating system.

## Inspect Utility

The Inspect Utility provides configuration information such as the contents of the operating system startup files, the current memory configuration, the ROM version, and Integrated Management Log information. It operates with MS-DOS emulation mode of OS/2.

### Running the Inspect Utility

1. Turn the server off, then back on, then press **F10** when the cursor appears in the upper right corner of the screen.
2. At the main menu, select Diagnostics and Utilities.
3. Press **Enter**.
4. Select Inspect Computer and press **Enter**.

**NOTE:** If Diagnostics is not installed on the hard drive, System Configuration prompts you to insert the Diagnostics diskette in drive A.

5. Follow the instructions.

### Printing the Inspect Listing

Select Print on the Inspect screen to print a copy of the Inspect listing. Keep a copy of the listing with each server for later reference.

## Utilities Access

The Compaq SmartStart and Support Software CD contains the SmartStart program and many of the Compaq utilities needed to maintain the system, including:

- System Configuration Utility
- Array Configuration Utility
- Array Diagnostic Utility
- ROMPaq Firmware Upgrade Utilities
- Compaq Diagnostics



**CAUTION:** Do not select the Erase Utility when running the SmartStart and Support Software CD. This will result in data loss to the entire system.

---

## Running Compaq Utilities

There are three ways to access Compaq utilities:

### Running the Utilities on the Compaq System Partition

If the system was installed using SmartStart, the Compaq utilities will automatically be available on the Compaq system partition. The Compaq system partition could also have been created during a manual system installation.

To run the utilities on the Compaq system partition, start the system and press **F10** when you see:

Press F10 for Compaq system partition utilities.

Then select the desired utility from the menu:

- The System Configuration Utility is available under the System Configuration menu.
- The Array Configuration Utility is available under the System Configuration menu.
- Compaq Diagnostics (Test and Inspect) are available under the Diagnostics and Utilities menu.
- The ROMPaq Firmware Upgrade Utility is available under the Diagnostics and Utilities menu.

### Running the Utilities from Diskette

- Run the utilities from their individual diskettes. If you have a utility diskette newer than the version on the SmartStart and Support Software CD, use that diskette.
- Create a diskette version of the utility from the SmartStart and Support Software CD.

To create diskette versions of the utilities from the CD:

1. Start the Compaq SmartStart and Support Software CD.
2. From the Compaq System Utilities screen, select Create Support Software Disks, then Next.
3. Select the diskette you would like to create from the list, then follow the instructions on the screen.

### Running the Utilities from the Compaq SmartStart and Support Software CD

---

**IMPORTANT:** Only the System Configuration Utility and the Array Configuration Utility and the Array Diagnostic Utility can be executed from the Compaq SmartStart and Support Software CD. All other utilities must be executed from the Compaq system partition or from the diskette.

---

To run these utilities directly from the Compaq SmartStart and Support Software CD:

1. Start the Compaq SmartStart and Support Software CD.
2. From the Compaq System Utilities screen, select the utility you wish to run, then select Next.
  - To execute the System Configuration Utility, select Run System Configuration Utility.
  - To execute the Array Configuration Utility, select Run Array Configuration Utility.
  - To execute the Array Diagnostic Utility, select Run Array Diagnostic Utility.

## Power-On Self-Test (POST)

POST is a series of diagnostic tests that run automatically on Compaq computers when the system is turned on. POST checks the following assemblies to ensure that the computer system is functioning properly:

- System ROM
- Keyboard
- Power supply
- System board
- Memory
- Memory expansion boards
- Controllers
- Diskette drives
- Hard drives
- Processor Power Modules
- Fans

### POST Error Messages

If POST finds an error in the system, an error condition is indicated by an audible and/or visual message. If an error code displays on the screen during POST or after resetting the system, use the instructions in the POST Error Messages table.

**NOTE:** Many of the actions listed require you to run Diagnostics or the Compaq System Configuration Utility. Steps for running these utilities are provided following the POST Error Messages tables.

The Recommended Action column lists the steps necessary to correct the problem. After completing each step, run the Diagnostics program to verify whether the error condition has been corrected. If the error code reappears, perform the next step, then run the Diagnostics program again. Follow this procedure until Diagnostics no longer detects an error condition.

**Table 3-2**  
**POST Error Messages**

| <b>Error Code</b>  | <b>Audible Beeps</b> | <b>Probable Source of Problem</b>   | <b>Recommended Action</b>   |
|--|----------------------|---|---|
| A Critical Error occurred prior to this power-up           | None                 | A catastrophic system error, which caused the server to crash, has been logged. | Run Diagnostics. Replace failed assembly as indicated.  |
| Unsupported Processor Detected System Halted               | 1 long, 1 short      | Processor not supported by current system ROM.                                  | Check documentation for supported processors, and if supported, remove the processor and update the system to latest ROM. |
| FATAL ROM ERROR: The System ROM is not properly programmed | 1 long, 1 short      | ROM programmed in factory incorrectly.  | Replace the physical ROM part.  |
| 101-ROM Error  | 1 long, 1 short      | System ROM checksum   | Run Diagnostics. Replace failed assembly as indicated.  |
| 101-I/O ROM Error  | None                 | Options ROM checksum  | Run Diagnostics. Replace failed assembly as indicated.  |
| 102-System Board Failure                                   | None                 | DMA, timers, and so on  | Replace the system board. Run the Compaq System Configuration Utility.  |
| 104-ASR-2 Timer Failure                                    | None                 | System board failure  | Run Diagnostics. Replace failed assembly as indicated.  |
| 162-System Options Not Set                                 | 2 short              | Configuration incorrect   | Run the System Configuration Utility and correct.   |
| 163-Time & Date Not Set                                    | 2 short              | Invalid time or date in configuration memory                                    | Run the System Configuration Utility and correct.   |
| 172-Configuration Nonvolatile Memory Invalid               | None                 | Nonvolatile configuration corrupt or jumper installed                           | Run the System Configuration Utility and correct.   |
| 177-Configuration Not Complete                             | None                 | Incomplete system configuration   | Run the System Configuration Utility and correct.   |

*continued*



**Table 3-2**  
**POST Error Messages** *continued*

| Error Code  | Audible Beeps   | Probable Source of Problem   | Recommended Action  |
|---|-----------------|--|---|
| 178-Processor Configuration Invalid                               | None            | Processor type or step does not match configuration memory.  | Run the System Configuration Utility and correct.   |
| 180-Log Reinitialized   | None            | N/A  | N/A   |
| 201-Memory Error  | None            | RAM failure  | Run Diagnostics. Replace failed assembly as indicated.  |
| 203-Memory Address Error  | None            | RAM failure  | Run Diagnostics. Replace failed assembly as indicated.  |
| 207-Invalid Memory Configuration - Check DIMM [SIMM] Installation | None            | Memory module installed incorrectly.   | Verify placement of memory modules.   |
| 208-Invalid Memory Speed - Check DIMM [SIMM] Installation         | 1 long, 1 short | The speed of the memory is too slow: <ul style="list-style-type: none"> <li>■ xx00 = expansion board SIMMs are too slow</li> <li>■ 00yy = system board SIMMs are too slow.</li> <li>■ xx and yy have a corresponding bit set.</li> </ul> | The speed of the memory modules must be 60 ns. Verify the speed of the memory modules installed and replace if slower than 60 ns. |
| 209-Memory Detection Failure. Check Memory Installation           | 1 long, 1 short | Unable to size memory  | Check DIMM installation and if error persists, call Compaq service provider.  |
| 211-Cache Switch Set Incorrectly                                  | None            | Switch not set properly during installation or upgrade.  | Verify switch settings.   |
| 212-System Processor Failed/ Mapped out                           | 1 short         | Processor in slot x failed.  | Run Diagnostics and replace failed processor.   |
| 214-DC-DC Converter Failed  | None            | PowerSafe Module (DC-DC Converter) failed.   | Run Diagnostics. Replace failed assembly as indicated.  |
| 214-Processor PPM Failed Module X                                 | None            | Indicated PPM (DC-DC Converter) failed.  | Replace failed assembly as indicated.   |

*continued*

**Table 3-2**  
**POST Error Messages** *continued*

| <b>Error Code</b>  | <b>Audible Beeps</b> | <b>Probable Source of Problem</b>                         | <b>Recommended Action</b>  |
|--|----------------------|---|--|
| 215-Processor Power Module has lost Redundancy in Socket x         | None                 | PPM (DC-DC Converter) has lost redundancy.                | Run Diagnostics. Replace failed assembly as indicated.   |
| 215-Nonfunctioning Voltage Regulator Module for Processors         | None                 | PPM (DC-DC Converter) has failed or lost redundancy.      | Run Diagnostics. Replace failed assembly as indicated.   |
| 216-Voltage Regulator Module for Processor X no longer redundant   | None                 | Redundancy failed in PPM.                                 | To restore redundancy, replace the PPM.  |
| 216-Processor PPM has lost Redundancy, Module X                    | None                 | Indicated PPM (DC-DC Converter) has lost redundancy.      | Replace failed assembly as indicated.  |
| 218-Cache Accelerators Not Installed. System Halted.               | None                 | Cache Accelerators not installed or improperly installed. | Check Cache Accelerator installation.  |
| 219-Tag Update Rules SRAM Failure. System Halted                   | None                 | Catastrophic chipset failure.                             | Call Compaq service provider.  |
| 219-Snoop Rules SRAM Failure. System Halted.                       | None                 | Catastrophic chipset failure.                             | Call Compaq service provider.  |
| 220-Cache Accelerator Slot x Initialization Failed. System Halted. | None                 | Cache Accelerator in slot x improperly installed or bad.  | Check Cache Accelerator installation and if properly installed, replace.   |
| 221-Power Fault On Processor Bus X                                 | None                 | A PPM on indicated bus is in a failed state.              | Run Diagnostics. Replace failed assembly as indicated.   |
| 301-Keyboard Error   | None                 | Keyboard failure  | Turn off the computer, then reconnect the keyboard.  |
| 301-Keyboard Error or Test Fixture Installed                       | None                 | Keyboard failure  | Replace the keyboard.  |
| ZZ-301-Keyboard Error  | None                 | Keyboard failure. (ZZ represents the Keyboard Scan Code.) | <ol style="list-style-type: none"> <li>1. A key is stuck. Try to free it.</li> <li>2. Replace the keyboard.</li> </ol> |

*continued*

**Table 3-2**  
**POST Error Messages** *continued*

| <b>Error Code</b>   | <b>Audible Beeps</b> | <b>Probable Source of Problem</b>   | <b>Recommended Action</b>   |
|---|----------------------|---|---|
| 303-Keyboard Controller Error                                   | None                 | System board, keyboard, or mouse controller failure                         | <ol style="list-style-type: none"> <li>1. Run Diagnostics.</li> <li>2. Replace failed assembly as indicated.</li> </ol>   |
| 304-Keyboard or System Unit Error                               | None                 | Keyboard, keyboard cable, or system board failure                           | <ol style="list-style-type: none"> <li>1. Make sure the keyboard is attached.</li> <li>2. Run Diagnostics to determine which is in error.</li> <li>3. Replace the part indicated.</li> </ol>      |
| 40X-Parallel Port X Address Assignment Conflict                 | 2 short              | Both external and internal ports are assigned to parallel port X.           | Run the System Configuration Utility and correct.   |
| 601-Diskette Controller Error                                   | None                 | Diskette controller circuitry failure                                       | <ol style="list-style-type: none"> <li>1. Make sure the diskette drive cables are attached.</li> <li>2. Replace the diskette drive and/or cable.</li> <li>3. Replace the system board.</li> </ol> |
| 605-Diskette Drive Type Error                                   | 2 short              | Mismatch in drive type  | Run the System Configuration Utility to set diskette type correctly.  |
| 1151-Com Port 1 Address Assignment Conflict                     | 2 short              | Both external and internal serial ports are assigned to COM1.               | Run the System Configuration Utility and correct.   |
| 1152-Com Port 2, 3, or 4 Address Assignment Conflict            | 2 short              | Both external and internal serial ports are assigned to COM2, COM3 or COM4. | Run the System Configuration Utility and correct.   |
| 1610-Temperature violation detected. Waiting for system to cool | 2 short              | Ambient system temperature too hot  | Check fan in system environment.  |
| 1611-Fan failure detected                                       | 2 short              | Required fan not installed or spinning.                                     | Check fans.   |
| 1611-I/O Fan (Fan X) failure detected                           | 2 short              | I/O fan has failed.   | Replace the failed fan.   |

*continued*

**Table 3-2**  
**POST Error Messages** *continued*

| <b>Error Code</b>  | <b>Audible Beeps</b> | <b>Probable Source of Problem</b>                                      | <b>Recommended Action</b>   |
|--|----------------------|--|---|
| 1611-CPU Fan (Fan X) failure detected  | 2 short              | CPU fan has failed.  | Replace the failed fan.   |
| 1612-Primary power supply failure  | 2 short              | Primary power supply has failed.                                       | Replace power supply as soon as possible.                                 |
| 1613-Low System Battery  | None                 | Real time clock system battery is running low on power.                | Run Diagnostics. Replace failed assembly as indicated.                    |
| 1615-Power Supply Failure, Power Supply Unplugged, or Power Supply Fan Failure in Bay X                    | None                 | A power supply has failed.   | Replace or check specified power supply.                                  |
| 1617-Fan controller not responding   | 2 short              | Fan controller failure   | Check and replace failed controller assembly.                             |
| 1617-I/O Fan controller not responding   | 2 short              | I/O fan controller failure   | Check and replace failed controller assembly.                             |
| 1617-CPU Fan controller not responding   | 2 short              | CPU fan controller failure   | Check and replace failed controller assembly.                             |
| 1618-PCI slots powered down. Check PCI hot plug enabler connectors.  | None                 | PCI hot plug enabler is missing or failed.                             | Check and replace missing or failed assembly.                             |
| 1620-Locked SCSI Bus Detected. Verify SCSI bus cabling. System halted.                                     | None                 | SCSI bus failure   | Run Diagnostics. Replace failed assembly as indicated.                    |
| 1621-Current SCSI bus cable configuration is not recommended   | None                 | Improper SCSI bus cabling  | Check documentation for proper SCSI bus cabling.                          |
| 1622-Internal SCSI Jumper Board Not Installed  | None                 | The system has detected that the array enabler board is not installed. | Install the array enabler board.  |
| 1703-SCSI cable error detected. Internal SCSI cable not attached to system board connector. System halted. | None                 | Incorrect cabling  | Ensure that the integrated SCSI controller has SCSI termination attached. |

*continued*

**Table 3-2**  
**POST Error Messages** *continued*

| Error Code   | Audible Beeps | Probable Source of Problem  | Recommended Action  |
|--|---------------|---|---|
| 1720-Slot x Drive Array – SMART Drive Detects Imminent Failure SCSI: Port y: SCSI ID x   | None          | Indicated drive has reported a SMART predictive-failure condition and may fail at some time in the future.  | If drive is part of a nonfault-tolerant configuration, back up all data before replacing drive and restore all data afterward. If drive is part of a fault-tolerant configuration <b>do not</b> replace drive unless all other drives in array are online. Press <b>F1</b> to resume. |
| 1721-Slot x Drive Array-Drive parameter tracking predicts imminent failure. The following devices should be replaced when conditions permit. Do not replace the drive unless all other drives in the array are online. Back up data before replacing drive(s) if using RAID 0. | None          | Monitor and performance threshold exceeded condition.   | Replace the drive when it is reasonable. The drive has not failed, but Compaq recommends you replace the drive.   |
| * 1724-Slot x Drive Array – Physical Drive Position Change(s) Detected – Logical drive configuration has automatically been updated  | None          | Logical drive configuration has been updated automatically following physical drive position changes.   | Press <b>F1</b> to resume.  |
| * 1726-Slot x Drive Array – Array Accelerator Memory Size Change Detected  | None          | Indicates array accelerator configuration has been updated automatically due to replacement of array accelerator (or controller) with one having different memory size. | Press <b>F1</b> to resume.  |

*continued*

**Table 3-2**  
**POST Error Messages** *continued*

| Error Code  | Audible Beeps | Probable Source of Problem  | Recommended Action  |
|---|---------------|---|---|
| * 1727-Slot x Drive Array – New Logical Drive(s) Attachment Detected. If more than 32 logical drives, this message will be followed by: Auto-configuration failed: Too many logical drives. | None          | Controller has detected an additional array of drives that was attached when the power was off. The logical drive configuration information has been updated to add the new logical drives. The maximum number of logical drives supported is 32. Additional logical drives will not be added to the configuration. | Press <b>F1</b> to resume.  |
| 1729-Disk consistency initialization in progress RAID 4/5 performance may be lower until Auto Reliability Monitoring has completed automatic parity consistency initialization.             | None          |   | This message is normal following the initial configuration of RAID 4 or RAID 5 logical drives. This POST message will go away and performance of the controller will improve after the parity data has been initialized by ARM (an automatic process that runs in the back ground on the controller.) |
| 1730-Fixed Disk 0 does not support DMA Mode.  | None          | Hard drive error  | Run the System Configuration Utility and correct.   |
| 1731-Fixed Disk 1 does not support DMA Mode.  | None          | Hard drive error  | Run the System Configuration Utility and correct.   |
| 1740-Fixed Disk 0 failed Set Block Mode command   | None          | Hard drive error  | Run the System Configuration Utility and correct.   |
| 1741-Fixed Disk 1 failed Set Block Mode command   | None          | Hard drive error  | Run the System Configuration Utility and correct.   |
| 1750-Fixed Disk 0 failed Identify command   | None          | Hard drive error  | Run the System Configuration Utility and correct.   |
| 1751-Fixed Disk 1 failed Identify command   | None          | Hard drive error  | Run the System Configuration Utility and correct.   |
| 1760-Fixed Disk 0 does not support Block Mode   | None          | Hard drive error  | Run the System Configuration Utility and correct.   |
| 1761-Fixed Disk 1 does not support Block Mode   | None          | Hard drive error  | Run the System Configuration Utility and correct.   |

*continued*

**Table 3-2**  
**POST Error Messages** *continued*

| Error Code  | Audible Beeps | Probable Source of Problem  | Recommended Action   |
|---|---------------|---|--|
| 1764-Slot x Drive Array - Capacity Expansion Process is temporarily disabled (followed by one of the following):<br><ul style="list-style-type: none"> <li>■ Expansion will resume when Array Accelerator has been reattached.</li> <li>■ Expansion will resume when Array Accelerator has been replaced.</li> <li>■ Expansion will resume when Array Accelerator RAM allocation is successful.</li> <li>■ Expansion will resume when Array Accelerator battery reaches full charge.</li> <li>■ Expansion will resume when automatic data recovery has been completed.</li> </ul> |               |   | Reattach or replace array accelerator, wait until the array accelerator batteries have charged, or for Automatic Data Recovery to complete, as indicated.  |
| 1767-Slot x Drive Array Option ROM is Not Programmed Correctly or may Conflict with the Memory Address Range of an ISA Card. Check the Memory Address Configuration of installed ISA Card(s) or run Options ROMPaq Utility to attempt SMART-2/E Option ROM Reprogramming.   |               |   | Remove or reconfigure conflicting ISA cards, especially any cards that are not recognized by the System Configuration Utility. Try reprogramming the ROM on the SMART-2/E Controller using the latest Options ROMPaq (version 2.29 or higher). |
| 1768-Slot x Drive Array-Resuming logical drive expansion process.   | None          | SMART-2 Controller error  | No action required. Appears whenever a controller reset or power cycle occurs while array expansion is in progress.  |
| 1769-Slot x Drive Array - Drive(s) disabled due to failure during expand. Select F1 to continue with logical drives disabled. Select F2 to accept data loss and to re-enable logical drives.  | None          | SMART-2 Controller error. Data has been lost while expanding the array; therefore, the drives have been temporarily disabled. | Press <b>F2</b> to accept the data loss and re-enable the logical drives. Restore data from backup.  |
| 1770-Slot x drive array critical drive firmware problem detected. Please upgrade firmware on the following drive(s) using Options ROMPaq (available from <a href="http://www.compaq.com">www.compaq.com</a> ); SCSI port (y) SCSI ID (x)<br><br>(RESUME=F1 or F2 KEY)   | None          | Needs firmware update   | The indicated drives are running firmware that is known to cause intermittent problems. Please use the Compaq Options ROMPaq utility to upgrade firmware on all drives to the latest revision. Press <b>F1</b> or <b>F2</b> to resume.         |

*continued*

**Table 3-2**  
**POST Error Messages** *continued*

| Error Code  | Audible Beeps | Probable Source of Problem  | Recommended Action   |
|---|---------------|---|--|
| 1771-Primary Disk Port Address Assignment Conflict  | None          | Internal and external hard drive controllers are both assigned to the primary address.                                | Run the System Configuration Utility and correct.  |
| 1771-Primary Disk Port Address Assignment Conflict  | None          | Internal and external hard drive controllers are both assigned to the primary address.                                | Run the System Configuration Utility and correct.  |
| 1772-Secondary Disk Port Address Assignment Conflict  | None          | Address Assignment Conflict. Internal and external hard drive controllers are both assigned to the secondary address. | Run the System Configuration Utility and correct.  |
| 1773-Primary Fixed Disk Port Assignment Conflict  | None          | Fixed disk drive error  | Run the System Configuration Utility and correct.  |
| 1774-Slot x Drive Array - Obsolete data found in Array Accelerator. Select F1 to discard contents of Array Accelerator. Select F2 to write contents of Array Accelerator to drives.   | None          | SMART-2 Controller error  | Data found in array accelerator is older than data found on drives. Press <b>F1</b> to discard the older data in the array accelerator and retain the newer data on the drives.  |
| 1775-Slot x Drive Array - ProLiant Storage System Not Responding SCSI Port (y): Check storage system power switch and cables. Turn the system power off while checking the ProLiant power and cable connections, then turn the system power back on to retry. | None          | Storage system problem  | Turn off power to system. Check external ProLiant power switch – external drives must all be powered up before or at the same time as the main system. Check cables. If retry does not help, try replacing the cable, ProLiant firmware, ProLiant backplane, or the Smart Array Controller.<br><br>Press <b>F1</b> to resume.  |
| 1776-Slot x Drive Array- SCSI Bus Termination Error-internal and external drive cannot both be attached to the same SCSI port. SCSI port (y). Check cables.   | None          | External and internal SCSI drives are both configured Port 1.   | The internal and external connectors of the specified SCSI port(s) are both attached to drives. The SCSI bus is not properly terminated when internal and external drives are attached concurrently to the SCSI bus. The indicated SCSI bus is disabled until this problem is resolved. Turn off the server power and check the cabling to the specified SCSI port. Press <b>F1</b> to resume. |

*continued*



**Table 3-2**  
**POST Error Messages** *continued*

| Error Code  | Audible Beeps | Probable Source of Problem   | Recommended Action   |
|---|---------------|--|--|
| 1777-Slot x Drive Array ProLiant drive storage enclosure problem detected (followed by one or more of the following )<br>SCSI Port (y) Colling fan malfunction detected<br>SCSI port (y) Overheated condition detected<br>SCSI port (y) Side panel must be closed to prevent overheating<br>SCSI port (y) Redundant power supply malfunction detected.<br>SCSI port (y) Wide SCSI transfer failed<br>SCSI port (y) Interrupt signal inoperative | None          | Cooling fan failure, internal temperature alert or open side panel   | Check cooling fan operation by placing hand over fan. Check internal plenum cooling fan in tower servers or storage systems. If fan is not operating, check for obstructions and check all internal connectors. Replace unit side panel if removed.<br><br>If the ProLiant Storage System power LED is amber instead of green this indicates a redundant power supply failure.<br><br>Check SCSI cables. If the message indicates that the SCSI cables should be checked, please verify the cabling with the diagrams in the Integrated Smart Array Controller Installation Guide. If the routing is correct, replace the cables on the specified port until the POST message is eliminated.<br><br>Press <b>F1</b> to resume. |
| 1778-Drive Array resuming Automatic Data Recovery process   | None          | This message appears whenever a controller reset or power cycle occurs while Automatic Data Recovery is in progress. | No action necessary.   |
| 1779-Drive Array Controller detects replacement drives<br>Port (y) SCSI ID (x); Restore data from backup if replacement drive x has been installed.   | None          | Intermittent drive failure and/or possible loss of data.   | If this message appears and drive x has not been replaced, this indicates an intermittent drive failure. This message also appears once immediately following drive replacement whenever data must be restored from backup.  |
| 1780-Disk 0 Failure   | None          | Hard drive/format error  | Run Diagnostics. Replace failed assembly as indicated.   |

*continued*

**Table 3-2**  
**POST Error Messages** *continued*

| Error Code  | Audible Beeps | Probable Source of Problem   | Recommended Action  |
|---|---------------|--|---|
| 1781-Disk 1 Failure   | None          | Hard drive/format error  | Run Diagnostics. Replace failed assembly as indicated.  |
| 1782-Disk Controller Failure  | None          | Hard disk drive circuitry error  | Run Diagnostics. Replace failed assembly as indicated.  |
| 1783-Slot x Drive Array Controller Failure  | None          | ROM installation problem or array accelerator board problem. If this message appears immediately following a ROM installation, the ROM is defective or not installed properly. | <p>Check to see if:</p> <ul style="list-style-type: none"> <li>■ The array accelerator board is attached properly.</li> <li>■ The array controller is firmly inserted in its slot.</li> </ul> <p>If error recurs, upgrade the System ROMs. Otherwise, replace the Smart Array Controller.</p>   |
| 1784-Drive Array Drive Failure The following SCSI drive(s) should be replaced; SCSI port (y) SCSI ID (x)  | None          | Defective drive and/or cables  | Check for loose cables. Replace defective drive X and/or cable(s).  |
| 1785-Drive Array not Configured (followed by one of the following)<br><br>Run Compaq Array Configuration Utility<br><br>No drives detected.<br><br>Drive positions appear to have changed.<br><br>Drive positions appear to have changed.<br><br>Configuration information indicates drive positions beyond the capability of this controller. This may be due to drive movement from a controller that supports more drives than the current controller. | None          | Configuration error  | <p>See actions below.</p> <p>Run the Compaq Array Configuration Utility.</p> <p>Turn off the system and check the SCSI cable connections to make sure the drives are attached properly.</p> <p>Run Array Diagnostic Utility if previous positions are unknown. Then turn system power Off and move drives to their original positions.</p> <p>To avoid data loss turn system power Off and reattach drives to the original controller firmware to the version on the original controller using Option ROMPaq. Select <b>F1</b> to resume.</p> |

*continued*

**Table 3-2**  
**POST Error Messages** *continued*

| Error Code  | Audible Beeps | Probable Source of Problem  | Recommended Action   |
|---|---------------|---|--|
| <p>1786-Drive Array Recovery Needed</p> <p>The following drive(s) need Automatic Data Recovery: SCSI port 1, SCSI ID 0</p> <p>Select F1 to continue automatic data recovery to drive. Select F2 to continue without starting automatic data recovery data to drive.</p> <p>Or</p> <p>Slot 1 Drive Array Recovery needed. Automatic data recovery previously aborted. The following SCSI drive(s) need automatic data recovery; SCSI port 1; SCSI ID 0.</p> <p>Select F1 to retry Automatic Data Recovery to drive. Select F2 to continue without starting Automatic Data Recovery to drive.</p> | None          | Interim Data Recovery mode. Data has not been recovered yet.  | <p>Press <b>F1</b> to start the Automatic Data Recovery to begin. Data will automatically be restored to drive X now that the drive has been replaced or now seems to be working.</p> <p>Or</p> <p>Press <b>F2</b> and the system will continue to operate in the Interim Data Recovery mode.</p> <p>The previously aborted version of the 1786 POST message will appear if the previous rebuild attempt was aborted for any reason. Run Drive Array Advanced Diagnostics (DAAD) for more information. If the replacement drive was failed, try using another replacement drive. If rebuild was aborted due to a read error from another physical drive in the array, back up all readable data on the array. Run Diagnostics Surface Analysis to restore your data.</p> |
| <p>1787-Slot x Drive Array Operating in Interim Recovery Mode. The following SCSI drive(s) should be replaced: SCSI port (y): SCSI ID (x)</p>   | None          | Hard drive X failed or cable is loose or defective. Following a system restart, this message reminds you that drive X is defective and fault tolerance is being used. | <ol style="list-style-type: none"> <li>1. Replace drive X as soon as possible.</li> <li>2. Check loose cables.</li> <li>3. Replace defective cables.</li> </ol>  |

*continued*

**Table 3-2**  
**POST Error Messages** *continued*

| Error Code   | Audible Beeps | Probable Source of Problem   | Recommended Action  |
|--|---------------|--|---|
| <p>* 1788-Slot x drive array reports incorrect drive replacement. The following SCSI drive(s) should have been replaced: SCSI port (y), SCSI ID (x). The following SCSI drive(s) were incorrectly replaced; SCSI port (y), SCSI ID (z).</p> <p>Select F1 to continue-drive array will remain disabled.</p> <p>Select F2 to reset configuration-all data will be lost.</p>  | None          | Drives are not installed in their original positions, so the drives have been disabled. <i>See</i> note below. | <p>Reinstall the drives correctly as indicated.</p> <p>Press <b>F1</b> to restart the computer with the drive array disabled.</p> <p>-Or-</p> <p>Press <b>F2</b> to use the drives as configured and lose all the data on them.</p> |
| <p>1788-Slot x drive array reports incorrect drive replacement. The following SCSI drive(s) should have been replaced: SCSI port (y), SCSI ID (x). The following SCSI drive(s) were incorrectly replaced; SCSI port (y), SCSI ID (z).</p> <p>Select F1 to continue-drive array will remain disabled.</p> <p>Select F2 to reset configuration-all data will be lost.</p>  | None          | Drives are not installed in their original positions, so the drives have been disabled. <i>See</i> note below. | <p>Reinstall the drives correctly as indicated.</p> <p>Press <b>F1</b> to restart the computer with the drive array disabled.</p> <p>-Or-</p> <p>Press <b>F2</b> to use the drives as configured and lose all the data on them.</p> |
| <p>* The 1788 error message might display inadvertently due to a bad power cable connection to the drive or by noise on the data cable. If this message was due to a bad power cable connection, but not because of an incorrect drive replacement, repair the connection and press <b>F2</b>.</p> <p>-Or-</p> <p>If this message was not due to a bad power cable connection, and no drive replacement took place, this could indicate noise on the data cable. Check cable for proper routing.</p> <p>-Or-</p> <p>If this message is due to a defective SCSI cable, replace the cable.</p> |               |  |   |

*continued*

**Table 3-2**  
**POST Error Messages** *continued*

| Error Code  | Audible Beeps | Probable Source of Problem  | Recommended Action   |
|---|---------------|---|--|
| 1789-Slot x Drive array SCSI physical drive(s) Not Responding. Check the cables or replace the following drives: SCSI port (x), SCSI ID (x).<br><br>Select F1 to continue - drive array will remain disabled.<br><br>Select F2 to fail drive(s) that are not responding -Interim Recovery Mode will be enabled if configured for fault tolerance. | None          | Cable or hard drive failure   | <ol style="list-style-type: none"> <li>1. Check the cable connections.</li> <li>2. Replace the cables.</li> <li>3. Replace the drive. If you do not want to replace the drive now, press <b>F2</b>.</li> </ol> |
| 1790-Disk 0 Configuration Error   | None          | Hard drive error or wrong drive type  | Run the System Configuration Utility and Diagnostics and correct.  |
| 1791-Disk 1 Error   | None          | Hard drive error or wrong drive type  | Run the System Configuration Utility and Diagnostics and correct.  |
| 1792-Drive Array Reports Valid Data Found in Array Accelerator.<br><br>Data will automatically be written to drive array.   | None          | This indicates that while the system was in use, power was interrupted while data was in the array accelerator memory. Power was then restored within 8 to 10 days, and the data in the array accelerator was flushed to the drive array.       | No action necessary; no data has been lost. Perform orderly system shutdowns to avoid data remaining in the array accelerator.   |
| 1793-Drive Array - Array Accelerator Battery Depleted - Data Lost<br><br>(Error message 1794 also displays.)  | None          | This indicates that while the system was in use, power was interrupted while data was in the array accelerator memory. Array accelerator batteries failed. Power was not restored within 8 to 10 days. Data in array accelerator has been lost. | Perform orderly system shutdowns to avoid data remaining in the array accelerator.   |
| 1794-Drive Array - Array Accelerator Battery Charge Low. Array Accelerator is temporarily disabled. Array Accelerator will be re-enabled when battery reaches full charge.  | None          | This is a warning that the battery charge is below 75%. Posted-writes are disabled.   | Replace the array accelerator board if batteries do not recharge within 36 power-on hours.   |

*continued*

**Table 3-2**  
**POST Error Messages** *continued*

| Error Code  | Audible Beeps   | Probable Source of Problem  | Recommended Action  |
|---|-----------------|---|---|
| 1795-Drive Array - Array Accelerator Configuration Error.<br><br>Data does not correspond to this drive array. Array Accelerator is temporarily disabled.                                   | None            | This indicates that while the system was in use, power was interrupted while data was in the array accelerator memory.<br><br>The data stored in the array accelerator does not correspond to this drive array. | Match the array accelerator to the correct drive array, or run the System Configuration Utility to clear the data in the array accelerator.   |
| 1796-Drive Array - Array Accelerator Not Responding.<br><br>Array Accelerator is temporarily disabled.  | None            | Array accelerator is defective or has been removed.   | <ol style="list-style-type: none"> <li>1. Check that the array accelerator is properly seated.</li> <li>2. Run the System Configuration Utility to reconfigure the Compaq IDA-2 without the array accelerator.</li> </ol> |
| 1797-Drive Array - Array Accelerator Read Error Occurred.<br>Data in Array Accelerator has been lost. Array Accelerator is disabled.  | None            | Hard parity error while reading data from posted-writes memory.   | Enable array accelerator.   |
| 1798-Drive Array - Array Accelerator Write Error Occurred.<br><br>Array Accelerator is disabled.  | None            | Hard parity error while writing data to posted-writes memory.   | Enable array accelerator.   |
| 1799-Drive Array - Drive(s) Disabled due to Array Accelerator Data Loss. Select F1 to continue with logical drives disabled. Select F2 to accept data loss and to re-enable logical drives. | None            | Volume failed due to loss of data in posted-writes memory.  | Press <b>F1</b> to continue with logical drives disabled or <b>F2</b> to accept data loss and re-enable logical drive.  |
| Beeps only: 2 Long  | 2 long          | No valid memory is present in the system.   | Replace failed memory with valid memory.  |
| Beeps only: 2 Long + 2 Short  | 2 long, 2 short | Power is cycled. Temperature too hot. Processor fan not installed or spinning.  | Check fans.   |
| (Run System Configuration Utility - F10 key)  | None            | A configuration error occurred during POST.   | Press <b>F10</b> to run System Configuration Utility.   |
| (RESUME - F1 key)   | None            | As indicated to continue  | Press <b>F1</b> .   |

## Diagnostics Software

Test Error Codes Tables include all test error codes generated by Compaq products. Each code has a corresponding description and recommended action(s). Each system generates only those codes that apply to its configuration and options.

When you select Diagnostics and Utilities from the System Configuration Utility main menu, the utility prompts you to test, inspect, upgrade, and diagnose the server.

Diagnostics and Utilities are located on the Compaq system partition on the hard drive and must be accessed when a system configuration error is detected during the Power-On Self-Test (POST). Compaq Diagnostics software is also available on the Compaq SmartStart and Support Software CD. You can create a Diagnostics diskette from the SmartStart and Support Software CD and run Diagnostics from diskette. See procedure in the “Running Compaq Utilities” section earlier in this chapter.

The following options are available from the Diagnostics and Utilities menu:

- Test Computer
- Inspect Computer
- Upgrade Firmware
- Remote Utilities
- Diagnose Drive Array

Diagnostic error codes are generated when the Diagnostics software recognizes a problem. These error codes help identify possible defective subassemblies.

### Steps for Diagnostics

In each case, the Recommended Action column lists the steps necessary to correct the problem. After completing each step, run the Diagnostics utility to verify that the error condition has been corrected. If the error code reappears:

1. Perform the next step listed in the table.
2. Run the Diagnostics program again.
3. Follow this procedure until the Diagnostics program no longer detects an error condition.

## 100 – 199, Primary Processor Test Error Codes

The 100 series of diagnostic error codes identifies failures with processor and system board functions.

**Table 3-3**  
**Primary Processor Test Error Codes**

| <b>Error Code</b> | <b>Description</b>                        | <b>Recommended Action</b>   |
|-------------------|---|---|
| 101-xx            | CPU test failed.                          | Replace the processor board and retest.   |
| 103-xx            | DMA page registers test failed.           | Replace the processor board and retest.   |
| 104-xx            | Interrupt controller master test failed.  |   |
| 105-xx            | Port 61 error.                            |   |
| 106-xx            | Keyboard controller self-test failed.     |   |
| 107-xx            | CMOS RAM test failed.                     | 1. Replace the battery/clock module and retest.   |
| 108-xx            | CMOS interrupt test failed.               | 2. Replace the system board and retest.   |
| 109-xx            | CMOS clock load data test failed.         |   |
| 110-xx            | Programmable timer load data test failed. | Replace the processor board and retest.   |
| 111-xx            | Refresh detect test failed.               |   |
| 112-xx            | Speed test slow mode out of range         |   |
| 113-xx            | Protected mode test failed.               |   |
| 114-xx            | Speaker test failed.                      | 1. Verify the speaker connection and retest.<br>2. Replace the speaker and retest.<br>3. Replace the system board and retest.   |
| 116-xx            | Cache test failed.                        | Replace the system board and retest.  |
| 122-xx            | Multiprocessor dispatch test failed.      | 1. Check the system configuration and retest.<br>2. Replace the processor board and retest.   |
| 123-xx            | Interprocessor communication test failed. | 3. Replace the system board and retest.   |
| 199-xx            | Installed devices test failed.            | 1. Check the system configuration and retest.<br>2. Verify cable connections and retest.<br>3. Check switch and/or jumper settings and retest.<br>4. Run the Configuration Utility and retest.<br>5. Replace the processor board and retest.<br>6. Replace the system board and retest. |



## 200 – 299, Memory Test Error Codes

The 200 series of diagnostic error codes identifies failures with the memory subsystem.

**Table 3-4**  
**Memory Test Error Codes**

| <b>Error Code</b> | <b>Description</b>   | <b>Recommended Action</b>   |
|-------------------|--|---|
| 200-xx            | Invalid memory configuration.  | Reinsert memory modules in correct location and retest.   |
| 201-xx            | Memory machine ID test failed.   | 1. Replace the system ROM and retest.   |
| 202-xx            | Memory system ROM checksum failed.   | 2. Replace the processor board and retest.<br>3. Replace the memory expansion board and retest.   |
| 203-xx            | Memory write/read test failed.   | 1. Replace the memory module and retest.  |
| 204-xx            | Memory address test failed.  | 2. Replace the processor board and retest.  |
| 205-xx            | Walking I/O test failed.   | 3. Replace the memory expansion board and retest.   |
| 206-xx            | Increment pattern test failed.   |   |
| 207-xx            | Invalid memory configuration-check DIMM installation. DIMMs installed have 8K refresh. | Replace DIMMs.  |
| 208-xx            | Invalid memory speed detected-check DIMM installation. Slow DIMMs may cause data loss. | Replace DIMMs with timing greater than 60 ns.   |
| 209-01            | RAM long test failed.  | 1. Replace the memory module/board and retest.  |
| 209-02            | Error while saving test block.   | 2. Replace the system board and retest.   |
| 209-03            | Error while restoring test block.  | 3. Replace the memory expansion board and retest.   |
| 209-89            | ECC error during testing.  |   |
| 210-xx            | Random pattern test failed.  | 1. Replace the memory module and retest.<br>2. Replace the processor board and retest.<br>3. Replace the memory expansion board and retest. |
| 211-01            | RAND test failed.  | 1. Replace the memory module/board and retest.  |
| 211-02            | Error while saving test block.   | 2. Replace the system board and retest.   |
| 211-03            | Error while restoring test block.  |   |
| 211-04            | Insufficient memory to perform the test.   |   |
| 211-05            | Failed inverted pattern compare, but RAM was correct.                                  |   |
| 211-89            | ECC error during noise test.   |   |

*continued*

**Table 3-4**  
**Memory Test Error Codes** *continued*

| Error Code | Description                                    | Recommended Action                                    |
|------------|--|---|
| 214-01     | Data error during noise test                   | 1. Replace the memory module/board and retest.        |
| 214-89     | ECC error during testing                       | 2. Replace the system board and retest.               |
| 215        | Nonfunctioning DC-DC converter for processor X | Replace the DC-DC converter (Processor Power Module). |

### 300 – 399, Keyboard Test Error Codes

The 300 series of diagnostic error codes identifies failures with keyboard and system board functions.

**Table 3-5**  
**Keyboard Test Error Codes**

| Error Code | Description                                 | Recommended Action   |
|------------|---|--|
| 301-xx     | Keyboard short test, 8042 self-test failed. | 1. Check the keyboard connection. If disconnected, turn off the computer, connect the keyboard, turn on the power, and retest. |
| 302-xx     | Keyboard long test failed.                  | 2. Replace the keyboard and retest.  |
| 303-xx     | Keyboard LED test, 8042 self-test failed.   | 3. Replace the system board and retest.  |
| 304-xx     | Keyboard typematic test failed.             |  |

### 400 – 499, Parallel Printer Test Error Codes

The 400 series of diagnostic error codes identifies failures with parallel printer interface card or system board functions.

**Table 3-6**  
**Parallel Printer Test Error Codes**

| Error Code | Description                      | Recommended Action  |
|------------|----------------------------------|---|
| 401-xx     | Printer failed or not connected. | 1. Connect the printer and retest.  |
| 402-xx     | Printer data register failed.    | 2. Check the power to the printer and retest.   |
| 403-xx     | Printer pattern test failed.     | 3. Install the loopback connector and retest.   |
| 498-xx     | Printer failed or not connected. | 4. Check the switch on the serial/parallel interface board (if applicable) and retest.<br>5. Replace the serial/parallel interface board (if applicable) and retest.<br>6. Replace the system board and retest. |

## 500 – 599, Graphics Display Unit Test Error Codes

The 500 series of diagnostic error codes identifies failures with graphics or system board functions.

**Table 3-7**  
**Graphics Display Unit Test Error Codes**

| <b>Error Code</b> | <b>Description</b>                                   | <b>Recommended Action</b>                 |
|-------------------|--|---|
| 501-xx            | Graphics controller test failed.                     | 1. Replace the monitor and retest.        |
| 502-xx            | Graphics memory test failed.                         | 2. Replace the graphics board and retest. |
| 503-xx            | Graphics attribute test failed.                      | 3. Replace the system board and retest.   |
| 504-xx            | Graphics character set test failed.                  |   |
| 505-xx            | Graphics 80x25-mode 9x14 character cell test failed. |   |
| 506-xx            | Graphics 80x25-mode 8x8 character cell test failed.  |   |
| 507-xx            | Graphics 40x25-mode test failed.                     |   |
| 508-xx            | Graphics 320x200-mode color set 0 test failed.       |   |
| 509-xx            | Graphics 320x200-mode color set 1 test failed.       |   |
| 510-xx            | Graphics 640x200-mode test failed.                   |   |
| 511-xx            | Graphics screen memory page test failed.             |   |
| 512-xx            | Graphics gray scale test failed.                     |   |
| 514-xx            | Graphics white screen test failed.                   |   |
| 516-xx            | Graphics noise pattern test failed.                  |   |

## 600 – 699, Diskette Drive Test Error Codes

The 600 series of diagnostic error codes identifies failures with diskette, diskette drive, or system board functions.

**Table 3-8**  
**Diskette Drive Test Error Codes**

| <b>Error Code</b> | <b>Description</b>                          | <b>Recommended Action</b>  |
|-------------------|---|--|
| 600-xx            | Diskette ID drive types test failed.        | 1. Replace the diskette and retest.  |
| 601-xx            | Diskette format failed.                     | 2. Check and/or replace the diskette power and signal cables and retest.         |
| 602-xx            | Diskette read test failed.                  | 3. Replace the diskette drive and retest.  |
| 603-xx            | Diskette write/read/compute test failed.    | 4. Replace the system board and retest.  |
| 604-xx            | Diskette random seek test failed.           |  |
| 605-xx            | Diskette ID media failed.                   |  |
| 606-xx            | Diskette speed test failed.                 |  |
| 607-xx            | Diskette wrap test failed.                  |  |
| 608-xx            | Diskette write protect test failed.         |  |
| 609-xx            | Diskette reset controller test failed.      |  |
| 610-xx            | Diskette change line test failed.           |  |
| 694-xx            | Pin 34 is not cut on 360-KB diskette drive. |  |
| 697-xx            | Diskette type error.                        |  |
| 698-xx            | Diskette drive speed not within limits.     |  |
| 699-xx            | Diskette drive/media ID error.              | 1. Replace the media and retest.<br>2. Run the Configuration Utility and retest. |

## 1100 – 1199, Serial Test Error Codes

The 1100 series of diagnostic error codes identifies failures with serial/parallel interface board or system board functions.

**Table 3-9**  
**Serial Test Error Codes**

| <b>Error Code</b> | <b>Description</b>          | <b>Recommended Action</b>   |
|-------------------|-----------------------------|---|
| 1101-xx           | Serial port test failed.    | 1. Check the switch settings on the serial/parallel interface board (if applicable) and retest.                       |
| 1109-xx           | Clock register test failed. | 2. Replace the serial/parallel interface board (if applicable) and retest.<br>3. Replace the system board and retest. |

## 1200 – 1299, Modem Communications Test Error Codes

The 1200 series of diagnostic error codes identifies failures with the modem.

**Table 3-10**  
**Modem Communications Test Error Codes**

| <b>Error Code</b> | <b>Description</b>                      | <b>Recommended Action</b>  |
|-------------------|---|--|
| 1201-xx           | Modem internal loopback test failed.    | 1. Refer to the modem documentation for correct setup procedures and retest. |
| 1202-xx           | Modem time-out test failed.             | 2. Check the modem line and retest.  |
| 1203-xx           | Modem external termination test failed. | 3. Replace the modem and retest.   |
| 1204-xx           | Modem auto originate test failed.       |  |
| 1206-xx           | Dial multi-frequency tone test failed.  |  |
| 1210-xx           | Modem direct connect test failed.       |  |

## 6000 – 6099, Compaq NIC Boards Test Error Codes

The 6000 series of diagnostic error codes identifies failures with some Compaq Network Interface Controllers.

**Table 3-11**  
**Compaq Network Interface Boards Test Error Codes**

| <b>Error Code</b> | <b>Description</b>                     | <b>Recommended Action</b>   |
|-------------------|--|---|
| 6000-xx           | Network card ID failed.                | 1. Check the controller installation in the PCI slot.   |
| 6001-xx           | Network card setup failed.             | 2. Check the interrupt type and number setting.   |
| 6002-xx           | Network card transmit failed.          | 3. Check the media connection at the controller and Multistation Access Unit (MAU).                           |
| 6014-xx           | Network card configuration failed.     | 4. Check the media speed (4/16) and type of Unshielded Twisted Pair/Shielded Twisted Pair (UTP/STP) settings. |
| 6016-xx           | Network card reset failed.             | 5. Check the MAU, cabling, or other network components.   |
| 6028-xx           | Network card internal failed.          | 6. Replace the controller.  |
| 6029-xx           | Network card external failed.          |   |
| 6089-xx           | Network card open failed.              |   |
| 6090-xx           | Network card initialization failed.    |   |
| 6091-xx           | Network card internal loopback failed. |   |
| 6092-xx           | Network card external loopback failed. |   |

## 6500 – 6599, SCSI Hard Drive Test Error Codes

The 6500 series of diagnostic error codes identifies failures with SCSI hard drives, SCSI hard drive controller boards, SCSI hard drive cabling, and system board functions. If the system uses a drive array controller, see the section for Array Diagnostic Utility (ADU).

**Table 3-12**  
**SCSI Hard Drive Test Error Codes**

| <b>Error Code</b> | <b>Description</b>                          | <b>Recommended Action</b>  |
|-------------------|---|--|
| 6500-xx           | SCSI disk ID drive types test failed.       | 1. Run the System Configuration Utility and verify the drive type. |
| 6502-xx           | SCSI disk unconditional format test failed. | 2. Replace the SCSI disk drive signal and power cables and retest. |
| 6505-xx           | SCSI disk read test failed.                 | 3. Replace the SCSI controller and retest.                         |
| 6506-xx           | SCSI disk SA/media test failed.             | 4. Replace the SCSI disk drive and retest.                         |
| 6509-xx           | SCSI disk erase tape test failed.           | 5. Replace the system board and retest.                            |
| 6523-xx           | SCSI disk random read test failed.          |  |
| 6528-xx           | Media load/unload test failed.              |  |

## 6600 – 6699, SCSI/IDE CD-ROM Drive Test Error Codes

The 6600 series of diagnostic error codes identifies failures with the CD-ROM drive cabling, CD-ROM drives, adapter boards, or the system board assembly.

**Table 3-13**  
**SCSI/IDE CD-ROM Drive Test Error Codes**

| <b>Error Code</b> | <b>Description</b>    | <b>Recommended Action</b>  |
|-------------------|-----------------------|--|
| 6600-xx           | CD-ROM ID failed.     | 1. Replace the CD-ROM media and retest.                            |
| 6605-xx           | CD-ROM read failed.   | 2. Check and/or replace the signal cable and retest.               |
| 6608-xx           | SCSI controller test. | 3. Check the switch settings on the adapter board (if applicable). |
| 6605-xx           | CD-ROM read failed.   | 4. Replace the SCSI controller (if applicable) and retest.         |
|                   |                       | 5. Replace the CD-ROM drive and retest.                            |
|                   |                       | 6. Replace the system board and retest.                            |

## 6700 – 6799, SCSI Tape Drive Test Error Codes

The 6700 series of diagnostic error codes identifies failures with tape cartridges, tape drives, media changers, tape drive cabling, adapter boards, or the system board assembly.

**Table 3-14**  
**SCSI Tape Drive Test Error Codes**

| <b>Error Code</b> | <b>Description</b>                    | <b>Recommended Action</b>  |
|-------------------|---------------------------------------|--|
| 6700-xx           | SCSI tape ID drive types test failed. | 1. Run the System Configuration Utility and verify the drive type. |
| 6706-xx           | SCSI disk SA/media test failed.       | 2. Replace the SCSI tape drive signal and power cables and retest. |
| 6709-xx           | SCSI disk erase tape test failed.     | 3. Replace the SCSI controller and retest.                         |
| 6728-xx           | Media load/unload test failed.        | 4. Replace the SCSI tape drive and retest.                         |
|                   |                                       | 5. Replace the system board and retest.                            |



## 8600 – 8699, Pointing Device Interface Test Error Codes

The 8600 diagnostic error codes identifies failures with the pointing device (mouse, trackball, and so on) or the system board assembly.

**Table 3-15**  
**Pointing Device Interface Test Error Codes**

| Error Code | Description                            | Recommended Action   |
|------------|--|--|
| 8601-xx    | Pointing device interface test failed. | <ol style="list-style-type: none"> <li>1. Replace with a working pointing device and retest.</li> <li>2. Replace the system board and retest.</li> </ol> |

## Array Diagnostic Utility (ADU)

Array Diagnostic Utility (ADU) is a Windows-based software tool designed to run on all Compaq servers that support Compaq array controllers and are running SmartStart 4.10 or later. The two main functions of ADU are to collect all possible information about array controllers in the system and to generate a list of detected problems. The error messages and codes listed include all codes generated by Compaq products. The system generates only codes applicable to the configuration and options in the server.

ADU works by issuing multiple commands to the array controllers to determine if a problem exists. This data can then be saved to a file. In severe situations, this file can be sent to Compaq for analysis. In most cases, ADU provides enough information to initiate problem resolution immediately.

**NOTE:** ADU does not write to the drives, destroy data, or change or remove configuration information.

### Starting ADU

1. Insert the SmartStart CD into the CD-ROM drive.
2. Restart the system from the SmartStart CD.
3. Select Array Diagnostic Utility (ADU) from the System Utilities menu.

A Please Wait panel displays, indicating that ADU is identifying the system parameters. ADU gathers information from all of the array controllers in the system. The time it takes to gather this information depends on the size of the system. When the information-gathering process is complete, ADU displays the main screen or a panel indicating any problems detected.



**CAUTION:** Do not cycle the power during this process. ADU must perform low-level operations that, if interrupted, could cause the controller to revert to a previous level of firmware if the firmware was soft-upgraded.

4. To generate an ADU report, select File then Save Data from the Command menu.

**Table 3-16**  
**ADU Diagnostic Messages**

| <b>Message</b>  | <b>Description</b>   | <b>Recommended Action</b>  |
|---|--|--|
| Accelerator board not detected  | Array controller did not detect a configured array accelerator board.  | Install the array accelerator board on the array controller. If an array accelerator board is already installed, check for proper seating on the array controller board. |
| Accelerator error log   | List of the last 32 parity errors on transfers to or from memory on the array accelerator board; displays starting memory address, transfer count, and operation (read and write).   | If there are many parity errors, you may need to replace the array accelerator board.  |
| Accelerator parity read errors: n   | Number of times that read memory parity errors were detected during transfers from memory on array accelerator board.  | If there are many parity errors, you may need to replace the array accelerator board.  |
| Accelerator parity write errors: n  | Number of times that write memory parity errors were detected during transfers to memory on the array accelerator board.   | If there are many parity errors, you may need to replace the array accelerator board.  |
| Accelerator status: Cache was automatically configured during last controller reset.                              | This can occur when cache board is replaced with one of a different size.  | Normal operations should continue.   |
| Accelerator status: Data in the cache was lost due to some reason other than the battery being discharged         | Data in the cache was lost, but not because of the battery being discharged.   | Ensure that the array accelerator is properly seated. If the error continues, you may need to replace the array accelerator.   |
| Accelerator status: Dirty data detected has reached limit. Cache still enabled, but writes no longer being posted | The number of cache lines containing dirty data that cannot be flushed (written) to the drives has reached a preset limit. The cache is still enabled, but writes are no longer being posted. This error usually occurs when there is a problem with the drive(s). | Resolve problem with drive(s). The controller will then be able to write dirty data to drives and posted write operations will be restored.                              |
| Accelerator status: Dirty data detected. Unable to write dirty data to drives                                     | At least one cache line contains dirty data that the controller has been unable to flush (write) to the drives. This problem usually occurs when there is a problem with the drive(s).   | Resolve the problem with the drive(s). The controller will then be able to write dirty data to drives.   |

*continued*

**Table 3-16**  
**ADU Diagnostic Messages** *continued*

| Message  | Description  | Recommended Action   |
|--|--|--|
| Accelerator status: Excessive ECC errors detected in at least one cache line. As a result, at least one cache line is no longer in use | At least one line in the cache is no longer in use due to excessive ECC errors detected during use of the memory associated with that cache line.                                  | Replacement of cache should be considered. If cache replacement is not done remaining cache lines should continue to operate properly. |
| Accelerator status: Obsolete data detected   | During reset initialization obsolete data was found in cache. This was due to drives being moved and written to by another controller.   | Normal operations should continue. The controller will either write data to the drives or discard the data completely.                 |
| Accelerator status: Obsolete data was discarded  | During reset initialization obsolete data was found in cache and was discarded (not written to drives).  | Normal operations should continue.   |
| Accelerator status: Obsolete data was flushed (written) to drives  | During reset initialization obsolete data was found in cache. Obsolete data was written to the drives, but newer data may have been overwritten.                                   | If newer data was overwritten, you may need to restore newer data; otherwise, normal operations should continue.                       |
| Accelerator status: Permanently disabled   | Array accelerator board has been permanently disabled. It remains disabled until it is reinitialized using the Array Configuration Utility (ACU).                                  | Check the Disable Code field. Run Array Configuration Utility (ACU) to reinitialize the array accelerator board.                       |
| Accelerator status: Possible data loss in cache  | Possible data loss detected during power-up due to all batteries being below sufficient voltage level and no presence of identification signatures on the array accelerator board. | There is no way to determine if dirty or bad data was in the cache and is now lost.  |
| Accelerator status: Temporarily disabled   | Array accelerator board has been temporarily disabled.   | Check the Disable Code field.  |
| Accelerator status: Unrecognized status  | A status returned from the array accelerator board that ADU does not recognize.  | Obtain the latest version of ADU.  |
| Accelerator status: Valid data found at reset  | Valid data was found in posted write memory at reinitialization. Data will be flushed to disk.   | Not an error or data loss condition. No action required.   |
| Accelerator status: Warranty alert   | Catastrophic problem with array accelerator board. Refer to other messages on Diagnostics screen for exact meaning of this message.  | Replace the array accelerator board.   |

*continued*

**Table 3-16**  
**ADU Diagnostic Messages** *continued*

| Message   | Description  | Recommended Action   |
|---|--|--|
| Adapter/NVRAM ID mismatch   | Nonvolatile RAM has an ID for a different controller from the one physically present in the slot.  | Run the System Configuration Utility.  |
| Array accelerator battery pack X not fully charged                    | Battery is not fully charged.  | If 75% of batteries present are fully charged, array accelerator is fully operational. If less than 75% of batteries are fully charged, allow 36 hours to recharge them. |
| Array accelerator battery pack X below reference voltage (recharging) | Battery pack on array accelerator is below required voltage levels.  | Allow enough time for batteries to recharge (36 hours). If batteries have not recharged after 36 hours, replace the array accelerator board.                             |
| Board in use by expand operation                                      | Array accelerator memory is in use by Expand operation.  | Operate system without array accelerator board until Expand operation completes.   |
| Board not attached  | Array controller configured for use with array accelerator board, but one is not attached.   | Attach array accelerator board to array controller.  |
| Configuration signature is zero                                       | ADU detected that nonvolatile RAM contains a configuration signature of zero. Old versions of the System Configuration Utility could cause this.   | Run the latest version of System Configuration Utility to configure the controller and nonvolatile RAM.  |
| Configuration signature mismatch                                      | Array accelerator board configured for a different array controller board. Configuration signature on array accelerator board does not match the one stored on the array controller board. | To recognize the array accelerator board, run the Array Configuration Utility.   |
| Controller communication failure occurred                             | Controller communication failure occurred.   | ADU was unable to successfully issue commands to the controller in this slot.  |
| Controller detected. NVRAM configuration not present                  | Nonvolatile RAM does not contain a configuration for this controller.  | Run the System Configuration Utility to configure the nonvolatile RAM.   |
| Controller firmware needs upgrading                                   | Controller firmware is below the latest recommended version.   | Run Options ROMPaq to upgrade the controller to the latest firmware revision.  |

*continued*

**Table 3-16**  
**ADU Diagnostic Messages** *continued*

| Message   | Description   | Recommended Action  |
|---|---|---|
| Controller is located in special "Graphics" slot              | Controller is installed in slot for special graphics control signals. If controller is used in this slot, LED indicators on front panel may not function properly.  | Install the controller in a different slot and run the System Configuration Utility to configure the controller and nonvolatile RAM. Then run the Array Configuration Utility to configure controller.  |
| Controller is not configured                                  | Controller is not configured. If controller was previously configured and you change drive locations, there may be a problem with placement of the drives. ADU examines each physical drive and looks for drives that have been moved to a different drive bay. | Look for messages indicating which drives have been moved. If none appear and drive swapping did not occur, run the Array Configuration Utility to configure the controller and run the System Configuration Utility to configure nonvolatile RAM. <b>Do not</b> run either utility if you believe drive swapping has occurred. |
| Controller reported POST error.<br>Error Code: x              | The controller returned an error from its internal Power-On Self-Tests.   | Replace the controller.   |
| Controller restarted with a signature of zero                 | ADU did not find a valid configuration signature to use to get the data. Nonvolatile RAM may not be present (unconfigured) or the signature present in nonvolatile RAM may not match the signature on the controller.   | Run the System Configuration Utility to configure the controller and nonvolatile RAM.   |
| Disable command issued  | Posted-writes have been disabled by the issuing of the Accelerator Disable command. This occurred because of an operating system device driver.   | Restart the system. Run the Array Configuration Utility to reinitialize the array accelerator board.  |
| Drive (bay) X firmware needs upgrading                        | Firmware on this physical drive is below the latest recommended version.  | Run the Options ROMPaq Utility to upgrade the drive firmware to the latest revision.  |
| Drive (bay) X has insufficient capacity for its configuration | Drive has insufficient capacity to be used in this logical drive configuration.   | Replace this drive with a larger capacity drive.  |
| Drive (bay) X has invalid M&P stamp                           | Physical drive has invalid monitor and performance data.  | Run the System Configuration Utility to properly initialize this drive.   |
| Drive (bay) X has loose cable                                 | The array controller could not communicate with this drive at power-up. This drive has not previously failed.   | Check all cable connections first. The cables could be bad, loose, or disconnected. Turn on the system and attempt to reconnect signal/power cable to the drive. If this does not work, replace the cable. If that does not work, the drive may need to be replaced.  |

*continued*

**Table 3-16**  
**ADU Diagnostic Messages** *continued*

| Message  | Description  | Recommended Action  |
|--|--|---|
| Drive (bay) X is a replacement drive                       | This drive has been replaced. This message displays if a drive is replaced in a fault tolerant logical volume.   | If the replacement was intentional, allow the drive to rebuild.   |
| Drive (bay) X is a replacement drive marked OK             | This drive has been replaced and marked OK by the firmware. This may occur if a drive has an intermittent failure (for example, if a drive has previously failed, then when ADU is run, the drive starts working again). | Replace the drive.  |
| Drive (bay) X is failed                                    | The indicated physical drive has failed.   | Replace the drive.  |
| Drive (bay) X is undergoing drive recovery                 | This drive is being rebuilt from the corresponding mirror or parity data.  | Normal operations should occur.   |
| Drive (bay) X needs replacing                              | The 210-megabyte hard drive has firmware version 2.30 or 2.31.   | Replace the drive.  |
| Drive (bay) X upload code not readable                     | An error occurred while ADU was trying to read the upload code information from this drive.  | If there were multiple errors, this drive may need to be replaced.  |
| Drive (bay) X was inadvertently replaced                   | The physical drive was incorrectly replaced after another drive failed.  | Replace the drive that was incorrectly replaced and replace the original drive that failed. Do not run the System Configuration Utility and try to reconfigure; data will be lost.              |
| Drive Monitoring features are unobtainable                 | ADU unable to get monitor and performance data due to fatal command problem such as drive time-out, or unable to get data due to these features not supported on the controller.   | Check for other errors (time-outs, and so on). If no other errors occur, upgrade the firmware to a version that supports monitor and performance, if desired.                                   |
| Drive Monitoring is NOT enabled for SCSI Port x Drive ID x | The monitor and performance features have not been enabled on this drive.  | Run the System Configuration Utility to initialize the monitor and performance features.  |
| Drive time-out occurred on physical drive bay X            | ADU issued a command to a physical drive and the command was never acknowledged.   | The drive or cable may be bad. Check the other error messages on the Diagnostics screen to determine resolution.  |
| Drive X indicates position Y                               | Message indicates physical drive that appears to be scrambled or in a drive bay other than the one for which it was originally configured.   | Examine the graphical drive representation on ADU to determine proper drive locations. Remove drive X and place it in drive position Y. Rearrange the drives according to the ADU instructions. |

*continued*

**Table 3-16**  
**ADU Diagnostic Messages** *continued*

| Message  | Description  | Recommended Action  |
|--|--|---|
| Duplicate write memory error   | Data could not be written to the array accelerator board in duplicate due to the detection of parity errors. This is not a data loss situation.  | Replace the array accelerator board.  |
| Error occurred reading RIS copy from SCSI Port x Drive ID x                            | An error occurred while ADU was trying to read the RIS from this drive.  | If there were multiple errors, this drive may need to be replaced.  |
| FYI: Drive (bay) X is non-Compaq supplied  | The installed drive was not supplied by Compaq.  | If problems exist with this drive, replace it with a Compaq drive.  |
| Identify controller data did not match with NVRAM                                      | The identify controller data from the array controller did not match the information stored in nonvolatile RAM. This could occur if new, previously configured drives have been placed in a system that has also been previously configured. It could also occur if the firmware on the controller has been upgraded and the System Configuration Utility was not run. | Check the identify controller data under the Inspect Utility. If the firmware version field is the only difference between the controller and nonvolatile RAM data, this is not a problem. Otherwise, run the System Configuration Utility. |
| Identify logical drive data did not match with NVRAM                                   | The identify unit data from the array controller did not match with the information stored in nonvolatile RAM. This could occur if new, previously configured drives have been placed in a system that has also been previously configured.  | Run the System Configuration Utility to configure the controller and nonvolatile RAM.   |
| Insufficient adapter resources   | The adapter does not have sufficient resources to perform operations to the array accelerator board. Drive rebuild may be occurring.   | Operate the system without the array accelerator board until the drive rebuild completes.   |
| Less than 75% batteries at sufficient voltage  | Operation of array accelerator board has been disabled due to less than 75% of battery packs being at sufficient voltage level.  | Allow sufficient time for batteries to recharge (36 hours). If batteries have not recharged after 36 hours, replace the array accelerator board.  |
| Less than 75% batteries at sufficient voltage. Battery pack X below reference voltage. | Battery pack on array accelerator is below required voltage levels.  | Allow sufficient time for batteries to recharge (36 hours). If batteries have not recharged after 36 hours, replace the array accelerator board.  |
| Logical drive X failed due to cache error  | This logical drive failed due to a catastrophic cache error.   | Replace the array accelerator board and reconfigure using the Array Configuration Utility.  |

*continued*

**Table 3-16**  
**ADU Diagnostic Messages** *continued*

| Message                                       | Description   | Recommended Action  |
|---|---|---|
| Logical Drive X status = FAILED               | This status could be issued for several reasons. If this logical drive is configured for No Fault Tolerance and one or more drives fail, this status will occur. If mirroring is enabled, and any two mirrored drives fail, this status will occur. If Data Guarding is enabled, and two or more drives fail in this unit, this status will occur. This status may also occur if another configured logical drive is in the Wrong Drive Replaced or Loose Cable Detected State. | Check for drive failures, wrong drive replaced, or loose cable messages. If there was a drive failure, replace the failed drive(s), then restore the data for this logical drive from the tape backup. Otherwise, follow the wrong drive replaced or loose cable detected procedures. |
| Logical Drive X status = INTERIM RECOVERY     | A physical drive in this logical drive has failed. The logical drive is operating in interim recovery mode and is vulnerable.   | Replace the failed drive as soon as possible.   |
| Logical Drive X status = LOOSE CABLE DETECTED | A physical drive has a cabling problem.   | Turn the system off and attempt to reattach the cable onto the drive. If this does not work, replace the cable.   |
| Logical Drive X status = NEEDS RECOVER        | A physical drive in this logical drive has failed and has now been replaced. This drive needs to be rebuilt from the mirror drive or the parity data.   | When starting the system, select the "F1 - rebuild drive" option to rebuild the replaced drive.   |
| Logical Drive X status = OVERHEATED           | The Intelligent Array Expansion System temperature is beyond safe operating levels, and the system has shut down to avoid damage.   | Check the fans and the operating environment.   |
| Logical Drive X status = OVERHEATING          | The Intelligent Array Expansion System temperature is beyond safe operating levels.   | Check the fans and the operating environment.   |
| Logical Drive X status = RECOVERING           | A physical drive in this logical drive has failed and has now been replaced. The replaced drive is rebuilding from the mirror drive or the parity data.   | Nothing needs to be done. Normal operations can occur.  |
| Logical Drive X status = WRONG DRIVE REPLACED | A physical drive in this logical drive has failed. The incorrect drive was replaced.  | Replace the drive that was incorrectly replaced. Then, replace the original drive that failed with a new drive. Do not run the System Configuration Utility to reconfigure; data on drive will be lost.   |

*continued*



**Table 3-16**  
**ADU Diagnostic Messages** *continued*

| Message  | Description  | Recommended Action  |
|--|--|---|
| Loose cable detected - logical drives may be marked FAILED until corrected | ADU found loose cable. If logical drives are marked FAILED, those logical drives will be unusable until problem corrected.<br><br>Controller unable to communicate with one or more physical drives, probably because of a cabling problem. Logical drives may be in a FAILED state until the condition is corrected, preventing access to data on the controller. | Turn off the system. Check cable(s) for tight connection to logical drives. Restart system. If same message recurs, cable(s) may be bad.<br><br>Check all controller and drive cable connections.   |
| Mirror data miscompared  | Data was found at reinitialization in the posted write memory; however, the mirror data compare test failed resulting in data being marked as invalid. Data loss is possible.  | Replace the array accelerator board.  |
| No configuration for accelerator board                                     | The array accelerator board has not been configured.   | If the array accelerator board is present, run the Array Configuration Utility (ACU) to configure the board.  |
| NVRAM configuration present, controller not detected                       | Nonvolatile RAM has a configuration for an array controller, but there is no board in this slot. Either a board has been removed from the system or a board has been placed in the wrong slot.   | Place the array controller in the proper slot or run the System Configuration Utility to reconfigure nonvolatile RAM to reflect the removal or new position.  |
| RIS copies between drives do not match                                     | Drives on controller contain copies of RIS that do not match.  | Upgrade ADU to the most recent version.   |
| SCSI Port x Drive ID x has exceeded threshold(s)                           | Monitor and performance threshold for this drive has been violated.  | Check for the particular threshold that has been violated.  |
| SCSI Port x Drive ID x is not stamped for monitoring                       | Drive has not been stamped with monitor and performance features.  | Run the Array Configuration Utility (ACU). Changing the configuration and saving should cause ACU to stamp drive with monitor and performance features. To do this without destroying the current configuration, change array accelerator size and save configuration. Change the array accelerator back to original size and save again. |
| SCSI Port x Drive ID x RIS copy mismatch                                   | Copies of RIS on drive do not match.   | Drive may need to be replaced. Check for other errors.  |

*continued*

**Table 3-16**  
**ADU Diagnostic Messages** *continued*

| Message   | Description   | Recommended Action  |
|---|---|---|
| SCSI Port x Drive ID x failed – REPLACE (failure message)                           | ADU found drive that needs to be replaced.  | Replace drive or correct condition that caused error.                             |
| SCSI Port x Drive ID x firmware needs upgrading                                     | Drive firmware is below recommended version.  | Run Options ROMPaq to upgrade drive to latest firmware revision.                  |
| SCSI Port x Drive ID x has a loose cable. SMART is unable to communicate with drive | Drive has loose cable.  | Turn off the system. Check drive cable for tight connection.                      |
| SCSI Port x Drive ID x was replaced on a good volume: (failure message)             | ADU found drive was replaced even though volume was fine.   | No action needed.   |
| SCSI port X, drive ID Y firmware needs upgrading                                    | Drive's firmware may cause problems and should be upgraded.   | Run Options ROMPaq to upgrade the firmware on the drive to a later version.       |
| Set configuration command issued  | The configuration of the array controller has been updated. The array accelerator board may remain disabled until it is reinitialized.  | Run the System Configuration Utility to reinitialize the array accelerator board. |
| Soft Firmware Upgrade required  | ADU has determined that the controller is running firmware that has been soft upgraded by the Compaq Upgrade Utility. However, the firmware running is not present on all drives. This could be caused by the addition of new drives in the system. | Run the Compaq Upgrade Utility to place the latest firmware on all drives.        |
| Unable to communicate with drive on SCSI Port x, Drive ID x                         | Controller could not communicate with drive.  | If the amber LED on the drive is on, replace the drive.                           |
| Unknown disable code  | A code was returned from the array accelerator board that ADU does not recognize.   | Obtain the latest version of ADU.   |

*continued*

**Table 3-16**  
**ADU Diagnostic Messages** *continued*

| Message                                     | Description  | Recommended Action  |
|---|--|---|
| Unrecoverable read error                    | Read parity errors were detected when attempting to read same data from both sides of mirrored memory. Data loss will occur.   | Replace the array accelerator board.  |
| WARNING - Drive Write Cache is enabled on X | Drive has its internal write cache enabled. The drive may be a third-party drive, or the operating parameters of the drive may have been altered. This condition may cause data corruption if power to the drive is interrupted.   | Replace the drive with a drive supplied by Compaq, or restore the operating parameters of the drive.                          |
| Warning bit detected                        | A monitor and performance threshold violation may have occurred. Status of a logical drive may not be OK.  | Check the other error messages on the diagnosis screen for an indication of the problem.                                      |
| Write memory error                          | Data could not be written to cache memory. This typically means that parity error was detected while writing data to cache. This could be caused by incomplete connection between cache and controller. This is not a data loss circumstance.  | With power to system turned off, verify that the cache board is fully connected to controller.                                |
| Wrong Accelerator                           | This could mean that either the board was replaced in the wrong slot or placed in a system that was previously configured with another board type. Included with this message is a message indicating the type of adapter sensed by ADU and a message indicating the type of adapter last configured in nonvolatile RAM. | Check the diagnosis screen for other error messages. Run the System Configuration Utility to update the system configuration. |

## Integrated Management Log

IML records system events and stores them in an easily viewable form. Each event is marked with a time-stamp with one-minute granularity.

Events listed in the Integrated Management Log are categorized as one of four event severity levels:

- **Status**—indicates that the message is informational only.
- **Repaired**—indicates that corrective action has been taken.
- **Caution**—indicates a nonfatal error condition.
- **Critical**—indicates a component failure.

The Integrated Management Log requires operating system-dependent drivers from Compaq. Refer to the Compaq Support Software CD for instructions on installing the appropriate drivers.

## Multiple Ways of Viewing the Log

You can view an event in the IML in several ways:

- From within Compaq Insight Manager
- From within the Compaq Survey Utility
- From within the IML Management Utility

### Compaq Insight Manager

Compaq Insight Manager is a comprehensive management tool used to monitor and control the operation of Compaq servers and clients. Compaq Insight Manager consists of two components: a Windows-based console application, and server- or client-based management data collection agents. Starting with Compaq Insight Manager 4.0, the agents for Windows NT and NetWare are also Web-enhanced; that is, these agents enable Web browser access and monitoring of management information.

The management agents monitor over 1,000 management parameters. Key subsystems are instrumented to make health, configuration, and performance data available to agent software. Agents act upon data by initiating information, such as statistics on network interface or storage subsystem performance.

### **Viewing the Event List**

1. From Compaq Insight Manager, select the appropriate server, then select View Device Data. The selected server displays, with buttons around its perimeter.
2. Select the Recovery button, then insert Integrated Management Log.
3. If a failed component has been replaced, select the event from the list. Then select Mark Repaired.

### **Printing the Event List**

**NOTE:** You can view the event list only from the Recovery/Integrated Management Log screen as described above.

1. From the Compaq Insight Manager screen, select the appropriate server.
2. Select the Configuration button then Recovery button, then Print.

### **Compaq Survey Utility**

The Compaq Survey Utility is a serviceability tool available for Windows NT and Novell NetWare. It delivers online-configuration capture and comparison to maximize server availability. It is delivered on the Compaq Management CD in the SmartStart package or is available on the Compaq website. Refer to the Compaq Management CD for information on installing and running the Compaq Survey Utility.

After running the Compaq Survey Utility, view the IML by loading the output of the utility (typically called "survey.txt") into a text viewer such as Microsoft Notepad. The event list follows the system slot information. After opening the text file, print it using the print feature of the viewer.

### **Compaq IML Management Utility**

The Compaq IML Management Utility is a DOS-based tool that gives you the offline ability to review, mark corrected, and print events from the IML. It is located on the Compaq SmartStart and Support Software CD. Refer to the SmartStart Installation for Servers poster, which ships with the server, for information on how to install and use the IML Management Utility.

## Event List

The Event List displays the affected components and the associated error messages. Though the same basic information displays, the format of the list may differ, depending on how you view it: on the Integrated Management Display, from within Compaq Insight Manager, or the Compaq Survey Utility. An example of the format of an event displayed on the Integrated Management Display is as follows:

```
**001 of 010**  
---caution---  
03/19/1997  
12:54 PM  
FAN Failure  
Main System  
Location:  
  System Board  
Fan ID: 03  
**END OF EVENT**
```

## Event Messages

**Table 3-17**  
**Event Messages**

| <b>Event Type</b>                       | <b>Event Message</b>   | <b>Action</b>   |
|---|--|---|
| <b>Machine Environment</b>              |  |   |
| Fan Failure                             | System Fan Failure (Fan X, Location).                              | Replace fan.  |
| Overheat Condition                      | System Overheating (Zone X, Location).                             | Check fans.   |
| <b>Main Memory</b>                      |  |   |
| Correctable Error<br>threshold exceeded | Corrected Memory Error threshold passed (Slot X, Memory Module X). | Replace the defective memory module.  |
|   | Corrected Memory Error threshold passed (System Memory).           | Replace the memory modules one at a time (if more than one) and retest the system after each replacement. |
| Uncorrectable Error                     | Corrected Memory Error threshold passed (Memory Module unknown).   | Replace the memory modules one at a time (if more than one).  |
|   | Uncorrectable Memory Error (Slot X, Memory Module X).              | Replace the defective memory module.  |
|   | Uncorrectable Memory Error (System Memory).                        | Replace the defective memory module.  |
|   | Uncorrectable Memory Error (Memory Module unknown).                | Replace the memory modules one at a time (if more than one) and retest the system after each replacement. |
| <b>Processor</b>                        |  |   |
| Correctable Error<br>Threshold exceeded | Processor Correctable error Threshold passed (Slot X, Socket X).   | Replace the processor.  |
| Uncorrectable Error                     | Unrecoverable Host Bus Data Parity Error.                          | Replace the processor.  |
| Host Bus Error                          | Unrecoverable Host Bus Address Parity Error.                       | Call the service provider or Compaq for diagnosis.  |
| <b>PCI Bus Error</b>                    | PCI Bus Error (Slot X, Bus X, Device X, Function X).               | Power down PCI slot and replace board.  |
| <b>Power Subsystem</b>                  |  |   |
| Power Supply Failure                    | System Power Supply Failure (Power Supply X).                      | Replace power supply.   |
| Power Supply Inserted                   | System Power Supply Inserted (Power Supply X).                     | None  |

*continued*

**Table 3-17**  
**Event Messages** *continued*

| <b>Event Type</b>                  | <b>Event Message</b>   | <b>Action</b>  |
|------------------------------------|--|--|
| Power Supply Removed               | System Power Supply Removed (Power Supply X).  | None   |
| Power Supply Not Redundant         | System Power Supplies Not Redundant.   | Add power supply.                                    |
| System Configuration Battery Low   | Real-Time Clock Battery Failing.   | Replace battery.                                     |
| Power Module Failure               | A CPU Power Module (System Board, Socket X).   | Replace power module.                                |
| Power Module Failure               | A CPU Power Module (Slot X, Socket X).   | Replace power module.                                |
| <b>Automatic Server Recovery-2</b> |  |  |
| System Lockup                      | ASR Lockup Detected: Cause   | Call the service provider or Compaq for diagnosis.   |
| <b>Operating System</b>            |  |  |
| System Crash                       | Blue Screen Trap: Cause [NT]<br>Kernel Panic: Cause [UNIX]<br>Abnormal Program Termination: Cause [NetWare]  | Refer to the documentation for the operating system. |
| Automatic OS Shutdown              | Automatic Operating System Shutdown Initiated Due to Fan Failure<br>Automatic Operating System Shutdown Initiated Due to Overheat Condition<br>Fatal Exception (Number X, Cause) | Refer to the documentation for the operating system. |



## Rapid Error Recovery

Compaq servers provide rapid recovery services for diagnosing and recovering from errors. These tools are available for local and remote diagnosis and recovery.

Rapid recovery means fast identification and resolution of complex faults. The Rapid Recovery Engine and Insight Management Agents notify the system administrator when a failure occurs, ensuring that the server experiences minimal downtime. You enable these features through the System Configuration Utility. These integrated server management features are:

- Automatic Server Recovery-2 (ASR-2)
- Integrated Management Logs
- Storage Fault Recovery Tracking
- Storage Automatic Reconstruction (requires the Integrated Smart Array Controller)
- Network Interface Fault Recovery Tracking
- Memory Fault Recovery Tracking

These are discussed in more detail on the server documentation CD.

## Automatic Server Recovery-2

Automatic Server Recovery-2 (ASR-2) lets the server restart automatically from the operating system or the Compaq Utilities. To use this feature, you must use the System Configuration Utility to install Compaq Utilities in the Compaq system partition.

You can enable the ASR-2 feature to restart a server after a critical hardware or software error occurs. If a critical error occurs, the server records the error information in the Integrated Management Log, restarts the system, and pages you. Using the Compaq System Configuration Utility, configure the system for automatic recovery or for attended local or remote access to diagnostic and configuration tools.

**NOTE:** ASR-2 is available only on specific operating systems. ASR-2 drivers are provided by Compaq.

You can also configure ASR-2 to page an administrator when the system restarts. ASR-2 depends on the application and driver that routinely notify the ASR-2 hardware of proper system operations. If the time between ASR-2 notifications exceeds the specified period, ASR-2 assumes a fault has occurred and initiates the recovery process.

To configure ASR-2:

1. Run the System Configuration Utility.
2. Select View and Edit Details.
3. Set the software error recovery status to Enabled.
4. Set the software error recovery timeout.

The available recovery features are:

- **Software Error Recovery**—can be set to automatically restart the server after a software-induced server failure.
- **Environmental Recovery**—can be set to allow the server to restart when temperature, fan, or AC power conditions return to normal.

### **Unattended Recovery**

For unattended recovery, ASR-2 performs the following actions:

- Logs the error information to the IML
- Resets the server
- Pages you (if a modem is present and you selected Paging)
- Tries to restart the operating system

Often the server restarts successfully, making unattended recovery the ideal choice for remote locations where trained service personnel are not immediately available.

If ASR-2 cannot restart the server within 10 attempts, it places a critical error in the Integrated Management Log, starts the server into Compaq Utilities, and enables remote access (if you configured remote access).

To use this level of ASR-2, you must configure ASR-2 to load the operating system after restart.

### **Attended Recovery**

For attended recovery, ASR-2 performs the following actions:

- Logs the error information to the IML
- Resets the server
- Pages you (if a modem is present and you selected Paging)
- Starts Compaq Utilities from the hard drive
- Enables remote access

During system configuration, these utilities are placed on the system utilities partition of the hard drive.

If you have configured for dial-in access and have a modem with an auto-answer feature installed, you can dial in and remotely diagnose or reconfigure the server.

If you have configured the Compaq Utilities for network access, you can access the utilities over the network. You can use Compaq Insight Manager for dial-in or network access.

## Hardware Requirements

To use this level of ASR-2 over a modem, you need the following:

- Compaq External Netelligent modem or compatible
- System Configuration Utility and Diagnostics Utility installed on the Compaq system partition of the hard drive
- ASR-2 configured to load Compaq Utilities after restart

You can also run Compaq Utilities remotely over an IPX or IP network using the Network feature:

- To use Compaq Utilities on an IPX network, you must have Compaq Insight Manager 2.0 or later or an NVT (Novell Virtual Terminal) Terminal Emulator with VT100 or ANSI terminal capabilities.
- To use Compaq Utilities on an IP network, you must have Compaq Insight Manager 2.10 or later, or a Telnet Terminal Emulator with VT100 or ANSI capabilities.

If you are notified that ASR-2 restarted the server and you have restarted to Compaq Utilities, use the Inspect Utility or Compaq Insight Manager to view the critical error. Run Diagnostics to diagnose and resolve the problem.

You can configure ASR-2 to restart the server into Compaq Utilities to diagnose the critical error or to start the operating system to return the server to operational status as rapidly as possible.

When you enable ASR-2 to start the operating system, the server tries to start from the primary partition. In this mode, ASR-2 can page you if a critical error occurs, but you cannot access Compaq Utilities.

When you enable ASR-2 to start Compaq Utilities, the server restarts after a critical error and loads Compaq Utilities from the Compaq system partition on the hard drive.

You can configure the server to start Compaq Utilities in four different ways:

- Without remote console support; for example, to run Compaq Utilities from the server console only
- With remote console support using modems for dial-in access
- With remote console support using a modem to dial a predetermined telephone number
- With remote console support through a network connection (IP or IPX)

**Table 3-18**  
**ASR-2 Features**

| <b>Features</b>                      | <b>Definition</b>  |
|--------------------------------------|--|
| Software error recovery              | If enabled, ASR-2 is activated if the OS hangs or has a crash that results in a lockup.  |
| Software error recovery timeout      | Determines how long the server waits to enable ASR-2 after an OS lockup.   |
| Standby recovery server option       | If enabled, ASR-2 activation initiates a switch to a standby recovery server.  |
| Standby recovery server port         | Port used to communicate with the recovery server.   |
| Standby recovery timeout             | Determines how long the server waits to initiate switch after ASR-2 activation.  |
| Software error recovery start option | Allows the server to restart either into the OS or into Compaq Utilities.  |
| Thermal shutdown                     | If enabled, shuts down the server if a critical thermal error occurs.  |
| UPS shutdown                         | If enabled, allows the server to perform a shutdown if a UPS is activated.   |
| UPS shutdown threshold               | Determines how long the server waits to shut down after the UPS is activated. If desired, this number should provide enough time for an administrator to perform any necessary operations or to gracefully shut down the server. |

## Compaq Integrated Remote Console

The standard Compaq Integrated Remote Console performs a wide range of configuration activities. Console features include:

- Is accessible using ANSI terminal
- Operates independently of the operating system
- Provides for remote server restart
- Provides access to system configuration
- Uses out-of-band communication with dedicated management modem installed in the server

For more information, see the *Integrated Remote Console User Guide* that shipped with the server.

---

**IMPORTANT:** Before configuring ASR-2, verify that the System Configuration Utility and Diagnostics software are installed on the Compaq system partition. ASR-2 must have this to start Compaq Utilities after a system restart. Compaq recommends this even if you configure ASR-2 to start the operating system.

---

## Compaq Health Driver

The Compaq Health Driver continually resets the ASR-2 timer according to the frequency you specified in the System Configuration Utility (for example, 10 minutes). If the ASR-2 timer counts down to zero before being reset, due to an operating system crash or a server lockup, ASR-2 restarts the server into either Compaq Utilities or the operating system (as indicated by the System Configuration parameters). The default value is 10 minutes. The allowable settings are 5, 10, 20, and 30 minutes.

For remote and off-site (unattended) servers, setting the software error recovery timeout for 5 minutes reduces server downtime and allows the server to recover quickly. For local (attended) servers located on site, you can set the software error recovery timeout for 20 or 30 minutes, giving you time to arrive at the server if you wish to manually diagnose the problem.

The Compaq Health Driver is independent of the ASR-2 timer. You should load it and enable the ASR-2 timer. This allows the driver to detect and log information in the IML regarding numerous hardware and software errors. However, you cannot enable the ASR-2 timer without loading the Compaq Health Driver.

Before ASR-2 restarts the server, it records any information available about the condition of the operating system in the IML. This information can be used to diagnose an operating system crash or server lock-up, while still allowing the server to be restarted.

The following ASR-2 flow chart shows you the sequence of events after a hardware or software error occurs:




Figure 3-1. ASR-2 flow chart

## Booting into Compaq Utilities

When you enable ASR-2 to start into Compaq Utilities and a critical error occurs, the operating system-specific Health Driver logs the error information in the IML and the ASR-2 feature restarts the server. When the system reinitializes, the system pages the designated administrator (if enabled), and starts Compaq Utilities from the hard drive.

If Dial-In status is enabled, the modem is placed in auto-answer mode. If you enable Dial-Out status, you are automatically enabled for Dial-In.

If Network Status is enabled, the appropriate network support software is loaded, depending on the network protocol, IP or IPX. This allows remote access via the network.

---

**IMPORTANT:** Compaq Utilities are loaded from a specially created Compaq system partition on the hard drive. This partition was configured during server configuration.

---

You can access the server and view the Integrated Management Logs remotely by modem, in-band over the network, or directly from the server. For modem access, you must have either Compaq Insight Manager 2.0 or above or have a VT100 or ANSI terminal type device. You may use a standard CRT with VT100 or ANSI emulation capability, or you may use a PC with a VT100 or ANSI terminal emulation package. The communication parameters must be set for 8 data bits, no parity, and 1 stop bit.

You can also enable ASR-2 to allow network access using the Network Status feature in the System Configuration Utility. You must have either Compaq Insight Manager 2.0 or greater or a Novell Virtual Terminal (NVT) emulator on an IPX network to use this feature. You must also have version 2.24 or later of the System Configuration Utility. For IP access, you must have Compaq Insight Manager 2.10 or later, or a Telnet Terminal emulator to use this feature. You also must have version 2.24 or later of the System Configuration Utility.

The System Configuration Utility settings should resemble the settings in Table 3-19 when you enable ASR-2 to start into Compaq Utilities.



**Table 3-19**  
**Compaq System Configuration Utility Pager Settings for Booting into Compaq Utilities**

| Pager Data        | Example Setting            | Description  |
|-------------------|----------------------------|--|
| Pager status      | Enabled                    | Indicates whether the pager feature is enabled or disabled   |
| Pager dial string | ATDT<br>555-5555           | Indicates the pager dial string and delay before the pager message; pagers typically use one of the following formats:<br><br>Local pagers: ATDT 555-5555<br><br>Wide area pagers: ATDT 1-800-555-5555,1234567#  |
| Pager message     | 1234567#                   | Represents a unique number (maximum seven digits, numeric only) that you must designate to identify the server on the pager display. The ROM adds a three-digit code to the front of this number. The first two indicate the subsystem and the third indicates the severity of the error that caused the alert. The # symbol usually terminates the message. If no message is required, delete the # symbol.   |
| Pager test        | Select to test pager setup | Use this to test the current pager settings. Press <b>Enter</b> to dial the pager number, and the pager message (if present) displays. You must configure the computer before testing the pager, and the Pager Status must be set to Enabled. Do not test the pager if you are running remotely and are using only one modem.  |
| Serial interface  | COM1                       | Select the communications port for the modem used by the pager and the remote ASR-2 functions. The options are COM1 and COM2.  |
| Dial-in status    | Enabled                    | Set Dial-In Status to Enabled. Be sure the Reset Boot option is set to Boot Compaq Utilities. When the system starts because of an ASR reset, it starts to the Compaq Utilities, sets the Management Modem to auto-answer, and waits for the administrator to dial in and run the Compaq Utilities.<br><br>You automatically disable this option when you configure the software error recovery start option to Boot Operating System. When ASR pages you, you cannot dial in unless ASR-2 exceeds 10, the threshold number of server restart retries. When this happens, ASR-2 restarts the server into the Compaq Utilities and places the modem in auto-answer mode.                    |
| Dial-out status   | Enabled                    | Allows ASR-2 to dial out to a remote workstation. If you selected this option, Dial-In Status is automatically selected.<br><br>To use the dial-out feature, set Dial-Out Status to Enabled and set the Dial-Out String to the correct phone number. You must also set the Reset Boot option to Boot Compaq Utilities. When the system restarts because of an ASR reset, the administrator is paged via Pager Status and Pager Dial String, the system restarts to the Compaq Utilities, and dials out to the phone number provided in the Dial-Out string. The dial-out number will be tried five times. If it fails to connect after five attempts, the modem is put in autoanswer mode. |

*continued*

**Table 3-19**  
**Compaq System Configuration Utility Pager Settings for Booting into Compaq Utilities** *continued*

| Pager Data                | Example Setting | Description   |
|---------------------------|-----------------|---|
| Dial-out string           | 555-1234        | Enter the dial string followed by the remote computer telephone number.   |
| Network status            | Enabled         | To allow network access to Compaq Utilities, set Network Status to Enabled and ensure that the Reset Boot option is set to Boot Compaq Utilities.   |
| Network protocol          |                 | <p>To use IPX network access, set Network Protocol to IPX. When the system restarts to the Compaq Utilities because of an ASR reset, it loads IPX network support. This enables remote access using NVT.</p> <p>To use IP network access, set Network protocol to IP. Also make sure to set Network IP address, Network IP net mask, and Network IP router address. When the system restarts to the Compaq Utilities because of an ASR reset, it loads IP network support. This enables remote access using Telnet.</p> <p><b>Note:</b> The Network Status must be set to Enabled for network access.</p> |
| Network controller        | Compaq          | For all Compaq standard network controllers.  |
| Network host name         | CPQHOU          | Enter the network name of the server. Use underscores instead of spaces within the name—for example, Compaq_Server. If you are using IPX network access to the Compaq Utilities, this server name is used to advertise NVT host services. This server name displays in the Compaq Insight Manager server list when the program determines it can communicate using NVT. Set this name to be the same as the server name you assign when the host OS is running.   |
| Network card slot         | Slot #          | Select the slot number of the network interface card you wish to use for network access to Compaq Utilities.  |
| Network frame type        | ETHERNET_II     | Select the frame type for the network. Selections include both Ethernet and Token Ring topologies.  |
| Network IP address        | xxx.xxx.xxx.xxx | Enter the IP address for this server in standard dot notation.<br><br><b>Note:</b> This is not used if you select Custom for Network controller. You must enter the IP address in the NET.CFG file that you load into the Compaq system partition.  |
| Network IP net mask       | xxx.xxx.xxx.xxx | Enter the net mask for this server in standard dot notation.<br><br><b>Note:</b> This is not used if you select Custom for network controller. You must enter the IP address in the NET.CFG file that you load into the Compaq system partition.  |
| Network IP router address | xxx.xxx.xxx.xxx | Enter the router to be used for this server in standard dot notation.<br><br><b>Note:</b> This is not used if you select Custom for network controller. You must enter the IP address in the NET.CFG file that you load into the Compaq system partition.   |

If you configure the server to boot into Compaq Utilities, it prepares for remote communications. You can remotely run Diagnostics software, the Inspect Utility, or the System Configuration Utility using a workstation running terminal emulation software, such as Compaq Insight Manager or PC Anywhere.

### Booting into the Operating System

When you enable ASR-2 to restart into the operating system and a critical error occurs, ASR-2 logs the error in the IML and restarts the server. The system ROM pages the designated administrator, then executes the normal restart process.

---

**IMPORTANT:** When you enable ASR-2 to restart into the operating system, Modem Dial-In Status, Network Status, and Modem Dial-Out Status are automatically disabled. In this mode, ASR-2 can page you if a critical error occurs, but you cannot access the server, and the server cannot dial out to a remote workstation.

---

If the ASR-2 feature cannot restart the server within 10 attempts, it logs a critical error in the IML and restarts the server into the Compaq Utilities, and puts the modem into auto-answer mode.

The System Configuration Utility setting should resemble the following when you enable ASR to restart into the operating system:

---

**Table 3-20**  
**OS Restart SCU Setting for ASR-2**

| Option                    | Setting         |
|---------------------------|-----------------|
| Serial interface          | COM1            |
| Dial-in status            | Disabled        |
| Dial-out status           | Disabled        |
| Dial-out string           | 555-1234        |
| Network status            | Disabled        |
| Network protocol          | IPX             |
| Network controller        | Compaq          |
| Network host name         | CPQHOU          |
| Network card slot         | Slot #          |
| Network frame type        | ETHERNET_II     |
| Network IP address        | xxx.xxx.xxx.xxx |
| Network IP net mask       | xxx.xxx.xxx.xxx |
| Network IP router address | xxx.xxx.xxx.xxx |

---

### **ASR-2 Security**

The standard Compaq password features function differently during ASR-2 than during a typical system startup. During ASR-2, the system does not prompt for the power-on password. This allows ASR-2 to restart the operating system or Compaq Utilities without user intervention.

To maintain system security, set the server to boot in Network Server Mode (an option in the System Configuration Utility). This option ensures that the server keyboard is locked until you enter the keyboard password.

Select an administrator password (an option in the System Configuration Utility). During attended ASR-2 (local or remote), you must enter this administrator password before any modifications can be made to the server configuration.

## ASR-2 Integrated Management Log Messages

The Integrated Management Log (IML) records memory errors, as well as catastrophic hardware and software errors that cause the system to fail. This information helps you quickly identify and correct the problem, thus minimizing downtime.

You can view the IML through Compaq Insight Manager. The Diagnostics Utility either resolves the error or suggests corrective action in systems that do not support event logs.

The IML or Integrated Management Log identifies and records all the following errors. Each error type is explained below.

**Table 3-21**  
**ASR-2 IML Messages**

| Message  | Description  |
|--|--|
| Abnormal Program Termination                           | The operating system has encountered an abnormal situation that has caused a system failure.   |
| ASR-2 detected by ROM                                  | An ASR-2 activity has been detected and logged by the system ROM.  |
| ASR-2 Test Event                                       | The System Configuration Utility generated a test alert.   |
| Automatic Server Recovery Base Memory Parity Error     | The system detected a data error in base memory following a reset due to the Automatic Server Recovery-2 (ASR-2) timer expiration.   |
| Automatic Server Recovery Extended Memory Parity Error | The system detected a data error in extended memory following a reset due to the ASR-2 timer expiration.   |
| Automatic Server Recovery Memory Parity Error          | The system ROM was unable to allocate enough memory to create a stack. Then, it was unable to put a message on the screen or continue starting the server.                                 |
| Automatic Server Recovery Reset Limit Reached          | The maximum number of system resets due to ASR-2 timer expiration has been reached, resulting in the loading of Compaq Utilities.  |
| Battery Failing  | Low system battery warning. Replace battery within 7 days to prevent loss of nonvolatile configuration memory. Failure of the battery supporting the system's nonvolatile RAM is imminent. |

*continued*

**Table 3-21**  
**ASR-2 IML Messages** *continued*

| Message   | Description   |
|---|---|
| Caution: Temperature Exceeded                     | The operating system has detected that the temperature of the system has exceeded the caution level. Accompanying data in the log notes if an auto-shutdown sequence has been invoked by the operating system.      |
| Diagnostic Error                                  | An error was detected by the Diagnostics Utility. See the specific error code in this chapter for a detailed explanation.   |
| Error Detected On Boot Up                         | The server detected an error during the Power-On Self-Test (POST).  |
| Processor Prefailure                              | A CPU has passed an internal corrected error threshold; excessive internal ECC cache errors.  |
| NMI - PCI Bus Parity Error                        | A parity error was detected on the PCI bus.   |
| NMI - Expansion Board Error                       | A board on the expansion bus indicated an error condition, resulting in a server failure.   |
| NMI - Expansion Bus Master Time-Out               | A bus master expansion board in the indicated slot did not release the bus after its maximum time, resulting in a server failure.   |
| NMI - Expansion Bus Slave Time-Out                | A board on the expansion bus delayed a bus cycle beyond the maximum time, resulting in a server failure.  |
| NMI - Fail-Safe Timer Expiration                  | Software was unable to reset the system fail-safe timer, resulting in a server failure.   |
| Processor Exception                               | The indicated processor exception occurred.   |
| NMI - Processor Parity Error                      | The processor detected a data error, resulting in a server failure.   |
| Server Manager Failure                            | An error occurred with the Server Manager/R.  |
| NMI - Software Generated Interrupt Detected Error | Software indicated a system error, resulting in a server failure.   |
| Caution: Temperature Exceeded                     | The operating system has detected that the temperature of the system has exceeded the caution level. Accompanying data in the log notes whether an auto-shutdown sequence has been invoked by the operating system. |
| Abnormal Program Termination                      | The operating system has encountered an abnormal situation that has caused a system failure.  |
| ASR-2 Test Event                                  | The System Configuration Utility generated a test alert.  |
| NMI - Automatic Server Recovery Timer Expiration  | The operating system has received notice of an impending ASR-2 timer expiration.  |
| Required System Fan Failure                       | The required system fan has failed. Accompanying data in the log notes if an auto-shutdown sequence has been invoked by the operating system.   |
| UPS A/C Line Failure Shutdown or Battery Low      | The UPS notified the operating system that the AC power line has failed. Accompanying data indicates whether either an auto-shutdown sequence has been invoked or the battery is nearly depleted.                   |
| ASR-2 detected by ROM                             | An ASR-2 activity has been detected and logged by the system ROM.   |

## Revision History Table

Some errors can be resolved by reviewing changes to the server configuration. The server has an Automatic Revision Tracking (ART) feature that helps you review recent changes to the server configuration.

One ART feature is the Revision History Table, which contains the hardware version number of the system board and any other system boards providing ART-compatible revision information. This feature lets you determine the level of functionality of an assembly in a system without opening or powering down the unit.

**Table 3-22**  
**Revision History Table**

| Current Revisions         |          |
|---------------------------|----------|
| Date                      | 10/21/99 |
| System board revision     | 03       |
| Assembly version          | 1        |
| Functional revision level | C        |
| Processor 01 revision     | 01       |
| Assembly version          | 1        |
| Functional revision level | A        |
| Previous Revisions        |          |
| Date                      | 10/31/95 |
| System board revision     | 03       |
| Assembly version          | 1        |
| Functional revision level | C        |
| Processor 01 revision     | 01       |
| Assembly version          | 1        |
| Functional revision level | A        |

The Revision History Table is stored in nonvolatile RAM and is accessed through the Inspect Utility and Compaq Insight Manager.

## **Storage Fault Recovery Tracking**

This feature tracks over 12 failure-indication parameters, such as timeouts, spin-up, and self-test errors of SCSI drives. You can use these parameters to pinpoint failed storage subsystem components and to recover from controller or hard drive failure.

## **Storage Automatic Reconstruction**

This feature automatically reconstructs data to an online spare or to a replaced drive if a drive fails. To use the reconstruction feature, you must configure the server for drive mirroring or data guarding. The reconstruction decreases system downtime by allowing rapid recovery to full system operation if a drive fails.

## **Network Interface Fault Recovery Tracking**

This feature tracks over 20 failure-indication parameters, such as alignment errors, lost frames, and frame copy errors, of Ethernet and Token Ring network interfaces. It decreases network downtime by enabling diagnosis of actual network interface failures.

## **Memory Fault Recovery Tracking**

This feature inspects the operation of the memory subsystem looking for uncorrectable memory errors.



## Remote Service Features

Compaq servers have the following management features that you can access through a modem or a network:

**Table 3-23**  
**Compaq Servers Remote Management Features**

| Feature                | Description   |
|------------------------|---|
| Service Session        | Provides remote access to all the utilities on the Compaq system partition, including Diagnostics utilities, Inspect, ROMPaq, Drive Array Advanced Diagnostics (DAAD), and the System Configuration Utility. Also provides the capability for remote file transfer services to and from the Compaq system partition.  |
| Disk-Based Diagnostics | Provides remote diagnostic capability after you configure ASR-2 and the reset restart option to restart from Compaq Utilities. Also allows you to view Health Logs. Disk-based diagnostics can also be run locally. Press <b>F10</b> during the restart process when the cursor moves to the upper-right corner of the monitor.   |
| Server Restart         | Provides the ability to restart the server remotely from Compaq Insight Manager while the operating system is running. Allows the server to restart back to the operating system or restart to the Compaq system partition. Provides a complete system reset to all peripherals. If you select Boot to Compaq Utilities from Compaq Insight Manager, Compaq Utilities loads the appropriate remote services so that remote access is available. If network status is enabled, network support is loaded. If Dial-In status is enabled, the modem is set to auto-answer. |
| Configuration Utility  | Allows you to run the remote System Configuration Utility locally. Press <b>F10</b> during the restart process when the cursor moves to the upper-right corner of the monitor.  |
| Firmware Updates       | Allows you to update the server firmware remotely. Uses firmware images on the Compaq system partition that might have been previously uploaded with the file transfer services.  |

## ROMPaq Error Recovery Options

From time to time it may be desirable to upgrade the current system ROM. Some reasons for this may be as follows:

- Customer requires ROM upgrade
- Obtained new SmartStart CD-ROM
- Desire to upgrade server processors
- Request from Compaq

The process of upgrading the system ROM is referred to as flashing the ROM. Flashing consists of using software to replace the current ROM image with a new one through ROMPaq.

Should an error such as a power failure occur during this process, the flash operation will not be completed, causing the ROM image in the server to be corrupted. Compaq provides two options for ROMPaq recovery, depending on the server and circumstances involved.

## ROMPaq Disaster Recovery

The following option should be utilized by any server that does not have a valid ROM image.

1. Build a fresh ROMPaq diskette, using the latest version for the server involved.

**NOTE:** If the ROM is corrupted by a ROMPaq interruption, the initial ROMPaq attempt may have affected the contents of the original diskette.

2. Turn off the server.
3. Set configuration switches 1, 4, 5, and 6 on the system maintenance switch block to On to enable disaster mode.

---

**Table 3-24**  
**Configuration Switches**

| Switch | Function                  |
|--------|---------------------------|
| 1      | Disable on-board graphics |
| 4      | Disable diskette drive    |
| 5      | Disable password          |
| 6      | Clear NVRAM               |

4. Insert the ROMPaq diskette. Although you will utilize a normal ROMPaq diskette, this situation will not allow you to save the old image.
5. Turn on the server. The keyboard, mouse and monitor are all inactive.
6. The server makes two long beeps, to indicate that you are in Disaster Recovery Mode and that you should insert the ROMPaq diskette.
7. The server reads the diskette for the latest ROM image. If the diskette is not in place, the system continues to beep until a valid ROMPaq diskette is inserted.
8. After successful completion of this process,
  - a. Turn off the server.
  - b. Remove the diskette.
  - c. Reset configuration switches 1, 4, 5 and 6. (Refer to Configuration Switches Table 3-24 within this section.)
  - d. Turn on the server as usual.

After a failed ROMPaq, power down the server and repeat the above process.

## Compaq Insight Manager

Compaq Insight Manager is the Compaq application for easily managing network devices. Compaq Insight Manager delivers intelligent monitoring and alerting as well as visual control of the servers.

In Compaq servers, every hardware subsystem, such as disk storage, system memory, and system processor, has a robust set of management capabilities. Compaq Full-Spectrum Fault Management prevents faults before they happen, keeps the system up and running in the unlikely event of a failure, and delivers rapid server recovery to normal operation after a fault.

### Features of Compaq Insight Management

Compaq Insight Management features include:

- **Web browser access**—to Insight Manager Device and Configuration information from anywhere you have network access and a standard Web browser for Windows NT and NetWare servers.
- **Comprehensive fault management**—for all major subsystems, including prefailure alerts in advance of potential system failures.

**NOTE:** Compaq Insight Manager will not support pre-failure alerts from the stored storage area in a ProLiant CL1850.

- **Broad configuration management**—provides effective deployment and maintenance of consistent, manageable configurations with Insight Version Control and Integration Server Maintenance. Version Control and Integration Server Maintenance allows the administrator to monitor and update versions of the server and workstation firmware, drivers and utilities.
- **Performance management**—sets performance and capacity thresholds for management variables related to CPU and bus utilization, NIC throughput, logical disk capacity, and more.
- **Workstation management**—monitors and manages Compaq Professional Workstations.
- **Client management**—manages faults and assets on Compaq Deskpro computers.
- **Netelligent management**—receives alarms from Netelligent devices. Full management of Netelligent devices is supported through integration with Compaq Netelligent Management Software.
- **Asset management**—exports asset information from the Compaq Insight Manager database to leading database and spreadsheet applications.
- **Remote management**—manages in-band or out-of-band devices, online or offline, from any location.
- **Integration can be provided for enterprise management platforms**—provides integration with leading management platforms including HP OpenView, IBM NetView, SunNet Manager, and Microsoft Systems Management Server.
- **Full integration with Compaq Remote Insight Board/PCI and ProLiant Integrated Remote Console**—allows “in-band” and “out-of-band” connection for server management to ensure that customers are in touch with their systems, even when they are offline or without power.

- **SNMP standards**—allow integration with other management products.
- **Flexible network conductivity**—supports multiple transport protocols including IPX, TCP/IP and PPP to operator over LANs, WANs, and modems.
- **Support for these operating systems:**
  - Microsoft Windows NT
  - Novell NetWare, intraNetWare 2000 and IntranetWare for Small Business
  - SCO UNIX, OpenServer, and UnixWare
  - IBM OS/2 Warp family of products
- **Reporting**—using Automatic Data Collection, gathers historic performance information for graphing or export purposes.

## Compaq Insight Management Software Architecture

The Compaq Insight Management software architecture is typical of other network management solutions. It has a client/server architecture and is composed of agent software (Compaq Insight Management Agents) and the management application software (Compaq Insight Manager).

### Insight Management Agents

Insight Agents operate on Compaq systems (such as servers and workstations), performing in-depth monitoring of the system's state by collecting and measuring system parameters. These parameters indicate the current state of subsystems by counting the occurrence of particular events (for example, the number of read operations performed on a disk drive) or monitoring the state of a critical function (such as whether the cooling fan is operating).

Insight Desktop Agents operate on Compaq Deskpro computers, monitoring functions that include temperature sensing and disk prefailure alerting.

Insight Agents provide information to management applications, such as Compaq Insight Manager, and can generate alarm notifications if significant changes occur in the fault or performance aspects of system operation. Information is delivered to and from the Insight Agents by the industry-standard Simple Network Management Protocol or SNMP.

### Compaq Insight Manager

Compaq Insight Manager delivers intelligent monitoring and alerting as well as visual control of the Compaq hardware. In the unlikely event of hardware failures, Compaq Insight Manager also provides a full complement of remote maintenance and control facilities.

For additional information, refer to the online *Compaq Insight Manager User Guide* on the server documentation CD that accompanied the server.

## *Chapter* **4**

# **Connectors, Switches, and Status Indicators**

## **Connectors**

This section contains graphics and tables showing connector locations on the rear panel, the riser board, and the system board.

## Rear Panel Components




Figure 4-1. Rear panel components

**Table 4-1**  
**Rear Panel Components**

| Item | Description  |
|------|--|
| ①    | External SCSI port   |
| ②    | Video (blue) port  |
| ③    | RJ-45 Ethernet with 10/100-Mbit operation port with LED indicator              |
| ④    | Parallel printer port (burgundy)   |
| ⑤    | Serial port B (teal)   |
| ⑥    | Serial port A (teal)   |
| ⑦    | Hot-plug keyboard connector (purple)   |
| ⑧    | Mouse connector (green)  |
| ⑨    | External SCSI access   |
| ⑩    | Hot-plug redundant power supply bay (supports optional redundant power supply) |
| ⑪    | Hot-plug power supply  |

## Riser Board Expansion Slots




Figure 4-2. Riser board expansion slots

**Table 4-2**  
**Riser Board Expansion Slots**

| Item | Description     |
|------|-----------------|
| ①    | 32-bit PCI slot |
| ②    | 64-bit PCI slot |
| ③    | 64-bit PCI slot |
| ④    | 64-bit PCI slot |

## System Board Components




Figure 4-3. System board components

**Table 4-3**  
**System Board Components**

| Item | Description                       | Item | Description                         |
|------|-----------------------------------|------|-------------------------------------|
| 1    | DIMM slots                        | 11   | Virtual power button connector      |
| 2    | Processor slot 1 (populated)      | 12   | Reserved                            |
| 3    | Processor slot 2                  | 13   | Diskette drive connector            |
| 4    | Riser board slot                  | 14   | CD-ROM drive connector              |
| 5    | CPU fan header                    | 15   | CD-ROM drive audio connector        |
| 6    | SCSI port 1                       | 16   | Processor Power Module (PPM) slot 2 |
| 7    | SCSI port 2                       | 17   | PPM slot 1                          |
| 8    | Integrated Smart Array Controller | 18   | Power supply fan header             |
| 9    | Battery                           | 19   | Power supply signal cable header    |
| 10   | Power switch connector            | 20   | Power supply power connector        |



## Switches

The Compaq ProLiant DL380 Server has two switchbanks (SW1 and SW2) located on the system board. These switches are used to set the configuration of the server. SW1 is used as a system identification switch and the setting is pre-set in the factory. Do not change these settings. Incorrectly set switches may result in damage to the server.

### System Configuration Switchbank (SW2)

The system configuration switchbank (SW2) is a six-position switch that is used for system configuration. The position of SW2 on the system board is shown in Figure 4-4, and the default switch settings are shown in Table 4-4.




Figure 4-4. Location of switchbank SW2

**Table 4-4**  
**System Configuration Switchbank (SW2) Settings**

| Item | Description                  | Default Setting |
|------|------------------------------|-----------------|
| ①    | Embedded video disable       | Off             |
| ②    | Configuration lock           | Off             |
| ③    | Rack mount                   | On              |
| ④    | Diskette drive boot override | Off             |
| ⑤    | Password disable             | Off             |
| ⑥    | Maintenance                  | Off             |

## LED Indicators

This section contains graphics and tables showing LED indicator locations and descriptions on the following components:

- Power switch
- Hot-plug power supply
- RJ-45 connector
- System board
- SCSI hard drive
- Low-profile IDE CD-ROM drive
- 1.44-MB diskette drive
- Riser board

## Power Switch LED Indicators




Figure 4-5. Power switch LED indicators

**Table 4-5**  
**Power Switch LED Indicators**

| Item | Description   | Status   |
|------|---|--|
| ①    | Power On/Standby  | Amber = Standby<br>Green = On  |
| ②    | Disk activity (including the CD-ROM drive and hot-plug hard drives) | Green = Drive activity<br>Off = No drive activity                                  |
| ③    | EMB, NIC link status  | Green = Embedded NIC linked to network<br>Off = Embedded NIC not linked to network |
| ④    | EMB, NIC activity   | Green = Embedded NIC activity<br>Off = No embedded NIC activity                    |

**Note:** When in Standby mode, NIC LED indicators are not operational.

## Hot-Plug Power Supply LED Indicators

Each power supply has a single LED indicator. See Figure 4-6 and Table 4-6 for a detailed description of the indicator.




Figure 4-6. Hot-plug power supply LED indicators

**Table 4-6**  
**Hot-Plug Power Supply LED Indicators**

| Item | Status | Condition   |
|------|--------|---|
| 1    | Green  | AC power is connected to this power supply. The server is powered up.                             |
|      | Off    | No AC power is connected to this supply. The server is in Standby or the power supply has failed. |

## RJ-45 LED Indicators

There are two LED indicators on the RJ-45 connector. See Figure 4-7 and Table 4-7 for a detailed description of both indicators.




Figure 4-7. RJ-45 LED indicators

**Table 4-7**  
**RJ-45 LED Indicators**

| Item | Status | Condition         |
|------|--------|-------------------|
| ❶    | Green  | Activity          |
|      | Off    | No activity       |
| ❷    | Green  | NIC is linked     |
|      | Off    | NIC is not linked |

## System Board LED Indicators

There are six LED indicators on the system board. See Figure 4-8 and Table 4-8 for a detailed description of these indicators.




Figure 4-8. System board LED indicators

**Table 4-8**  
**System Board LED Indicators**

| Item | Status  | Condition         |
|------|---|-------------------|
| ①    | Green = Power to system<br>Off = System in Standby or Off         | System power good |
| ②    | Red = Processor 1 internal error<br>Off = Normal                  | IEFF1             |
| ③    | Red = Processor 2 internal error<br>Off = Normal                  | IEFF2             |
| ④    | Red = Riser card not seated<br>Off = Normal, riser card is seated | Interlock         |

## SCSI Hard Drive LED Indicators




Figure 4-9. SCSI hard drive LED indicators

## Low-Profile IDE CD-ROM Drive LED Indicator




Figure 4-10. Low-profile CD-ROM drive LED indicator

**Table 4-9**  
**Low-Profile CD-ROM Drive LED Indicator**

| Item | Status | Condition   |
|------|--------|-------------|
| 1    | On     | Activity    |
|      | Off    | No activity |



## 1.44-MB Diskette Drive LED Indicator




Figure 4-11. 1.44-MB diskette drive LED indicator

**Table 4-10**  
**1.44-MB Diskette Drive LED Indicator**

| Item | Status | Condition   |
|------|--------|-------------|
| 1    | On     | Activity    |
|      | Off    | No activity |

## Riser Board LED Indicator

The riser board has one LED indicator. See Figure 4-12 and Table 4-11 for a description of this indicator.




Figure 4-12. Riser board LED indicator

**Table 4-11**  
**Riser Board LED Indicator**

| Item | Status | Condition                         |
|------|--------|-----------------------------------|
| 1    | Amber  | AC power connected to server      |
|      | Off    | AC power disconnected from server |

# *Chapter* **5**

## **Specifications**

This chapter provides operating and performance specifications for Compaq ProLiant DL380 Servers and optional hardware. The sections in this chapter are:

- System Unit
- Hot-Plug Power Supply
- Memory
- 1.44-MB Diskette Drive
- Low-Profile IDE CD-ROM Drive
- Wide Ultra2 SCSI Hot-Plug Hard Drive
- Integrated Smart Array Controller
- NC3163 Embedded 10/100 Fast Ethernet NIC Controller (Wake on LAN)
- Smart Array 221 Controller (optional)
- Smart Array 3200 Controller (optional)
- Smart Array 4200 Controller (optional)
- NC3131 Fast Ethernet NIC 64 PCI Dual Base 10/100 (optional)
- Optional 2x1-Inch Hot-Plug Hard Drive Cage

## System Unit

**Table 5-1**  
**System Unit Specifications**

| <b>Item</b>                              | <b>Description</b>          |
|--|-----------------------------|
| Height                                   | 12.9 cm (5.1 inch)          |
| Depth                                    | 56.1 cm (22.1 inch)         |
| Width                                    | 45.00 cm (17.7 inch)        |
| Weight (fully configured)                | 15.9 kg (35.0 lb)           |
| International input voltage requirements |                             |
| Rated input voltage                      | 100-240 VAC                 |
| Rated input frequency                    | 50-60 Hz                    |
| Rated input current                      | 4.8 A, 2.4 A (110V, 220V)   |
| U.S. input voltage requirements          |                             |
| Rated input voltage                      | 100-240 VAC                 |
| Rated input frequency                    | 50-60 Hz                    |
| Rated input current                      | 4.8 A, 2.4 A (110V, 220V)   |
| Power supply output power                |                             |
| Rated steady-state power                 | 275 W                       |
| Maximum peak power                       | 306 W                       |
| BTUs                                     | 1475 BTU/h                  |
| Temperature range                        |                             |
| Operating                                | 10° to 35°C (50° to 95°F)   |
| Nonoperating                             | -20° to 50°C (-4° to 122°F) |
| Relative humidity (noncondensing)        |                             |
| Operating                                | 8% to 90%                   |
| Nonoperating                             | 5% to 95%                   |
| Maximum wet bulb temperature             | 38.7°C (101.7°F)            |

## Hot-Plug Power Supply

**Table 5-2**  
**Hot-Plug Power Supply Specifications**

| Item                              | Description                            |
|-----------------------------------|--|
| Input voltage specifications      |  |
| Rated input voltage               | 100 VAC to 240 VAC                     |
| Rated input line                  | 180 VAC to 264 VAC (90 VAC to 132 VAC) |
| Frequency range                   | 50Hz to 60 Hz                          |
| Rated input power                 | 432 W                                  |
| Rated input current               | 4.8A 2.4A (110V, 220V)                 |
| Steady state power                | 275 W                                  |
| Maximum peak power                | 305 W                                  |
| Ambient temperature range         |  |
| Operating                         | 10°C to 35°C (41°F to 113°F)           |
| Shipping                          | -30°C to 50°C (-40°F to 185°F)         |
| Relative humidity (noncondensing) |  |
| Operating                         | 80% to 90%                             |
| Nonoperating                      | 5% to 95%                              |
| Dielectric voltage withstand      |  |
| Input to output                   | Dielectric voltage withstand           |
| Input to ground                   | Input to output                        |
| Input transient susceptibility    | Input to ground                        |
| Maximum wet bulb temperature      | 38.7°C                                 |

## Memory

**Table 5-3**  
**SDRAM DIMM Specifications**

| Item  | Description  |
|---|--|
| Size  | 64-MB, 128-MB, 256-MB, 512-MB, 1-GB                                  |
| Speed   | 133-MHz minimum  |
| Width   | 72 bits  |
| Upgrade requirement   | Any combination of SDRAM DIMM (minimum 128-MB total memory required) |
| <b>Note:</b> Use only 64-, 128-, 256-, 512-MB, or 1-GB registered, 72-bit wide, 3.3-volt, registered ECC SDRAM. SDRAM must be 133-MHz or faster. Use Compaq SDRAM only. |  |

## 1.44-MB Diskette Drive

**Table 5-4**  
**1.44-MB Diskette Drive Specifications**

| Item  | Description        |
|---|--------------------|
| Size  | 8.89 mm (3.5 inch) |
| LED indicator (front panel)                         | Green              |
| Read/write capacity per diskette (high/low density) | 1.44 MB/720 KB     |
| Drives supported                                    | 1                  |
| Drive height  | Third, 1.0 inch    |
| Drive rotation                                      | 300 rpm            |
| Transfer rate bits/sec (high/low)                   | 500/250 Kb/s       |
| Bytes/sector  | 512                |
| Sectors/track (high/low)                            | 18/9               |
| Tracks/side (high/low)                              | 80/80              |
| Access times  |                    |
| Track-to-track (high/low)                           | 6 ms/3 ms          |
| Average (high/low)                                  | 169 ms/94 ms       |
| Settling time                                       | 15 ms              |
| Latency average                                     | 100 ms             |
| Cylinders (high/low)                                | 80/80              |
| Read/write heads                                    | 2                  |

## Low-Profile IDE CD-ROM Drive

**Table 5-5**  
**Low-Profile IDE CD-ROM Drive Specifications**

| Item                   | Description   |
|------------------------|---|
| Applicable disk        | CD-DA, CD-ROM (mode 1 and 2); CD-XA (mode 2, Form 1 and 2), CD-1 Ready; CD-Extra; Photo CD (single and multiple session); CDi ready |
| Capacity               | 550 MB (mode 1, 12 cm)<br>640 MB (mode 2, 12 cm)  |
| Block size             | 2638, 2352 bytes (mode 0); 2352, 2340, 2336, 1024 bytes (mode 1);<br>2352, 2340, 2336, 2048, 1024 bytes (mode 2)                    |
| Dimensions             |   |
| Height                 | 12.7 mm (0.5 inch)  |
| Depth                  | 130 mm (5.12 inch)  |
| Width                  | 131 mm (5.16 inch)  |
| Weight                 | <340 g (<11.98 oz)  |
| Data transfer rate     |   |
| Sustained              | 150 KB/s (sustained 1X)   |
| Burst                  | 2100-4800 KB/s  |
| Access times (typical) |   |
| Full stroke            | <350 ms   |
| Random                 | <150 ms   |
| Disc diameter          | 12 cm, 8 cm (4.7 inch, 3.15 inch)   |
| Disc thickness         | 1.2 mm, 0.05 cm (.047 inch x .20 inch)  |
| Track pitch            | 1.6 $\mu$ m   |
| Cache/buffer           | 128 KB  |
| Startup time           | <7s   |
| Stop time              | <4s (single); <30s (multi-session)  |
| Laser parameters       |   |
| Type                   | Semiconductor Laser   |
| Wave length            | 700 $\pm$ 25nm  |
| Divergence angle       | 53.5 $^{\circ}$ $\pm$ 1.5 $^{\circ}$  |
| Output power           | 0.13 mW   |
| Operating conditions   |   |
| Temperature            | 5 $^{\circ}$ to 45 $^{\circ}$ C (41 $^{\circ}$ to 118 $^{\circ}$ F)   |
| Humidity               | 5% - 90% (10% to 80%)   |

## Wide Ultra2 SCSI Hot-Plug Hard Drive

**Table 5-6**  
**Wide Ultra2 SCSI Hot-Plug Hard Drive Specifications**

|                                 | 9.1 GB           | 9.1 GB           | 18.2 GB          | 18.2 GB          |
|---------------------------------|------------------|------------------|------------------|------------------|
| Logical capacity                | 9100 MB          | 9100 MB          | 18209 MB         | 18209 MB         |
| Height                          | Third, 1.0 inch  | Third, 1.0 inch  | Third, 1.0 inch  | Third, 1.0 inch  |
| Size                            | 3.5 inches       | 3.5 inches       | 3.5 inches       | 3.5 inches       |
| Interface                       | Wide Ultra2 SCSI | Wide Ultra2 SCSI | Wide Ultra2 SCSI | Wide Ultra2 SCSI |
| Transfer rate synchronous (Max) | 80 MB/s          | 80 MB/s          | 80 MB/s          | 80 MB/s          |
| Single track                    | 0.8 ms           | 0.8 ms           | 0.8 ms           | 0.8 ms           |
| Average                         | 7.9 ms           | 5.4 ms           | 6.9 ms           | 7.5 ms           |
| Full stroke                     | 17.0 ms          | 12.2 ms          | 15.0 ms          | 16.0 ms          |
| Rotational speed                | 7200 rpm         | 10,000 rpm       | 7200 rpm         | 10,000 rpm       |
| Bytes/sector                    | 512              | 512              | 512              | 512              |
| Logical blocks                  | 17,773,524       | 17,773,524       | 35,556,080       | 35,556,080       |
| Operating temperature           |                  |                  |                  |                  |
| Celsius                         | 10° to 35°       | 10° to 35°       | 10° to 35°       | 10° to 35°       |
| Fahrenheit                      | 50° to 95°       | 50° to 95°       | 50° to 95°       | 50° to 95°       |



## Integrated Smart Array Controller

**Table 5-7**  
**Integrated Smart Array Controller Specifications**

| Item   | Description                                     |
|--|---|
| Temperature range (noncondensing)            |   |
| Operating                                    | 10° to 35°C (50° to 95°F)                       |
| Shipping                                     | -20° to 50°C (-4° to 122°F)                     |
| Relative humidity (noncondensing)            |   |
| Operating                                    | 8% to 90%                                       |
| Nonoperating                                 | 5% to 95%                                       |
| Maximum drives supported                     | Up to 15 per channel                            |
| Logical drives supported                     | 32  |
| Simultaneous drive transfer channels         | 2   |
| Data transfer method                         | 32-bit PCI bus master                           |
| Total transfer rate                          | 160 MB/s (80 MB/s per channel)                  |
| SCSI electrical interface                    | Low-voltage differential (LVD) and single ended |
| PCI bus transfer rate (maximum)              | 133 MB/s  |
| SCSI port connectors (internal and external) | PCI 64D extended SCSI connector                 |
| Protocol                                     | Wide Ultra2 SCSI                                |
| Software upgradable firmware                 | Yes   |
| Read cache                                   | 8 MB  |

## NC3163 Embedded 10/100 Fast Ethernet NIC Controller (Wake On LAN)

**Table 5-8**  
**NC3163 Embedded 10/100 Fast Ethernet NIC Controller (Wake On LAN)**  
**Specifications**

| <b>Dimensions</b>                 | <b>Metric (U.S.)</b>         |
|-----------------------------------|------------------------------|
| Operating speed                   | 10/100 Mbits/s               |
| Transfer rate                     | 133 MB/s                     |
| Data transfer method              | 32-bit PCI bus master        |
| Temperature range                 |                              |
| Operating                         | 0° to 55°C (32° to 131°F)    |
| Nonoperating                      | -65° to 85°C (-85° to 185°F) |
| Relative humidity (noncondensing) |                              |
| Operating                         | 10 to 90%                    |
| Nonoperating                      | 5% to 95%                    |
| Power required                    | 195 mA@5V max                |
| Emissions standards               | FCC class A                  |
| Safety compliance                 | CE Mark                      |

## Smart Array 221 Controller

**Table 5-9**  
**Smart Array 221 Controller Specifications**

| Item                                    | Description                                     |
|---|---|
| Dimensions                              |   |
| Height                                  | 13.7 cm (5.4 inch)                              |
| Length                                  | 12.4 cm (31.5 inch)                             |
| Thickness (including array accelerator) | 2.5 cm (1.0 inch)                               |
| Temperature range                       |   |
| Operating                               | 10° to 35° (C50° to 95°F)                       |
| Nonoperating                            | -30° to 60°C (-22° to 140°F)                    |
| Relative humidity (noncondensing)       |   |
| Operating                               | 20% to 80%                                      |
| Nonoperating                            | 5% to 90%                                       |
| Power required                          |   |
|   | +3.3V/300 mA                                    |
|   | +5V/3.0A  |
|   | +12V/60 mA                                      |
|   | -12V/0 mA                                       |
| Heat dissipated (maximum)               | 16.7 W  |
| Maximum physical drives supported       | 18  |
| Logical drives supported                | 32  |
| Simultaneous drive transfer channels    | 2   |
| Data transfer method                    | 32-bit PCI bus master                           |
| Total transfer rate                     | 160 MB/s per channel                            |
| SCSI electrical interface               | Low-voltage differential (LVD) and single-ended |
| PCI bus transfer rate (maximum)         | 133 MB/s  |
| SCSI port connectors                    | PCI 64D extended SCSI connector                 |

## Smart Array 3200 Controller

**Table 5-10**  
**Smart Array 3200 Controller Specifications**

| Item                                    | Description                                     |
|---|---|
| Dimensions                              |   |
| Height                                  | 13.7 cm (5.4 inch)                              |
| Length                                  | 12.4 cm (31.5 inch)                             |
| Thickness (including array accelerator) | 2.5 cm (1.0 inch)                               |
| Temperature range                       |   |
| Operating                               | 10° to 35° (C50° to 95°F)                       |
| Nonoperating                            | -30° to 60°C (-22° to 140°F)                    |
| Relative humidity (noncondensing)       |   |
| Operating                               | 20% to 80%                                      |
| Nonoperating                            | 5% to 90%                                       |
| Power required                          |   |
|   | +3.3V/300 mA                                    |
|   | +5V/3.0A  |
|   | +12V/60 mA                                      |
|   | -12V/0 mA                                       |
| Heat dissipated (maximum)               | 16.7 W  |
| Maximum drives supported                | 18  |
| Logical drives supported                | 32  |
| Simultaneous drive transfer channels    | 2   |
| Data transfer method                    | 32-bit PCI bus master                           |
| Total transfer rate                     | 160 MB/s per channel                            |
| SCSI electrical interface               | Low-voltage differential (LVD) and single-ended |
| PCI bus transfer rate (maximum)         | 133 MB/s  |
| SCSI port connectors                    | PCI 64D extended SCSI connector                 |

## Smart Array 4200 Controller

**Table 5-11**  
**Smart Array 4200 Controller Specifications**

| Item                                    | Description                                     |
|---|---|
| Dimensions                              |   |
| Height                                  | 13.7 cm (5.4 inch)                              |
| Length                                  | 12.4 cm (31.5 inch)                             |
| Thickness (including Array accelerator) | 2.5 cm (1.0 inch)                               |
| Temperature range                       |   |
| Operating                               | 10° to 35° (50° to 95°F)                        |
| Nonoperating                            | -30° to 60°C (-22° to 140°F)                    |
| Relative humidity (noncondensing)       |   |
| Operating                               | 20% to 80%                                      |
| Nonoperating                            | 5% to 90%                                       |
| Power required                          |   |
|   | +3.3V/300 mA                                    |
|   | +5V/3.0A  |
|   | +12V/60 mA                                      |
|   | -12V/0 mA                                       |
| Heat dissipated (maximum)               | 16.7 W  |
| Maximum drives supported                | 18  |
| Logical drives supported                | 32  |
| Simultaneous drive transfer channels    | 2   |
| Data transfer method                    | 32-bit PCI bus master                           |
| Total transfer rate                     | 160 MB/s (80-MBs per channel)                   |
| SCSI electrical interface               | Low-voltage differential (LVD) and single-ended |
| PCI bus transfer rate (maximum)         | 133 MB/s  |
| SCSI port connectors                    | PCI 64D extended SCSI connector                 |

## NC3131 Fast Ethernet NIC 64 PCI Dual Base 10/100

**Table 5-12**  
**NC3131 Fast Ethernet NIC 64 PCI Dual Base 10/100 Specifications**

| <b>Item</b>                             | <b>Description</b>           |
|---|------------------------------|
| Dimensions                              |                              |
| Height                                  | 9.9 cm (3.9 inches)          |
| Depth                                   | 16.5 cm (6.5 inches)         |
| Thickness (including array accelerator) | 6.4 cm (2.5 inches)          |
| Temperature range                       |                              |
| Operating                               | 0° to 55°C (32° to 131°F)    |
| Nonoperating                            | -65° to 85°C (-85° to 185°F) |
| Relative humidity (noncondensing)       |                              |
| Operating                               | 10% to 90%                   |
| Nonoperating                            | 5% to 95%                    |
| Bus master interface                    | 32/64 bit PCI                |
| Power required                          | 1050 mA@5V max               |
| Emissions standards                     | FCC class A                  |
| Safety compliance                       | CE Mark                      |

## Optional 2x1-Inch Hot-Plug Drive Cage

**Table 5-13**  
**Optional 2x1-Inch Hot-Plug Drive Cage Specifications**

| Item                              | Description                                     |
|-----------------------------------|---|
| Dimensions                        |   |
| Height                            | 2.54 cm (1.0 inch)                              |
| Length                            | 17.74 cm (7.0 inch)                             |
| Thickness                         | 5.08 cm (2.0 inch)                              |
| Temperature range                 |   |
| Operating                         | 10° to 35° (C50° to 95°F)                       |
| Nonoperating                      | -30° to 60°C (-22° to 140°F)                    |
| Relative humidity (noncondensing) |   |
| Operating                         | 20% to 80%                                      |
| Nonoperating                      | 5% to 90%                                       |
| Power required                    |   |
|                                   | +3.3V/300 mA                                    |
|                                   | +5V/3.0A  |
|                                   | +12V/60 mA                                      |
|                                   | -12V/0 mA                                       |
| Heat dissipated (maximum)         | 16.7 W  |
| Maximum drives supported          | 2   |
| SCSI electrical interface         | Low-voltage differential (LVD) and single-ended |

# Index

## Symbols and Numbers

2x1-inch media device drive  
cage *See* media device  
drive cage

## A

### ADU

accessing 3-5  
description 3-3, 3-33  
diagnostic messages 3-34  
executing 3-6  
starting 3-33

### Array Configuration Utility

accessing 3-5, 3-6  
accessing from System  
Configuration 3-5, 3-6  
executing 3-6

Array Diagnostic Utility *See* ADU

ART, assembly version 3-63

### ASR-2

allowing network access 3-56  
attended recovery 3-51  
booting into Compaq  
Utilities 3-56  
booting into operating  
system 3-59  
configuring 3-50, 3-54  
default value 3-54  
description 3-49  
dial-in status, restart  
setting 3-59  
dial-out status, restart  
setting 3-59  
dial-out string, restart  
setting 3-59  
features 3-53  
flow chart 3-55  
for off-site servers 3-54

for remote servers 3-54  
hardware requirements 3-52  
Integrated Management Log  
messages 3-61  
network card slot, restart  
setting 3-59  
network controller, restart  
setting 3-59  
network frame type, restart  
setting 3-59  
network host name, restart  
setting 3-59  
network IP address, restart  
setting 3-59  
network IP net mask, restart  
setting 3-59  
network IP router address, restart  
setting 3-59  
network protocol, restart  
setting 3-59  
network status, restart  
setting 3-59  
OS Restart SCU Setting,  
table 3-59  
paging administrator 3-50  
security 3-60  
serial interface, restart  
setting 3-59  
software error  
recovery 3-53  
recovery start option 3-53  
recovery timeout 3-53  
standby recovery  
server option 3-53  
server port 3-53  
time-out 3-53  
thermal shutdown 3-53  
timer 3-54  
unattended recovery 3-50  
UPS shutdown 3-53  
UPS shutdown threshold 3-53



ASR-2 IML log messages *See* error log messages  
Asset Management, defined 3-67  
audible beeps, during POST 3-8  
Automatic Data Collection, defined 3-68  
Automatic Revision Tracking *See* ART  
Automatic Server Recovery-2 *See* ASR-2  
automatic storage reconstruction, defined 3-64

## B

backplane board  
removing 2-21  
removing, illustrated 2-21  
replacing 2-21  
baffle, part number 1-6  
battery  
disposal 2-39  
location, identified 4-4  
part number 1-6  
removing 2-40  
removing, illustrated 2-40  
replacing 2-40  
beeps, during POST 3-8  
bezel, rack-mount  
part number 1-3  
removing 2-9  
removing, illustrated 2-9  
replacing 2-9  
BIOS settings, reconfiguring 2-39  
blank option board bracket, part number 1-6  
buns, part number 1-6

## C

cables  
14-pin power signal head cable, part number 1-6  
20-pin main power cable, part number 1-6  
CD data shredded, part number 1-6  
hard drive/CD power assembly, part number 1-6  
routing diagrams 2-25  
SCSI 1-device shredded, part number 1-6  
SCSI 2-device shredded, part number 1-6  
carton, part number 1-6  
cautions

ADU 3-33  
battery disposal 2-39  
BIOS settings 2-39  
cable routing 2-25  
controller firmware upgrade 3-33  
data loss 3-5  
defined vii  
diskette drive removal 2-10  
electrostatic discharge 2-5, 2-31, 2-33  
Erase Utility 3-5  
firmware upgrade 3-33  
grounding viii  
nonsupported drives 2-17  
overheating viii, 2-6  
removing all power from system 2-4  
symbols on equipment 2-3  
ventilation clearances viii  
CD tray assembly, part number 1-6  
CD-ROM drive  
access times 5-5  
applicable disk 5-5  
audio connector, identified 4-4  
block size 5-5  
cable routing, illustrated 2-25  
cables, part number 1-6  
cache/buffer 5-5  
capacity 5-5  
connector, identified 4-4  
data transfer rate 5-5  
depth 5-5  
diameter 5-5  
dimensions 5-5  
height 5-5  
laser parameters 5-5  
LED indicators, illustrated 4-12  
operating conditions 5-5  
part number 1-5  
removing 2-22  
removing, illustrated 2-22  
replacing 2-22  
specifications 5-5  
startup time 5-5  
stop time 5-5  
test error codes 3-32  
thickness 5-5  
track pitch 5-5  
weight 5-5  
width 5-5  
chassis, part number 1-3  
Client Management, defined 3-67  
communication parameters, setting 3-56

- Compaq download facility, telephone number ix
- Compaq Insight Management
  - features 3-67
  - software architecture 3-68
- Compaq Insight Manager
  - defined 3-44, 3-68
  - description 3-2
  - remote maintenance 3-68
  - viewing the event list 3-45
- Compaq Integrated Remote Console, features 3-54
- Compaq Network Interface Controller *See* NIC
- Compaq Survey Utility
  - description 3-2
  - installing 3-2
  - viewing 3-45
- Compaq system partition, accessing utilities from 3-5
- Compaq System Reference Library 3-49
- Compaq website ix
- Comprehensive Insight Management, defined 3-67
- conflict, resolving 3-3
- controllers
  - Integrated Smart Array 2-36
    - illustrated 2-37
    - removing 2-37
    - specifications 5-7
  - NC3163 Embedded 10/100 Fast Ethernet NIC controller
    - specifications 5-8
  - Smart Array 221,
    - specifications 5-9
  - Smart Array 3200,
    - specifications 5-10
  - Smart Array 4200,
    - specifications 5-11
- Correctable Memory Logs *See* IML
- country kit, part number 1-6
- cover
  - expansion slot, replacing 2-27
  - server
    - removing 2-7
    - removing, illustrated 2-7
    - replacing 2-7
- CPU fan
  - removing 2-35
  - removing, illustrated 2-35
  - replacing 2-35
- CPU fan header, identified 4-4

## D

- DAAD
  - accessing remotely 3-65
  - description 3-3
- DC-to-DC converter *See* Processor Power Module
- default configuration
  - determining 3-4
  - messages 3-4
- Diagnose Drive Array utility, accessing 3-23
- Diagnostics
  - accessing 3-2, 3-5
  - booting remotely 3-59
  - defined 3-23
  - description 3-2
  - diskette, creating 3-23
  - Drive Array 3-23
  - error codes 3-23
  - locating 3-2
  - overview 3-2
  - POST error messages 3-8
  - running 3-23
  - starting from CD 3-4
  - test error codes
    - CD-ROM drive 3-32
    - diskette drive 3-28
    - graphics display unit 3-27
    - hard drive 3-31
    - keyboard 3-26
    - memory 3-25
    - modem 3-29
    - NIC 3-30
    - pointing device
      - interface 3-33
    - processor 3-24
    - SCSI hard drive 3-31
    - SCSI tape drive 3-32
    - SCSI/IDE CD-ROM drive 3-32
    - serial port 3-29
    - tape drive 3-32
  - Test Error Codes Tables,
    - description 3-23
    - when to run 3-7
- dial-in status, setting 3-57
- dial-out status, setting 3-57
- dial-out string, setting 3-58
- DIMM slots, identified 4-4
- DIMMs *See* memory
- diskette drive
  - access times 5-4
  - cable routing, illustrated 2-25
  - connector, identified 4-4
  - cylinders 5-4

- disabling 3-66
- disabling boot 4-5
- height 5-4
- LED indicator 5-4
- LED indicator, illustrated 4-13
- number supported 5-4
- part number 1-5
- read/write capacity 5-4
- read/write heads 5-4
- removing 2-10
- removing, illustrated 2-10, 2-11
- replacing 2-11
- size 5-4
- specifications 5-4
- test error codes 3-28
- transfer rate 5-4
- diskette, creating Diagnostics 3-23
- Drive Array Advanced
  - Diagnostics *See* DAAD
- drive array, diagnosing 3-23
- drive bay positions, identified 2-17
- drive cage
  - cable routing, illustrated 2-26
  - option
    - dimensions 5-13
    - drives supported 5-13
    - height 5-13
    - temperature range 5-13
    - thickness 5-13
- removable media, part
  - number 1-3
- removing 2-20
- removing, illustrated 2-20
- replacing 2-20
- SCSI, part number 1-3
- specifications 5-13
- drive options, defined 2-17
- drivers, installing 3-3

## E

- electrostatic discharge,
  - precautions 2-2
- environmental recovery 3-50
- error codes *See also* test error codes
  - 101 through 105 3-8
  - 101 through 199 3-24
  - 1101 through 1199 3-29
  - 1151 3-11
  - 1152 3-11
  - 1201 through 1299 3-29
  - 1610 through 618 3-11
  - 162 through 164 3-8
  - 1620 through 622 3-12
  - 1703 3-12
  - 172 through 174 3-8

- 1720 through 1724 3-13
- 1726 through 1761 3-13
- 1764 through 1772 3-15
- 1773 through 1780 3-16
- 1781 through 1784 3-18
- 1785 3-18
- 1786 through 1788 3-19
- 1789 through 1794 3-21
- 1795 through 1799 3-22
- 180 3-9
- 200 through 215 3-25
- 201 through 215 3-9
- 216 through 221 3-10
- 301 through 304 3-10, 3-26
- 401 through 498 3-26
- 40X 3-11
- 501 through 516 3-27
- 600 through 699 3-28
- 6000 through 6099 3-30
- 601 through 605 3-11
- 6500 through 6599 3-31
- 6600 through 6699 3-32
- 6700 through 6799 3-32
- 8600 through 8699 3-33
- beeps only 3-22
- description 3-23
- error condition, resolving 3-23
- error log messages
  - Abnormal Program
    - Termination 3-61, 3-62
  - ASR-2 detected by ROM 3-61, 3-62
  - ASR-2 Test Event 3-61, 3-62
  - Automatic Server Recovery
    - Base Memory Parity
      - Error 3-61
    - Extended Memory Parity
      - Error 3-61
    - Memory Parity Error 3-61
    - Reset Limit Reached 3-61
  - Battery Failing 3-61
  - Caution, Temperature
    - Exceeded 3-62
  - Diagnostic Error 3-62
  - Error Detected On Boot
    - Up 3-62
  - NMI
    - Automatic Server Recovery
      - Timer Expiration 3-62
    - Expansion Board
      - Error 3-62
    - Expansion Bus Master
      - Time-Out 3-62
    - Expansion Bus Slave
      - Time-Out 3-62

- Fail-Safe Timer
  - Expiration 3-62
- PCI Bus Parity Error 3-62
- Processor Parity Error 3-62
- Software Generated
  - Interrupt Detected
    - Error 3-62
- Processor Exception 3-62
- Processor Prefailure 3-62
- Required System Fan
  - Failure 3-62
- Server Manager Failure 3-62
- UPS A/C Line Failure Shutdown
  - or Battery Low 3-62
- error messages
  - A Critical Error occurred prior to
    - this power-up 3-8
  - Accelerator board not
    - detected 3-34
  - Accelerator error log 3-34
  - Accelerator parity read 3-34
  - Accelerator parity write 3-34
  - accelerator status
    - Cache was automatically
      - configured 3-34
    - Data in the cache was
      - lost 3-34
    - Dirty data detected has
      - reached limit 3-34
    - Dirty data detected. Unable
      - to write 3-34
    - Excessive ECC errors 3-35
    - Obsolete data detected 3-35
    - Obsolete data was
      - discarded 3-35
    - Obsolete data was
      - flushed 3-35
    - Possible data loss in
      - cache 3-35
    - Temporarily disabled 3-35
    - Unrecognized status 3-35
    - Valid data found at
      - reset 3-35
    - Warranty alert 3-35
  - Adapter/NVRAM ID
    - mismatch 3-36
  - Array accelerator battery pack X
    - not fully charged 3-36
  - Array accelerator battery pack X
    - below reference
      - voltage 3-36
  - ASR-2 Timer Failure 3-8
  - beeps only 3-22
  - Board in use by expand
    - operation 3-36
  - Board not attached 3-36
  - Cache Accelerator Slot X
    - Initialization Failed 3-10
  - Cache Accelerators Not
    - Installed 3-10
  - Cache Switch Set
    - Incorrectly 3-9
  - Com Port Address Assignment
    - Conflict 3-11
  - Configuration Nonvolatile
    - Memory Invalid 3-8
  - Configuration Not
    - Complete 3-8
  - Configuration signature is
    - zero 3-36
  - configuration signature
    - mismatch 3-36
  - controller
    - communication failure
      - occurred 3-36
    - detected. NVRAM
      - configuration not
        - present 3-36
      - firmware needs
        - upgrading 3-36
      - is not configured 3-37
      - located in special graphics
        - slot 3-37
      - reported POST error 3-37
      - restarted with a signature of
        - zero 3-37
  - CPU Fan (Fan X) failure
    - detected 3-12
  - CPU Fan controller not
    - responding 3-12
  - Current SCSI bus cable
    - configuration is not
      - recommended 3-12
  - DC-DC Converter Failed 3-9
  - Disable command issued 3-37
  - Disk 0 Configuration Error 3-21
  - Disk 0 Failure 3-17
  - Disk 1 Error 3-21
  - Disk 1 Failure 3-18
  - Disk Controller Failure 3-18
  - Diskette Controller Error 3-11
  - Diskette Drive Type Error 3-11
    - drive (bay) X
      - firmware needs
        - upgrading 3-37
      - has insufficient capacity for
        - its configuration 3-37
      - has invalid M&P
        - stamp 3-37
      - has loose cable 3-37
      - is a replacement drive 3-38

- is a replacement drive marked OK 3-38
- is failed 3-38
- is undergoing drive recovery 3-38
- needs replacing 3-38
- upload code not readable 3-38
- was inadvertently replaced 3-38
- drive array
  - Array Accelerator Battery Charge Low 3-21
  - Array Accelerator Battery Depleted 3-21
  - Array Accelerator Configuration Error 3-22
  - Array Accelerator Not Responding 3-22
  - Array Accelerator Read Error 3-22
  - Array Accelerator Write Error 3-22
  - Controller detects replacement drives 3-17
  - Drive Failure 3-18
  - Drive(s) Disabled due to Array Accelerator Data Loss 3-22
  - External Drive Subsystem Error 3-17
  - not Configured 3-18
  - Operating in Interim Recovery Mode 3-19
  - Recovery Needed 3-19
  - Reports Valid Data 3-21
  - resuming Automatic Data Recovery process 3-17
- Drive Monitoring features are unobtainable 3-38
- Drive Monitoring is NOT enabled 3-38
- Drive Not Responding 3-21
- Drive time-out occurred on physical drive bay X 3-38
- Drive X indicates position Y 3-38
- Duplicate write memory error 3-39
- Error occurred reading RIS copy from SCSI Port X 3-39
- Fan controller not responding 3-12
- Fan failure detected 3-11
- Fatal ROM Error 3-8
- Fixed Disk 0 does not support DMA Mode 3-14
- Fixed Disk does not support Block Mode 3-14
- Fixed Disk failed Identify command 3-14
- Fixed Disk failed Set Block Mode command 3-14
- FYI, Drive (bay) X is non-Compaq supplied 3-39
- I/O Fan (Fan X) failure detected 3-11
- I/O Fan controller not responding 3-12
- I/O ROM Error 3-8
- Identify controller data did not match NVRAM 3-39
- Identify logical drive data did not match NVRAM 3-39
- Incorrect Drive Replaced 3-20
- Insufficient adapter resources 3-39
- Internal SCSI Jumper Board Not Installed 3-12
- Invalid Memory Configuration 3-9
- Invalid Memory Speed 3-9
- Keyboard Controller Error 3-11
- Keyboard Error 3-10
- Keyboard or System Unit Error 3-11
- Less than 75% batteries at sufficient voltage 3-39
- Locked SCSI Bus Detected. 3-12
- Log Reinitialized 3-9
- Logical drive X failed due to cache error 3-39
- Logical drive X status
  - Failed 3-40
  - Interim Recovery 3-40
  - Loose Cable Detected 3-40
  - Needs Recover 3-40
  - Overheated 3-40
  - Overheating 3-40
  - Recovering 3-40
  - Wrong Drive Replaced 3-40
- Loose cable detected, logical drives may be marked FAILED 3-41
- Low System Battery 3-12
- Memory Address Error 3-9
- Memory Detection Failure 3-9
- Memory Error 3-9
- Mirror data miscompared 3-41

- No configuration for accelerator board 3-41
  - Nonfunctioning Voltage
    - Regulator Module 3-10
  - NVRAM configuration present, controller not detected 3-41
  - Parallel Port X Address
    - Assignment Conflict 3-11
  - PCI slots powered down. 3-12
  - Permanently disabled 3-35
  - Power Fault On Processor
    - Bus X 3-10
  - Power Supply Failure, Power
    - Supply Unplugged, or Power Supply Fan Failure 3-12
  - Primary Disk Port Address
    - Assignment Conflict 3-16
  - Primary Fixed Disk Port
    - Assignment Conflict 3-16
  - Primary power supply
    - failure 3-12
  - Processor Configuration
    - Invalid 3-9
  - Processor Power Module has lost
    - Redundancy 3-10
  - Processor PPM Failed 3-9
  - Processor PPM has lost
    - Redundancy 3-10
  - RESUME - F1 key 3-22
  - RIS copies between drives do not match 3-41
  - ROM Error 3-8
  - Run System Configuration
    - Utility 3-22
  - SCSI cable error detected 3-12
  - SCSI Port X Drive ID X
    - failed - Replace 3-42
    - firmware needs
      - upgrading 3-42
    - has exceeded
      - threshold(s) 3-41
    - has loose cable 3-42
    - is not stamped for
      - monitoring 3-41
    - replaced on a good
      - volume 3-42
    - RIS copy mismatch 3-41
  - SCSI Port X drive ID Y firmware
    - needs upgrading 3-42
  - Secondary Disk Port Address
    - Assignment Conflict 3-16
  - Set configuration command
    - issued 3-42
  - Slot X Drive Array
    - Array Accelerator Memory
      - Size Change
        - Detected 3-13
    - Capacity Expansion Process
      - is temporarily
        - disabled 3-15
    - Drive(s) disabled due to
      - failure during
        - expand 3-15
    - New Logical Drive(s)
      - Attachment
        - Detected 3-14
    - Obsolete data found in Array
      - Accelerator 3-16
    - Physical Drive Position
      - Change(s)
        - Detected 3-13
    - ProLiant Storage System
      - Not Responding SCSI
        - port (y) 3-16
    - Resuming logical drive
      - expansion process 3-15
    - SMART Drive Detects
      - Imminent Failure 3-13
  - Slot x Drive Array Controller
    - Failure 3-18
  - Slot x Drive Array Option ROM
    - is Not Programmed
      - Correctly 3-15
  - Snoop Rules SRAM
    - Failure 3-10
  - Soft Firmware Upgrade
    - required 3-42
  - System Board Failure 3-8
  - System Options Not Set 3-8
  - System Processor Failed/
    - Mapped out 3-9
  - Tag Update Rules SRAM
    - Failure 3-10
  - Temperature violation
    - detected 3-11
  - Time & Date Not Set 3-8
  - Unable to communicate with
    - drive on SCSI Port x 3-42
  - Unknown disable code 3-42
  - Unrecoverable read error 3-43
  - Unsupported Processor Detected
    - System Halted 3-8
  - Voltage Regulator Module for
    - Processor X 3-10
  - Warning bit detected 3-43
  - Warning, Drive Write Cache
    - enabled on X 3-43
  - Write memory error 3-43
  - Wrong Accelerator 3-43
- Ethernet port, identified 4-2

Event List *See also* IMD  
  defined 3-46  
  printing 3-45  
  viewing 3-45  
event messages, defined 3-47  
event type  
  ASR-2, system lockup 3-48  
  Fan Failure 3-47  
  machine environment  
    Fan Inserted 3-47  
    Fan Removed 3-47  
    Fans Not Redundant 3-47  
    Overheat Condition 3-47  
  main memory  
    Correctable Error threshold  
      exceeded 3-47  
    Uncorrectable Error 3-47  
  operating system  
    automatic OS  
      shutdown 3-48  
      system crash 3-48  
  PCI bus error 3-47  
  power subsystem  
    power module failure 3-48  
    power supply failure 3-47  
    power supply inserted 3-47  
    power supply not  
      redundant 3-48  
    power supply  
      removed 3-48  
    system configuration  
      battery low 3-48  
  processor  
    Correctable Error Threshold  
      exceeded 3-47  
    Host Bus Error 3-47  
    Uncorrectable Error 3-47  
events log  
  description 3-3  
  viewing 3-3  
expansion boards  
  removing 2-27  
  removing, illustrated 2-27  
  replacing 2-27  
external SCSI access, identified 4-2  
external storage devices,  
  connecting 2-16

## F

fans  
  CPU  
    part number 1-5  
    removing 2-35  
    replacing 2-35

  power supply  
    part number 1-5  
    removing 2-12  
    removing, illustrated 2-12  
    replacing 2-12  
  rear  
    removing 2-35  
    removing, illustrated 2-35  
    replacing 2-35  
flow chart, ASR-2 3-55

## G

graphics display unit, test error  
  codes 3-27  
graphics, disabling on-board 3-66  
ground plug, disabling viii  
grounding techniques 2-2

## H

hard drive blank  
  part number 1-3  
  removing 2-18  
  removing, illustrated 2-18  
  replacing 2-18  
hard drives  
  cables, part number 1-6  
  capacity 5-6  
  height 5-6  
  interface 5-6  
  LED indicators, illustrated 4-11  
  part number 1-5  
  removing 2-19  
  removing, illustrated 2-19  
  replacing 2-19  
  size 5-6  
  specifications 5-6  
  test error codes 3-31  
  transfer rate 5-6  
Health Driver, description 3-54  
help  
  additional sources ix  
  Compaq authorized resellers,  
    telephone numbers ix  
  technical support telephone  
    numbers ix  
hot-plug drive cage *See* drive cage  
hot-plug power supply *See* power  
  supply  
hot-plug power supply backplane  
  board *See* power supply  
  backplane board

- I
- illustrated parts map, part
  - number 1-6
- illustrations
  - backplane board, removing 2-21
  - battery, removing 2-40
  - CD-ROM drive
    - cable routing 2-25
    - LED indicators 4-12
    - removing 2-22
  - CPU fan, removing 2-35
  - diskette drive
    - cable routing 2-25
    - LED indicator 4-13
    - removing 2-10, 2-11
  - drive cage, removing 2-20
  - drive positions 2-17
  - expansion boards,
    - removing 2-27
  - hard drive blank, removing 2-18
  - hard drive, removing 2-19
  - hot-plug drive cage
    - cable routing 2-26
  - Integrated Smart Array
    - Controller 2-37
  - mechanical parts 1-2
  - media device drive cage
    - cable routing 2-26
    - removing 2-24
  - memory
    - removing 2-31
    - slot locations 2-30
  - Power On/Standby switch,
    - removing 2-8
  - power supply backplane board,
    - removing 2-15
  - power supply blank,
    - removing 2-13
  - power supply fan,
    - removing 2-12
  - power supply LED
    - indicators 4-8
  - power supply, removing 2-14
  - power switch LED
    - indicators 4-7
  - processor
    - removing 2-33
    - system board
      - locations 2-32
  - Processor Power Module,
    - removing 2-34
  - rack-mount bezel, removing 2-9
  - rear panel components 4-2
  - removable media blank,
    - removing 2-23
  - riser board
    - expansion slots 4-3
    - LED indicators 4-14
    - removing 2-28
  - RJ-45 LED indicators 4-9
  - SCSI backplane board,
    - removing 2-21
  - SCSI hard drive LED
    - indicators 4-11
  - server cover, removing 2-7
  - SW2, location 4-5
  - system board
    - components 4-4
    - LED indicators 4-10
    - removing 2-38
    - system components 1-4
- IMD Event List, defined 3-46
- IML *See also* error log
  - accessing from Compaq Insight
    - Manager 3-44
  - defined 3-44, 3-61
  - description 3-3
  - error messages 3-61
  - error types, explained 3-61
  - recorded information 3-54,
    - 3-56, 3-59, 3-61
  - security levels defined 3-44
  - viewing 3-44, 3-45, 3-61
- Insight Agents, defined 3-68
- Insight Management Agents,
  - enabling 3-49
- Inspect Computer utility,
  - accessing 3-23
- Inspect listing, printing 3-4
- Inspect utility
  - accessing 3-2
  - booting remotely 3-59
  - description 3-2, 3-4
  - printing Inspect listing 3-4
  - running 3-4
- Integrated Management Log *See also* error log. *See* IML
- Integrated Remote Console,
  - features 3-54
- integrated server management,
  - features 3-49
- Integrated Smart Array Controller
  - cache size 5-7
  - data transfer method 5-7
  - illustrated 2-37
  - maximum drives supported 5-7
  - part number 1-5
  - protocol 5-7
  - removing 2-37
  - SCSI port connectors 5-7



- specifications 5-7
- transfer rate 5-7
- IP access 3-56
- IP/IPX, using network features 3-52
- IRQ conflict, resolving 3-3

## J

- jumper settings, obtaining 3-3

## K

- keyboard
  - test error codes 3-26
- keyboard connector, identified 4-2

## L

- laser product, identifying label 2-3
- LEDs
  - CD-ROM drive, illustrated 4-12
  - diskette drive, illustrated 4-13
  - power switch, illustrated 4-7, 4-8
  - riser board, illustrated 4-14
  - RJ-45, illustrated 4-9
  - SCSI hard drive, illustrated 4-11
  - system board, illustrated 4-10
- low-profile IDE CD-ROM drive *See* CD-ROM drive

## M

- maintenance and service guide, part number 1-6
- mass storage devices, guidelines 2-16
- mechanical parts
  - exploded view 1-2
  - illustrated 1-2
  - spare parts list 1-3
- media device drive cage
  - cable routing, illustrated 2-26
  - removing 2-24
  - removing, illustrated 2-24
  - replacing 2-24
- memory
  - clearing NVRAM 3-66
  - errors, recorded to Log 3-61
  - installation guidelines 2-29
  - module size 5-4
  - part numbers 1-5, 1-7

- removing 2-31
- removing, illustrated 2-31
- replacing 2-31
- slot locations, identified 2-30
- slot locations, illustrated 2-30
- specifications 5-4
- speed 5-4
- test error codes 3-25
- upgrade requirements 5-4
- width 5-4
- modem
  - test error codes 3-29
  - when used with ASR-2 3-52
- mounting kit, part number 1-6
- mouse connector, identified 4-2

## N

- NC3131 Fast Ethernet NIC 64 PCI dual base 10/100, part number 1-7
- NC3163 Embedded 10/100 Fast Ethernet NIC controller specifications 5-8
- NC3163 Embedded 10/100 Fast Ethernet NIC, part number 1-7
- Netelligent Management, defined 3-67
- network
  - access, configuring ASR-2 for 3-56
  - card slot, selecting 3-58
  - frame type, selecting 3-58
  - host name, setting 3-58
  - interface fault recovery, defined 3-64
  - protocol, setting 3-58
- Network Interface Controller *See* NIC
- network IP
  - address, setting 3-58
  - net mask, setting 3-58
  - router address, setting 3-58
- NIC
  - specifications 5-12
  - test error codes 3-30

## O

- operating system, booting into 3-59
- option board retainer, part number 1-6

**P**

- packing materials, part number 1-6
- pager
  - booting Compaq Utilities
    - from 3-57
  - serial interface, selecting 3-57
  - setting dial string 3-57
  - setting message 3-57
  - settings 3-57
  - testing 3-57
- parallel printer port, identified 4-2
- parallel printer, test error codes 3-26
- part numbers
  - baffle 1-6
  - battery 1-6
  - blank option board bracket 1-6
  - buns 1-6
  - cables
    - 14-pin power signal
      - head 1-6
    - 20-pin main power 1-6
    - CD data shredded 1-6
    - SCSI 1-device
      - shredded 1-6
    - SCSI 2-device
      - shredded 1-6
  - carton 1-6
  - CD tray assembly 1-6
  - CD-ROM drive 1-5
  - chassis 1-3
  - country kit 1-6
  - diskette drive 1-5
  - drive cage, removable media
    - device 1-3
  - drive cage, SCSI 1-3
  - fan, CPU 1-5
  - fan, power supply 1-5
  - hard drive 1-5
  - hard drive blank 1-3
  - hard drive/CD power
    - assembly 1-6
  - hot-plug redundant
    - power supply 1-5
  - illustrated parts map 1-6
  - Integrated Smart Array
    - Controller 1-5
  - maintenance and service
    - guide 1-6
  - memory 1-5, 1-7
  - mounting kit 1-6
  - NC3131 Fast Ethernet NIC 64
    - PCI dual base 10/100 1-7
  - NC3163 Embedded 10/100 Fast
    - Ethernet NIC 1-7
  - option board retainer 1-6
  - plastics kit 1-6
  - power cable kit 1-6
  - Power On/Standby switch 1-5
  - power supply backplane
    - board 1-5
  - power supply fan cover 1-6
  - power supply fan guard 1-6
  - processor 1-5
  - Processor Power Module 1-5
  - rack-mount bezel 1-3
  - removable media blank 1-3
  - return kit 1-6
  - riser board 1-5
  - SCSI drive cage backplane
    - board 1-5
  - server cover 1-3
  - signal cable kit 1-6
  - Smart Array 221 controller 1-7
  - Smart Array 3200 controller 1-7
  - Smart Array 4200 controller 1-7
  - system board 1-5
- parts
  - catalog, illustrated 1-1
  - handling 2-2
  - storing 2-2
  - transporting 2-2
- password, disabling 3-66, 4-5
- PCI boards, configuring
  - automatically 3-3
- PCI slots, identified 4-3
- plastics kit, part number 1-6
- pointing device interface, test error
  - codes 3-33
- POST
  - beeps, description 3-8
  - defined 3-7
  - error messages 3-7, 3-8
- power cable kit, part number 1-6
- Power On/Standby switch
  - part number 1-5
  - positions 2-4
  - removing 2-8
  - removing, illustrated 2-8
  - replacing 2-8
- power supply
  - bays, identified 4-2
  - frequency range 5-3
  - input specifications 5-3
  - installing redundant 2-13
  - part number 1-5
  - power connector, identified 4-4
  - removing 2-14
  - removing, illustrated 2-14
  - replacing 2-14

- signal cable header,
  - identified 4-4
- temperature range 5-3
- voltage input 5-3
- power supply backplane board
  - part number 1-5
  - removing 2-15
  - removing, illustrated 2-15
  - replacing 2-15
- power supply blank
  - removing 2-13
  - removing, illustrated 2-13
  - replacing 2-13
- power supply fan and bracket
  - removing 2-12
  - removing, illustrated 2-12
  - replacing 2-12
- power supply fan cover, part number 1-6
- power supply fan guard, part number 1-6
- power supply fan header, identified 4-4
- power supply LED indicators, illustrated 4-8
- power switch connector, identified 4-4
- power switch LED indicators
  - illustrated 4-7
  - table 4-7
- power switch, positions 2-4
- Power-On Self-Test *See* POST
- processor
  - aligning with slot 2-33
  - locations, identified 2-32
  - part number 1-5
  - removing 2-33
  - removing, illustrated 2-33
  - replacing 2-33
  - system board locations 2-32
  - system board locations, illustrated 2-32
  - test error codes 3-24
- Processor Power Module
  - part number 1-5
  - removing 2-34
  - removing, illustrated 2-34
  - replacing 2-34
  - slots, identified 4-4
  - system board locations 2-32
  - system board locations, illustrated 2-32
- processor slots, identified 4-4

## R

- rack warnings 2-6
- rack-mount bezel
  - part number 1-3
  - removing 2-9
  - removing, illustrated 2-9
  - replacing 2-9
- Rapid Recovery Engine,
  - enabling 3-49
- rapid recovery services 3-49
- rear panel components,
  - illustrated 4-2
- recovery
  - attended 3-51
  - automatic 3-49, 3-50
  - environmental 3-50
  - from software error 3-50
  - rapid recovery services 3-49
  - unattended 3-50
- remote management features,
  - defined 3-65
- Remote Management, defined 3-67
- remote service features,
  - defined 3-65
- Remote Utilities, accessing 3-23
- removable media bay
  - installing additional drives 2-23
- removable media blank
  - part number 1-3
  - removing 2-23
  - removing, illustrated 2-23
  - replacing 2-23
- removable media device drive cage,
  - part number 1-3
- removable media drive, installing
  - additional 2-23
- removal and replacement
  - procedures 2-1
- removal and replacement procedures,
  - preparation 2-4
- resource conflict, resolving 3-3
- return kit, part number 1-6
- Revision History Table
  - accessing 3-63
  - defined 3-63
  - where stored 3-63
- riser board
  - expansion slots, illustrated 4-3
  - LED indicators, illustrated 4-14
  - part number 1-5
  - removing 2-28
  - removing, illustrated 2-28
  - replacing 2-28
  - slot, identified 4-4

- RJ-45
  - LED indicators, illustrated 4-9
  - port, identified 4-2
- ROM is corrupted 3-66
- ROMPaq
  - Disaster Recovery 3-66
  - Firmware Upgrade Utility,
    - accessing 3-5
    - interruption 3-66
- S**
- SCSI backplane board
  - removing 2-21
  - removing, illustrated 2-21
  - replacing 2-21
- SCSI CD-ROM drives *See*
  - CD-ROM drives
- SCSI drive cage backplane board,
  - part number 1-5
- SCSI hard drives *See* hard drives
- SCSI hot-plug hard drive *See* hard drives
- SCSI ports, identified 4-2, 4-4
- SCSI tape drives *See* tape drives
- SDRAM DIMM *See* memory
- security levels
  - Caution, defined 3-44
  - Critical, defined 3-44
  - Repaired, defined 3-44
  - Status, defined 3-44
- security, ASR-2 3-60
- serial port, test error codes 3-29
- serial ports, identified 4-2
- server
  - rack warnings 2-6
  - safety warnings 2-6
  - unloading from pallet 2-6
- server cover
  - part number 1-3
  - removing 2-7
  - removing, illustrated 2-7
  - replacing 2-7
- shipping materials, part number 1-6
- signal cable kit, part number 1-6
- Smart Array 221 controller
  - data transfer method 5-9
  - dimensions 5-9
  - drives supported 5-9
  - height 5-9
  - part number 1-7
  - power requirements 5-9
  - SCSI port connectors 5-9
  - specifications 5-9
  - temperature range 5-9
  - thickness 5-9
  - transfer rate 5-9
- Smart Array 3200 controller
  - data transfer method 5-10
  - dimensions 5-10
  - drives supported 5-10
  - height 5-10
  - part number 1-7
  - SCSI port connectors 5-10
  - specifications 5-10
  - temperature range 5-10
  - thickness 5-10
  - transfer rate 5-10
- Smart Array 4200 controller
  - data transfer method 5-11
  - dimensions 5-11
  - drives supported 5-11
  - height 5-11
  - part number 1-7
  - power requirements 5-11
  - SCSI port connectors 5-11
  - specifications 5-11
  - temperature range 5-11
  - thickness 5-11
  - transfer rate 5-11
- SmartStart and Support Software CD
  - contents 3-5
  - running utilities 3-5
  - running utilities from 3-6
  - starting from 3-4
- software error
  - recovery from 3-50, 3-53
  - recovery start option 3-53
  - recovery timeout 3-53
- spare parts list
  - mechanical 1-3
  - system components 1-5
- specifications
  - CD-ROM drive 5-5
  - diskette drive 5-4
  - drive cage 5-13
  - hard drives 5-6
  - Integrated Smart Array
    - Controller 5-7
    - memory 5-4
    - NC3131 Fast Ethernet NIC 5-12
    - NC3163 Embedded NIC 5-8
    - power supply 5-3
    - Smart Array 221 controller 5-9
    - Smart Array 3200
      - controller 5-10
    - Smart Array 4200
      - controller 5-11
    - system unit 5-2

- Standby
  - activating 2-5
  - effects 2-4
- Standby recover
  - server option 3-53
  - server port 3-53
  - time-out 3-53
- storage automatic reconstruction,
  - defined 3-64
- storage fault recovery tracking,
  - defined 3-64
- Survey Utility, viewing 3-45
- SW1
  - function 4-5
  - settings 4-5
- SW2
  - function 4-5
  - location, illustrated 4-5
- switch settings, obtaining 3-3
- switches
  - SW1
    - function 4-5
    - settings 4-5
  - SW2
    - function 4-5
    - location, illustrated 4-5
- symbols
  - in text vii
  - on equipment 2-3
- system board
  - components, illustrated 4-4
  - LED indicators, illustrated 4-10
  - part number 1-5
  - removing 2-38
  - removing, illustrated 2-38
  - replacing 2-38
- system components
  - exploded view 1-4
  - illustrated 1-4
  - spare parts list 1-5
- System Configuration CD, starting
  - from 3-4
- System Configuration Utility
  - accessing 3-5
  - booting remotely 3-59
  - description 3-3
  - executing 3-6
  - messages 3-4
  - running 3-3
  - selecting Diagnostics from 3-23
- system configuration,
  - determining 3-4
- system unit
  - depth 5-2
  - height 5-2
  - power supply specifications 5-2

- specifications 5-2
- temperature range 5-2
- voltage input requirements 5-2
- weight 5-2
- width 5-2

## T

- tables
  - 1.44-MB Diskette Drive LED Indicator 4-13
  - 1.44-MB Diskette Drive Specifications 5-4
  - 2x1-Inch Optional Hot-Plug Drive Cage Specifications 5-13
  - ADU Diagnostic Messages 3-34
  - ASR-2 Features 3-53
  - ASR-2 IML Messages 3-61
  - Compaq Network Interface Board Test Error Codes 3-30
  - Compaq Servers Remote Management Features 3-65
  - Compaq System Configuration Utility Pager Settings 3-57, 3-58
  - Configuration Switches 3-66
  - Diagnostic Tools 3-2
  - Diskette Drive Test Error Codes 3-28
  - Drive Options 2-17
  - Event Messages 3-47
  - Graphics Display Unit Test Error Codes 3-27
  - Hot-Plug Power Supply LED Indicators 4-8
  - Hot-Plug Power Supply Specifications 5-3
  - Integrated Smart Array Controller Specifications 5-7
  - Keyboard Test Error Codes 3-26
  - Low-Profile CD-ROM Drive LED Indicators 4-12
  - Low-Profile IDE CD-ROM Drive Specifications 5-5
  - MC3131 Fast Ethernet NIC 64 PCI Dual Base 10/100 Specifications 5-12
  - Mechanical Spare Parts List 1-3
  - Memory Test Error Codes 3-25
  - Modem Communications Test Error Codes 3-29

- NC3163 Embedded 10/100 Fast Ethernet NIC Controller Specifications 5-8
  - OS Restart SCU Setting for ASR-2 3-59
  - Parallel Printer Test Error Codes 3-26
  - Pointing Device Test Error Codes 3-33
  - POST Error Messages 3-8
  - Power Switch LED Indicators 4-7
  - Primary Processor Test Error Codes 3-24
  - Processor and Processor Power Module Locations 2-32
  - Rear Panel Components 4-2
  - Revision History Table 3-63
  - Riser Board Expansion Slots 4-3
  - Riser Board LED Indicator 4-14
  - RJ-45 LED Indicators 4-9
  - SCSI Hard Drive Test Error Codes 3-31
  - SCSI Tape Drive Test Error Codes 3-32
  - SCSI/IDE CD-ROM Test Error Codes 3-32
  - SDRAM DIMM Slot Locations 2-30
  - SDRAM DIMM Specifications 5-4
  - Serial Test Error Codes 3-29
  - Smart Array 221 Controller Specifications 5-9
  - Smart Array 3200 Controller Specifications 5-10
  - Smart Array 4200 Controller Specifications 5-11
  - System Board Components 4-4
  - System Board LED Indicators 4-10
  - System Components Spare Parts List 1-5
  - System Configuration Switchbank Settings 4-5
  - System Unit Specifications 5-2
  - Wide Ultra2 SCSI Hot-Plug Hard Drive Specifications 5-6
  - tape drives, test error codes 3-32
  - technical support telephone numbers ix
  - technician notes viii
  - telephone numbers
    - Compaq authorized resellers ix
    - Compaq download facility ix
    - technical support ix
  - Test Computer utility, accessing 3-23
  - test error codes
    - CD-ROM drive 3-32
    - diskette drive 3-28
    - graphics display unit 3-27
    - hard drive 3-31
    - keyboard 3-26
    - memory 3-25
    - modem 3-29
    - NIC board 3-30
    - parallel printer 3-26
    - pointing device interface 3-33
    - processor 3-24
    - SCSI hard drive 3-31
    - SCSI tape drive 3-32
    - SCSI/IDE CD-ROM drive 3-32
    - serial port 3-29
    - tape drive 3-32
  - thermal failure 2-18
  - thermal shutdown 3-53
  - tools
    - recommended type 2-2
    - required for servicing 2-1
- ## U
- Upgrade Firmware utility, accessing 3-23
  - UPS shutdown threshold 3-53
  - utilities
    - accessing 3-5
    - ADU
      - accessing 3-5
      - description 3-3
      - executing 3-6
    - allowing network access to 3-58
    - Array Configuration
      - accessing 3-5, 3-6
      - executing 3-6
    - Compaq
      - configuring server to start 3-52
      - Insight Manager 3-67
      - Insight Manager, description 3-2
      - running on IPX network 3-52
      - running remotely 3-52
      - Survey Utility, description 3-2
      - Survey, installing 3-2

- System Reference
  - Library 3-49
- creating diskette versions 3-6
- DAAD
  - accessing remotely 3-65
  - description 3-3
- Diagnose Drive Array,
  - accessing 3-23
- Diagnostics
  - accessing 3-5
  - accessing from Compaq
    - system partition 3-5
  - menu choices 3-23
  - selecting from System
    - Configuration
      - Utility 3-23
- Firmware Upgrade,
  - accessing 3-5
- Health Driver 3-54
- IML Management Utility,
  - defined 3-45
- Inspect
  - accessing 3-2
  - description 3-2, 3-4
  - printing Inspect listing 3-4
  - running 3-4
- Inspect Computer,
  - accessing 3-23
- Integrated Management Log,
  - description 3-3
- Remote Utilities, accessing 3-23
- ROMPaq Firmware Upgrade,
  - accessing 3-5
- running from SmartStart and
  - Support Software CD 3-6
- starting from ASR-2 3-56
- Survey, defined 3-45
- System Configuration
  - accessing 3-5
  - booting from pager 3-57
  - description 3-3
  - executing 3-6
  - running 3-3
- Test Computer, accessing 3-23
- Upgrade Firmware,
  - accessing 3-23

## V

- video
  - disabling embedded 4-5
  - port, identified 4-2
- virtual power button connector,
  - identified 4-4
- voiding warranty viii
- voltage regulator board *See*
  - Processor Power Module

## W

- warnings
  - AC power overload 2-6
  - battery 2-39
  - component level repairs viii
  - defined vii
  - electric shock viii, 2-3, 2-4, 2-6, 2-9, 2-14
  - equipment damage viii, 2-3, 2-4
  - explosion 2-39
  - extending components 2-4, 2-6
  - fire 2-3
  - ground plug viii
  - hot surfaces 2-3, 2-6, 2-34, 2-37
  - improper repairs viii
  - loading rack 2-6
  - manual material handling 2-3
  - network interface
    - connection 2-3
  - personal injury 2-3, 2-4, 2-6, 2-37
  - power fluctuations 2-6
  - power supply repair 2-14
  - Processor Power Module 2-34
  - rack stability 2-4, 2-6
  - removing all power from
    - system 2-4
  - removing server from rack 2-6
  - RJ-45 receptacle 2-3
  - working with racks 2-4
- warranty, voiding viii
- website, Compaq home page ix
- Wide Ultra2 hard drive *See* hard drives
- work area recommendations 2-2
- Workstation Management,
  - defined 3-67
- wrist strap, using 2-2
- www.compaq.com ix